

E18190

First Edition / June 2021

# IN SEARCH OF INCREDIBLE



Service Manual



## COPYRIGHT INFORMATION

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 2021 ASUSTeK COMPUTER INC. All Rights Reserved.

## LIMITATION OF LIABILITY

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

## SERVICE AND SUPPORT

Visit our multi-language website at <https://www.asus.com/support/>

# Table of Contents

Disclaimer .....	4
Safety precautions.....	4
Major components.....	6
Installation tools.....	7
Removing the compartment cover.....	8
Disconnecting the battery .....	11
Replacing the battery.....	13
Replacing the M.2 SSD module .....	17
Replacing the LCD module .....	20
Replacing the motherboard .....	33
Wiring and connection diagrams .....	43

# Disclaimer


ASUS is not responsible for direct, indirect, intentional or unintentional damages resulting from improper installation and operation.

## Safety precautions


- Keep liquids or moisture away from your Notebook PC before installing or removing any components.
- Ensure to place your Notebook PC on a stable surface before installing or removing any components.
- Detach the clip or flap before removing the signal cables to prevent damage.
- Disconnect the power plug by pulling the plug evenly to avoid damage. Ensure to connect the signal cables in the correct orientation.
- Disconnect all power cables and remove the battery pack (if applicable) before cleaning your Notebook PC with liquid detergent to avoid risk of electric shock.
- Disconnect all power cables and remove the battery pack (if applicable) before installing or removing any components. Ensure to read and follow the instructions in the manual.

- Before handling components, use a grounded wrist strap or touch a safely grounded object to avoid damaging them due to static electricity.
- Keep liquids or moisture away from your Notebook PC to avoid short circuits.
- Hold components by the edges to avoid touching the ICs.
- Ensure to properly install all the components before connecting the AC power.
- Do not use power adapters or batteries from other devices to reduce the risk of injury to persons due to fire or explosion. Use only certified power adapters or batteries supplied by the manufacturer or authorized retailers.
- Ensure to install the correct screw models on your Notebook PC to prevent damage.


# Major components



## Motherboard with ports and connectors



**Fan/Cooling radiator**




**Keyboard (Top case module)**




**M.2 SSD module**



**LCD panel module**



**Power adapter**



**Battery and power connector**

---

**NOTE:**

- The illustrations are for reference only.
  - The maintenance procedures described in this manual depend on the model configuration and may not reflect the entire servicing process. For servicing those components that are not covered in this manual, please visit an authorized service center for further assistance.
- 

## Installation tools



**Screwdriver**



**Plastic blade**



**Tweezers**


# Removing the compartment cover

---

**NOTE:** The appearance of your Notebook PC's bottom view may vary per model.


---

- A. Use the torx screwdriver to remove the screw(s) from the Notebook PC's compartment cover.






- B. Place your Notebook PC in the orientation as shown in the illustration below.
- C. Starting from the bottom edge, separate the compartment cover from the chassis as shown in the illustration below.




- D. From the gap created in the previous step, detach the compartment cover and remove from the chassis.



To reattach the compartment cover:

- E. Align and reattach the compartment cover.  
F. Secure the compartment cover using the screw(s) you removed earlier.



# Disconnecting the battery


- A. Remove the compartment cover.

---


**NOTE:** For more details, refer to the *Removing the compartment cover* section in this manual.

---

- B. Locate and disconnect the battery power cable(s) as shown in the illustration below.



To connect the battery, align and connect the cable to the battery connector before you reattach the compartment cover.



# Replacing the battery

Refer to the following steps when installing a compatible battery in your Notebook PC:

---

**IMPORTANT!** Purchase your battery from authorized retailers of this Notebook PC to ensure maximum compatibility and reliability.

---

---

**WARNING!** Disconnect all the connected peripherals, any telephone or telecommunication lines and power connector (such as external power supply, battery pack, etc.) before removing the compartment cover.

---

---

**NOTE:**

- The appearance of your Notebook PC's bottom view and battery may vary per model but the module installation remains the same.
  - It is recommended that you install the battery under professional supervision. You may also visit an authorized service center for further assistance.
-


- A. Remove the compartment cover and disconnect the battery.

---


**NOTE:** For more details, refer to the *Removing the compartment cover* and *Disconnecting the battery* sections in this manual.

---

- B. Remove the screw(s) from the battery.




- C. Remove the battery.




- D. Prepare the new battery.

- E. Reinstall the battery as shown in the illustration below.



- F. Secure the battery using the screw(s) you removed earlier.





# Replacing the M.2 SSD module

Refer to the following steps when installing a compatible M.2 SSD module in your Notebook PC:

---

**IMPORTANT!** Purchase your M.2 SSD module from authorized retailers of this Notebook PC to ensure maximum compatibility and reliability.

---

---

**WARNING!** Disconnect all the connected peripherals, any telephone or telecommunication lines and power connector (such as external power supply, battery pack, etc.) before removing the compartment cover.

---

---

**NOTE:**

- The appearance of your Notebook PC's bottom view and M.2 SSD module may vary per model but the module installation remains the same.
  - It is recommended that you install the M.2 SSD module under professional supervision. You may also visit an authorized service center for further assistance.
-


- A. Remove the compartment cover and disconnect the battery.

---


**NOTE:** For more details, refer to the *Removing the compartment cover* and *Disconnecting the battery* sections in this manual.

---

- B. Remove the screw(s) from the M.2 SSD module.
- C. Remove the M.2 SSD module from the motherboard.



- D. Prepare the new M.2 SSD module.
- E. Align and insert the M.2 SSD module into the M.2 connector on the motherboard.
- F. Secure the M.2 SSD module in place using the screw(s) you removed earlier.



# Replacing the LCD module

---

**IMPORTANT!** Do not bend the LCD panel in any ways to avoid risk of LCD panel leakage.

---

---

**NOTE:** The illustrations are for reference only.

---


- A. Remove the compartment cover and disconnect the battery.

---


**NOTE:** For more details, refer to the *Removing the compartment cover* and *Disconnecting the battery* sections in this manual.

---


- B. Place your Notebook PC in the orientation as shown in the illustration below.
- C. Locate and disconnect all the cable(s) as shown in the illustration below.
- D. Unroute the eDP cable from the cable guides on the chassis.



- E. Remove the screw(s) from the hinges, and then remove the LCD panel module.



- F. Pry loose the top side of the bezel first, then continue with the left and right sides of the bezel. **DO NOT** remove the bezel!




- G. Locate the tip of the adhesive strips near the top area of the display panel.
- H. Carefully pull the adhesive strips out one part at a time as shown in the illustration below.

---


**IMPORTANT!** Avoid pulling the adhesive strips with excessive force or the adhesive strips might break.

---





- I. Release the bottom side of the LCD bezel.
- J. Use the tweezers to remove the tab from the LCD hinge cap.
- K. While removing the LCD panel module and the LCD bezel, remove also the eDP cable from the LCD hinge cap.




---


**NOTE:** The bottom of the LCD bezel is attached to the LCD panel module.

---


- L. Prepare the new adhesive strips.
- M. Remove the release liner underneath the adhesive strips.
- N. Align and apply the adhesive strips as shown in the illustration below.



- O. Remove the release liner above the adhesive strips.



- P. Prepare the new LCD panel module.
- Q. Align and place the new LCD panel module in the orientation as shown in the illustration below.
- R. Guide the eDP cable through the LCD hinge cap. Use the tweezers to secure the eDP cable to the LCD hinge cap with a tab.




- S. Prepare the new LCD bezel.

---


**NOTE:** The new LCD bezel comes with pre-attached adhesive strips.

---


- T. Remove the release liner underneath the LCD bezel.




- U. Align and gently reattach the bezel onto its slot on the bottom side of the LCD panel module. Continue reattaching upward along the left and right sides. Finally, reattach the top side.




- V. In the orientation shown, align and place the hinge of the display module on the screw holes on the chassis.
- W. Secure the LCD panel module using the screw(s) you removed earlier.





- X. Route the eDP cable through the cable guides on the chassis.
- Y. Reconnect all the cable(s) as shown in the illustration below.



## LCD hinges screw map



-  M2.0 X 4.5L (5PCS)
-  M2.0 X 3.5L (1PCS)



# Replacing the motherboard

Refer to the following steps when installing the motherboard to your Notebook PC:

---

**IMPORTANT!** Purchase your motherboard from authorized retailers of this Notebook PC to ensure maximum compatibility and reliability.

---

---

**WARNING!** Disconnect all the connected peripherals, any telephone or telecommunication lines and power connector (such as external power supply, battery pack, etc.) before removing the compartment cover.

---

---

**NOTE:**

- The appearance of your Notebook PC's bottom view and motherboard may vary per model but the module installation remains the same.
  - It is recommended that you install the motherboard under professional supervision. You may also visit an authorized service center for further assistance.
-


- A. Remove the LCD panel module.

---


**NOTE:** For more details, refer to steps A to E in the *Replacing the LCD module* section in this manual.

---


- B. Remove the screw(s) from the M.2 SSD module.
- C. Remove the M.2 SSD module from the motherboard.




- D. Remove the cooling radiator screw(s) one by one in the sequence as shown in the illustration below.
- E. Remove the screw(s) from the fan.




- F. Locate and disconnect the fan cable(s) as shown in the illustration below.
- G. Remove the fan/cooling radiator from the motherboard.




- H. Locate and disconnect the left speaker cable(s) as shown in the illustration below.
- I. Remove the speaker from the chassis.




- J. Remove the screw(s) from the I/O board FFC connector.
- K. Locate and disconnect all the cable(s) and antenna(s) as shown in the illustration below.




- L. Remove the screw(s) from the motherboard.




- M. Release the motherboard I/O connectors from the I/O slots on the chassis and then remove the motherboard.




- N. Prepare the new motherboard.
- O. Align and insert the motherboard I/O connectors into the I/O connectors on the chassis. Then lower the motherboard back in the chassis.




- P. Secure the motherboard using the screw(s) you removed earlier.




- Q. Locate and reconnect all the connector(s) and antenna(s) disconnected earlier.
- R. Secure the I/O board FFC connector using the screw(s) you removed earlier.



- S. Align and install the speaker into its slot on the chassis.
- T. Reconnect the left speaker cable(s) as shown in the illustration below.




- U. Align and replace the fan/cooling radiator on the screw holes of the motherboard.
- V. Reconnect the fan cable(s) as shown in the illustration below.







- W. Secure the fan in place using the screw(s) you removed earlier.
- X. Secure the cooling radiator screw(s) one by one in the sequence as shown in the illustration below.



- Y. Align and insert the M.2 SSD module into the M.2 connector on the motherboard.
- Z. Secure the M.2 SSD module in place using the screw(s) you removed earlier.




## Motherboard screw map




■ M2.0 X 4.5L (2PCS)

■ M2.0 X 3.0L (1PCS)


# Wiring and connection diagrams



## Top View



## Bottom View



- |                                     |   |
|-------------------------------------|---|
| 1. I/O FPC connector                | 13. HDMI connector                        |
| 2. Fan connector                    | 14. Micro HDMI for LAN connector          |
| 3. Keyboard connector               | 15. Speaker connector                     |
| 4. Fingerprint board connector      | 16. LED connector                         |
| 5. NFC connector                    | 17. M.2 SSD module connector              |
| 6. Backlight connector              | 18. Camera connector                      |
| 7. Battery power connector          | 19. Speaker connector                     |
| 8. Display connector                | 20. I/O FPC connector                     |
| 9. Touchpad connector               | 21. Headphone/Headset/<br>Microphone jack |
| 10. RTC connector                   | 22. USB 3.2 Gen 1 connector               |
| 11. USB 3.2 Gen 2 Type-C® connector | 23. Random-access memory (RAM)<br>module  |
| 12. USB 3.2 Gen 2 Type-C® connector |   |