

ASUS ROG Zephyrus G16 (GU603V) series

Service Guide

COPYRIGHT INFORMATION

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 2024 ASUSTeK COMPUTER INC. All Rights Reserved.

LIMITATION OF LIABILITY

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

Disclaimer

ASUS is not responsible for direct, indirect, intentional or unintentional damages resulting from improper installation and operation.

Safety precautions


- Keep liquids or moisture away from your Notebook PC before installing or removing any components.
- Ensure to place your Notebook PC on a stable surface before installing or removing any components.
- Detach the clip or flap before removing the signal cables to prevent damage.
- Disconnect the power plug by pulling the plug evenly to avoid damage. Ensure to connect the signal cables in the correct orientation.
- Disconnect all power cables and remove the battery pack (if applicable) before cleaning your Notebook PC with liquid detergent to avoid risk of electric shock.
- Disconnect all power cables and remove the battery pack (if applicable) before installing or removing any components. Ensure to read and follow the instructions in the manual.
- Before handling components, use a grounded wrist strap or touch a safely grounded object to avoid damaging them due to static electricity.
- Keep liquids or moisture away from your Notebook PC to avoid short circuits.
- Hold components by the edges to avoid touching the ICs.
- Ensure to properly install all the components before connecting the AC power.
- Do not use power adapters or batteries from other devices to reduce the risk of injury to persons due to fire or explosion. Use only certified power adapters or batteries supplied by the manufacturer or authorized retailers.
- Ensure to install the correct screw models on your Notebook PC to prevent damage.

- [Service Overview](#)
- [ASUS ROG Zephyrus G16\(GU603V\) Overview](#)
- [Components Top View](#)
- [Components Bottom View](#)
- [Repair Overview](#)
- [Appropriate Tools](#)
- [Keyparts and Related Parts](#)
- Disassembly steps :
 - [BOTTOM CASE](#)
 - [SSD](#)
 - [DDR](#)
 - [BATTERY](#)
 - [WIFI CARD](#)
 - [HALL SENSOR BD](#)
 - [WOOFER](#)
 - [THERMAL MODULE](#)
 - [FAN](#)
 - [MAIN BOARD](#)
 - [BUTTON BD](#)
 - [TWEETER](#)
 - [TOUCHPAD MODULE](#)
 - [KEYBOARD MODULE](#)
 - [LCD BEZEL](#)
 - [LCD PANEL](#)
 - [LCD COVER MODULE](#)

- **Carefully read through this Service Guide for a look at various components of the device before performing any service and repairs.**
- To provide the best service, we have provided the below information for technicians from distributors and resellers to perform the complete device disassembly and assembly. Before performing the procedures, please be sure to read through the overview in this service guide for component overview to avoid any unwarranted damages to the device hardware.
- The following contents include all part numbers mentioned in the service guide are **used for reference only**, if you need the exact part number for ordering, please refer to the OrderBook.
- Due to sales policy difference, the components might have different specifications on the same series product, please refer to E-manual by model.


Due to sales policy difference, the components may have different specifications on the same model. If you have any operational issues, please contact the service hotline.

Top View




- 1 Array microphones
- 2 Camera
- 3 Camera indicator
- 4 Display panel
- 5 Status indicators
- 6 Audio speakers
- 7 Capital lock indicator
- 8 Power button
- 9 Keyboard
- 10 Touchpad

Cover View




- 1 Microphone

Bottom View




- 1 Air vents
- 2 Audio speakers
- 3 Bottom cover

Right View



- 1 USB 3.2 Gen 2 port
- 2 MicroSD card slot
- 3 Air vents
- 4 Kensington® Security slot

Left View



- 1 Air vents
- 2 Power (DC) input port
- 3 HDMI output port
- 4 LAN port
- 5 USB 3.2 Gen 2 port
- 6 Thunderbolt™ 4 port with Power Delivery
- 7 USB 3.2 Gen 2 Type-C® /DisplayPort/Power Delivery combo port
- 8 Headphone/Headset/Microphone jack

- 6 Thunderbolt™ 4 port with Power Delivery
- 7 USB 3.2 Gen 2 Type-C® /DisplayPort/Power Delivery combo port

Note: Supports using JIG BOARD and Type C debug cable to read EEPROM data



The "UP" mark on the TYPE-C debug cable must be inserted facing upwards.

- 8 Headphone/Headset/Microphone jack

◆ LCD COVER MODULE



◆ LCD Panel (16")



◆ LCD BEZEL



◆ KEYBOARD MODULE



◆ BOTTOM CASE




◆ MAIN BOARD



◆ THERMAL MODULE



◆ FAN



◆ HALL SENSOR BD



◆ BUTTON BD



◆ DDR



◆ SSD



◆ BATTERY



◆ WIFI CARD



◆ TOUCHPAD MODULE



◆ CAMERA




◆ BATTERY CABLE




◆ POWER KEY



◆ WIFI ANTENNA



◆ HINGE L/R



◆ HINGE CAP L/R



◆ HINGE RUBBER L/R



◆ WOOFER




◆ TWEETER



◆ BATTERY RIB RUBBER



◆ SSD THERMAL PAD




◆ HALL SENSOR FFC




◆ TP FFC



◆ DIMM BOT ABSORBER



◆ DIMM CONN ABSORBER




◆ SSD ABSORBER

◆ TP SPONGE



◆ HALL SENSOR PCB ADH




◆ LCD CU FOIL




◆ GRAPHITE



◆ CABLE SPONGE



◆ CABLE TAPE




◆ KB TAPE



◆ EDP CABLE



◆ MB WIFI MODULE MYLAR



◆ MIC FPC




◆ SCREW RUBBER



◆ BOTTOM CASE IO GASKET



◆ CAMERA SPONGE




◆ CAM MODULE TAPE



◆ TP HOLDER MYLAR




◆ LCD COVER MODULE




◆ LCD Panel



◆ LCD BEZEL



◆ MAIN BOARD



◆ THERMAL MODULE



◆ HALLSENSOR BD



◆ BUTTON BD




◆ POWER KEY



◆ BOTTOM CASE



◆ KEYBOARD MODULE



This chapter describes disassembly and assembly (Assemble document please look up from the last page), please follow the information provided in this section to perform the complete disassembly procedure.

◆ Precautions:


Before you perform any service or repair on the notebook, please pay special attention to the cautions prevent any damages to the notebook.

1. Be sure that the notebook is powered down.
2. Before disassembling any part, please disconnect all power source. ex: AC plug/Battery connector/Power protect screw etc.

3. Remove all rings, watches and any other metal objects from your hands.



4. Always wear a ground strap on your hand to protect the notebook from static discharge.
5. Please refer to “ANSI ESD S20.20” about ESD protection measure.
6. Put the disassembled parts in the functional PE BAG to avoid any damages of the A/B/C/D part.



7. The maintenance environment temperature is 20-30 °C and humidity is 40% - 70%.
8. To avoid scratching on the surface of machine; please use anti-static and soft materials to put on desk in repair environment as below photo.



9. Screw Appearance Criteria:

If the screws have the following damaged appearance, please do not use.

- a. Shape deformed.
- b. Damaged head – unable to drive in or the stripped screw.
- c. Damaged unable to securely tighten.
- d. Paint scratched off.
- e. Rusty



10. The following chapter includes all part numbers mentioned in service guide are used for reference only, actual part name depends on different SKU, if you need the exact part number for ordering, please refer to the Orderbook.
11. Due to sales policy difference, the components may have different specifications on the same model. Please note that all pictures and components shown on Service Guide are for disassembly/assembly description purpose only, so please refer to the actual product for disassemble/assemble.

Please prepare and select the appropriate tools to disassemble/assemble for the ASUS ROG Zephyrus G16 (GU603V) series notebook.

◆ Screwdriver

Please accord to different screw specification to choose different screwdriver and head.

#1



◆ Plastic Blade




◆ Plastic Tweezers

Use a pair of tweezers to remove/insert/tidy cables.




◆ Thickness Gauge

Thickness compass specification 0.05mm-1.5mm. Use it to measure the gap.



◆ Magnetism Board

Suggest local buy magnetism board to place screw, avoid mix different type screw to cause assembly damage.



◆ Alcohol 95%



◆ Glove



◆ Dust-free Cloth



◆ Thermal Pad PTM7958



◆ PLASTIC CARD T=0.35mm



◆ FCR-AS Thermal Grease



◆ PLASTIC PICK T=0.5mm




◆ NB LCD MYLAR *4pcs

Use it to align panel position.

LCD MYLAR can be reused 5 to 10 times, please stick it on the plastic bag save after used, and repeatedly use until lose stickiness.



Please prepare and select the appropriate tools to disassemble/assemble for the ASUS ROG Zephyrus G16 (GU603V) series notebook.



⚠ Warning! When the tool is with Liquid Metal residue, please clean tools with dust free cloth and 95% alcohol.

Tooling Type	Item	Part Name	Memo
For Liquid metal use	1	Silicone scraping pen	
	2	Conductonaut 1g (Liquid Metal)	▪Please store it in the environment of 10 ~ 40 °C. ▪Please keep cover tightly closed until ready for next time use. ▪Shipping category : Dangerous Goods.
	3	2023 Intel Raptor Lake H45 steel plate	
	4	Stainless steel plate (60mm*20mm*0.2t)	
For Clean use	5	Dust-free cotton swab//class 100 (100pcs)	
	6	95% alcohol	
	7	Dust-free cloth	

Disassembly Notice





The device has an Ambient Light Sensor (ALS) for power-off protection function.

Step 1 : Remove rubbers *3pcs.

Step 2 : Remove screws *12pcs.


Step 3 : Use plastic blade to pry the bottom case.



⚠ The screw is unable to remove from bottom case, so please always loosen it last, and lock it at first.



⚠ To avoid the bottom case hook, don't insert plastic blade in each red circle.



⚠ Please follow above arrow direction with using plastic blade to pry bottom case in each blue circle location.(To avoid the bottom case hook, please prying at each blue circle location.)

Screws	QTY	Spec	Torque (kgf-cm)
	4	M2*11L (4.5,0.8) (K) #1	2.0±0.2
	3	M2*8L(4.5,0.8) (K)#1	2.0±0.2
	3	M2*8L(4.5,0.8) (K)#1	2.8±0.2
	2	M2*11.5L (4.5,0.8) (K) #1	2.0±0.2
	1	Retention Screw	2.0±0.2



Ambient Light Sensor (ALS):

1. After removing the BOTTOM CASE, the ambient light sensor detects light, system will automatically power off for protection.
2. Make sure assemble bottom case back and plug in AC adapter, then you can power on normally.



Disassembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.


⚠ Please be sure to pull out adapter and disconnect the battery.

Step 1 : Disconnect the battery connector.

Step 2 : Remove the Thermal PAD upon the SSD.



Step 3 : Remove screws *2pcs and SSD *2pcs then remove absorbers *4pcs.

Step 4 : Remove BOT THERMAL PAD.



Screws	QTY	Spec	Torque(kgf-cm)
	2	M2*4.5L(4.5,0.8) (K)#1	2.0±0.2

Assembly Notice

⚠ When installing the SSD, please keep the SSD less than 15 degrees with motherboard, and then insert the SSD.




1 Disconnect



2 Remove



3 Unscrew and remove



4 Remove



Assembly Notice






The device has an Ambient Light Sensor (ALS) for power-off protection function.


⚠ Please be sure to pull out adapter and disconnect the battery.

⚠ When installing the SSD, please keep the SSD less than 15 degrees with motherboard, and then insert the SSD.


A Please use SSD1 slot as first priority.



B Follow the illustrations to paste absorbers on SSD.



C Follow the steps below to assemble SSDs.



Disassembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.





⚠ Please be sure to pull out adapter and disconnect the battery.

Step 1 : Tear off DIMM CONN ABSORBER.

Step 2 : Unlock and remove the DDR.

Step 3 : Tear off DIMM BOT ABSORBER *1pc from DDR.

Step 4 : Please check and remove the PN label from the ABSORBER, and paste it back to the RAM module.

**1** Tear off**2** Unlock and Remove**3** Tear off**4** Tear off


Assembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.

⚠ Please be sure to pull out adapter and disconnect the battery.

A Follow below steps to paste absorber on DDR.



B Follow below steps to assemble DDR.



Disassembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.

⚠ Please be sure to pull out adapter and disconnect the battery.

Step 1 : Remove screws *4pcs.

Step 2 : Remove BATTERY.

Step 3 : Disconnect battery cable.



2 Remove




3 Disconnect



Assembly Notice

⚠ For BATTERY RIB RUBBER assembly, please follow below location to paste.
* The BATTERY RIB Rubber need to be attached on the rib.



⚠ When replacing new battery, please follow illustration (red mark) to paste GU603VV KB TAPE *1pc.



Disassembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.


⚠ Please be sure to pull out adapter and disconnect the battery.

Step 1 : Tear off the TAPE and MYLAR.



Step 2 : Disconnect RF cable *2pcs.

Step 3 : Remove the screw *1pc.

Step 4 : Remove the WLAN CARD.



① Tear off



② Disconnect



③ Unscrew




④ Remove




Screws	QTY	Spec	Torque(kgf-cm)
	1	M2*4.5L(4.5,0.8) (K)#1	2.0±0.2

Assembly Notice


⚠ Please assemble RF cable according to below image.



⚠ After the WIFI card is assembled, please paste the CABLE TAPE and Mylar according to the following positions.



CABLE TAPE



MB WIFI MODULE MYLAR

Disassembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.

⚠ Please be sure to pull out adapter and disconnect the battery.



Step 1 : Disconnect the HALL SENSOR FFC connector.

Step 2 : Remove HALL SENSOR FFC.


Step 3 : Remove HALL SENSOR BD.



1 Disconnect



2 Remove





3 Remove





Assembly Notice

⚠ If FFC is damage during disassembly, please replace new one. Here are some samples of FFC damage:



⚠ For HALL SENSOR BD assembly, please paste HALLSENSOR PCB ADH (1pc) as below.



Disassembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.


⚠ Please be sure to pull out adapter and disconnect the battery.

Step 1 : Disconnect the SPEAKER connector (green mark) and release tape *1pc (yellow mark).

Step 2 : Remove the WOOFER.



1 Disconnect




2 Remove




Assembly Notice

A Please follow the mark below to tidy up cable.



B Paste tape *1pc to fix speaker cable then connect the speaker connector.



Disassembly Notice





The device has an Ambient Light Sensor (ALS) for power-off protection function.

⚠ Please be sure to pull out adapter and disconnect the battery

Step 1 : Disconnect cables (yellow mark) and release tapes/sponges in green area.

Step 2 : Please follow the reverse screws numbers to remove and release screws *7pcs.


Step 3 : Remove the THERMAL MODULE.

Screws	QTY	Spec	Torque (kgf-cm)
	4	M2*4.5L (4.5,0.8) (K) #1	2.0±0.2
	3	Retention screw	2.0±0.2




Recommend that the force point is at green block, and pull up thermal module to take it out. Do not pull up at red block and also notice the thermal pipe should not have deformation.

1 Disconnect and remove



2 Unscrew



3 Remove




Assembly Notice

Step-1

To prevent a short circuit resulting from the Thermal module deforming and contact with the components below, please paste a TAPE to the motherboard as illustrated.

For Model : GU603VI/VU/VV/ZI/ZU/ZV




Step-2

Please follow the screws numbers to lock screws *7pcs.

Step-3

Please follow the mark below to tidy up cable.



IMPORTANT! Thermal paste, thermal pads, liquid metal, or other thermal interface materials must be thoroughly removed and replaced if this component is removed. Ensure that replacement materials are available before proceeding, or contact an authorized service center for assistance.

WARNING! The heat sink contains liquid metal and should only be removed by authorized service personnel. Significant damage may occur to motherboard components if the heat sink is improperly removed.

Disassembly Notice





The device has an Ambient Light Sensor (ALS) for power-off protection function.



⚠ Please be sure to pull out adapter and disconnect the battery.

Step 1 : Disconnect connectors *2pcs. (Yellow mark)

Step 2 : Remove screws *4pcs. (Green mark)

Step 3 : Remove the FAN *2pcs.

Screws	QTY	Spec	Torque (kgf-cm)
 	4	M2*4.5L (4.5,0.8) (K) #1	2.0±0.2

**3** Remove

Assembly Notice



Please use the correct technique to take fans off to avoid getting out of shape.



Disassembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.


⚠ Please be sure to pull out adapter and disconnect the battery.

Step 1 : Disconnect connectors (yellow mark).


Step 2 : Remove screws *2pcs (green mark).

Step 3 : Remove the MAIN BOARD.

Screws	QTY	Spec	Torque (kgf-cm)
	2	M2*4.5L (4.5,0.8) (K) #1	2.0±0.2



⚠ Please refer Repair Notice SOP to rework Liquid metal.



Assembly Notice

Step-1

thermal module before.

- THERMAL MODULE Location:[VRAM/CHOKE/MOS]
Material: FCR-AS Grease


- MB Location:[GPU]
Material: TH PAD PTM7958)

Step-2


Please refer Repair Notice SOP for **Liquid metal** rework when reassemble thermal module before.

- MB Location:[CPU]


Mainboard connector placement



Materials on mainboard



Materials on mainboard





Disassembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.

- Step 1 : Remove screws *2pcs and remove BUTTON BD with FP PW FFC.
Step 2 : Disconnect connector and remove FP PW FFC from BUTTON BD.
Step 3 : Remove POWER KEY from top case.

Screws	QTY	Spec	Torque (kgf-cm)
	2	M2*3L (K) B-ZN #1 NY	2.0±0.2



① Unscrew



② Disconnect



③ Remove

**Important Repair Notice : RN202301101**


Module(L2) or Main-Board(L3) repair, if require a device or Main-Board power on, please must assembly POWER BUTTON Board, then connect power (Battery/ AC Adapter). After that, you can start up it.

*Notice: If POWER BUTTON Board is not assembled, the power key will be unable to work.

Assembly Notice



If FFC is damage during disassembly, please replace new one. Here are some samples of FFC damage:




Disassembly Notice





The device has an Ambient Light Sensor (ALS) for power-off protection function.

Step 1 : Release TWEETER TAPE *6pcs (red mark).

Step 2 : Insert plastic blade from upper side of tweeter and lift it up to remove from KB module.




2 Remove



Assembly Notice

⚠ When assemble TWEETER SPEAKER, please follow below mark to tidy up cable and paste TWEETER TAPE *6pcs.



Disassembly Notice









The device has an Ambient Light Sensor (ALS) for power-off protection function.

Step 1 : Disconnect and remove the FFC.

Step 2 : Flip up the KB FPC and remove screws *3pcs.

Step 3 : Remove TOUCHPAD module.

Screws	QTY	Spec	Torque (kgf-cm)
 	3	M2*2.5L (4.5,0.5) (K) #1	2.0±0.2



**1** Disconnect**2** Flip up and unscrew**3** Remove

Disassembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.


Step 1 : Remove hinge's screws *6pcs.
Step 2 : Flip up and remove KB module.

Screws	QTY	Spec	Torque (kgf-cm)
 	6	M2*4.5L (4.5,0.8) (K) #1	2.0±0.2

1 Unscrew



2 Flip up and remove



Disassembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.

Step 1 : Remove LCD BEZEL.

①

Step 1-1~1-3 Start from the middle area of each side of bezel, Using the forefinger to hold the outer edge firmly and the thumb flipping the bezel inner edge outward to release the hooks as indicated in the diagram shown. (It can be helpful, if holding the bezel outer edge firmly with forefinger.)

Step 1-4 Use plastic blade to pry the bezel from hinge side (green mark).



Step 1-5 Due to some tapes behind the lower edge of bezel, please using plastic blade to teardown the bezel.

Please follow the direction shown in the red arrow, to move plastic blade from left to right and peel the bezel away slowly. **While peeling, please move the blade in the parallel direction to the panel and pressing the black Mylar downward** (As circled in green) to ensure the black Mylar and the tape behind the bezel are well separated.

Please move blade slowly to separate the bezel away, and must press the black Mylar downward with panel parallel direction..




Assembly Notice



When reuse the LCD BEZEL:

Please paste new LCD BEZEL ADHESIVE before assembly BEZEL.
(New LCD BEZEL already contains LCD BEZEL ADHESIVE *1pc, BEZEL ADHESIVE TOP*1pc, BEZEL ADHESIVE L/R*2pcs.)



Disassembly Notice







The device has an Ambient Light Sensor (ALS) for power-off protection function.

Step 1 : Pull out LCD adhesive *2pcs.


Step 2 : Flip up the panel and disconnect the EDP cable.

Step 3 : Remove screws *6pcs then remove HINGE module R & L.


Step 4 : Remove screws *4pcs then remove caps and deco rubbers from HINGE.

Screws	QTY	Spec	Torque (kgf-cm)
 	6	M2.5*2.3L(7.5,0.6)(K) #1	2.3±0.2 kgf-cm
 	4	M1.4*2.5L(3.4,0.5) (K)#0	1.3±0.2 kgf-cm


- 1  Please pull the adhesive up about 30 degree slowly, and don't pull out the tape in vertical direction!




- 2 Flip up the panel, and disconnect the MIC cable and EDP cable.



- 3 Remove



- 4 Remove




Assembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.

A When reuse the LCD PANEL or BEZEL:


Please use the fingertip to clean the residual glue on PANEL or BEZEL.

**B** Before assembly the NEW LCD PANEL :

Please make sure paste GRAPHITE and CU FOIL at panel back side.

**Step-1**

Please confirm the position to be paste according to different panel.(Green line).

With Position line panelWithout Position line panel**Step-2**

Paste the GRAPHITE.

**Step-3**

Paste the CU Foil.
(on the GRAPHITE)



Assembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.

C When assembly the LCD PANEL: (The following is an operation example)

Step 1~2 : Paste NB LCD MYLAR *6pcs on LCD COVER.
(Positions are as below)

Step-1 Upper Left Corner : Mylar *3pcs

Step-2 Upper Right Corner : Mylar *3pcs



Step 3 : Remove release paper of LCD Adhesive *2pcs.

Step 4 : Assembly and align the LCD to the upper side of the LCD Cover.

Step 5 : Remove Mylar *6pcs and complete the Panel assembly.


Step-3 Remove



Step-4 Align



Step-5 Pull out Mylar *6pcs.



⚠ Please stick LCD MYLAR on the plastic bag save after used, and repeatedly use until lose stickiness.

Disassembly Notice




The device has an Ambient Light Sensor (ALS) for power-off protection function.

Step 1 : Release GASKET and disconnect MIC FPC connectors.

Step 2 : Remove MIC FPC and EDP CABLE.

Step 3 : Remove CAMERA.


Step 4 : Remove MIC RUBBER *2pcs.




1 Release and disconnect



2 Remove



3 Remove



4 Remove



Assembly Notice

⚠ After the camera module is assembled, please stick the camera module tape and camera sponge according to the following positions, and then connect the MIC FPC.

CAM MODULE TAPE

CAMERA SPONGE




Assembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.

A Please follow the green mark to tidy up MIC FPC and EDP CABLE.




Assembly Notice



The device has an Ambient Light Sensor (ALS) for power-off protection function.

- B** Please follow the green mark to tidy up ANTENNA CABLE.



- C** When reuse the LCD COVER:
Please paste new PANEL ADHESIVE *2pcs.
(New LCD COVER already contains PANEL ADHESIVE *2pcs)

