

ASUSTek Computer Inc.

# ASUS API Programming Guide

Manual Rev.: 1.00

Revision Date: 2021/10/08



# Revision History

| Revision | Date       | Change          |
|----------|------------|-----------------|
| 1.00     | 2021/10/08 | Initial release |
|          |            |                 |
|          |            |                 |
|          |            |                 |
|          |            |                 |
|          |            |                 |



# Table of Contents

|                                       |    |
|---------------------------------------|----|
| Revision History.....                 | 1  |
| Table of Contents .....               | 2  |
| 1 Introduction.....                   | 5  |
| 1.1 File Description.....             | 5  |
| 1.2 ASUS API Supported Functions..... | 6  |
| 1.3 Supported OS .....                | 8  |
| 2 Function Documentation .....        | 8  |
| 2.1 Initailization Functions.....     | 8  |
| 2.1.1 EApiLibInitialize .....         | 8  |
| 2.1.2 EApiLibUnInitialize .....       | 8  |
| 2.2 EAPI Information Functions .....  | 9  |
| 2.2.1 EApiBoardGetStringA.....        | 9  |
| 2.2.2 EApiBoardGetValue .....         | 10 |
| 2.2.3 AsusBoardSetValue.....          | 12 |
| 2.3 GPIO Functions .....              | 13 |
| 2.3.1 EApiGPIOGetDirectionCaps.....   | 13 |
| 2.3.2 EApiGPIOGetDirection .....      | 14 |
| 2.3.3 EApiGPIOSetDirection.....       | 15 |
| 2.3.4 EApiGPIOGetLevel .....          | 16 |
| 2.3.5 EApiGPIOSetLevel .....          | 17 |
| 2.4 Watchdog.....                     | 18 |
| 2.4.1 EApiWDogGetCap.....             | 18 |
| 2.4.2 EApiWDogStart.....              | 19 |
| 2.4.3 AsusWDogStartWdtService.....    | 20 |



|        |  |    |
|--------|--|----|
| 2.4.4  | EApiWDogTrigger .....                    | 21 |
| 2.4.5  | EApiWDogStop .....                       | 21 |
| 2.5    | Power Scheduling .....                   | 22 |
| 2.5.1  | AsusSystemBootSet .....                  | 22 |
| 2.5.2  | AsusSystemBootGet .....                  | 24 |
| 2.6    | Functions for the I2C Bus .....          | 26 |
| 2.6.1  | EApil2CGetBusCap .....                   | 26 |
| 2.6.2  | EApil2CWriteReadRaw .....                | 27 |
| 2.6.3  | EApil2CReadTransfer .....                | 29 |
| 2.6.4  | EApil2CWriteTransfer .....               | 30 |
| 2.6.5  | EApil2CProbeDevice .....                 | 31 |
| 2.7    | Connectivity Management.....             | 32 |
| 2.7.1  | AsusConnMgrModemGetNumberofModems.....   | 32 |
| 2.7.2  | AsusConnMgrModemGetModemInfo .....       | 33 |
| 2.7.3  | AsusConnMgrModemStartNetwork .....       | 34 |
| 2.7.4  | AsusConnMgrModemStopNetwork .....        | 35 |
| 2.7.5  | AsusConnMgrModemPowerOn .....            | 36 |
| 2.7.6  | AsusConnMgrModemPowerOff .....           | 36 |
| 2.7.7  | AsusConnMgrModemRestart.....             | 37 |
| 2.7.8  | AsusConnMgrModemGetKeepAliveStatus ..... | 38 |
| 2.7.9  | AsusConnMgrModemSetKeepAlive.....        | 38 |
| 2.7.10 | AsusConnMgrModemGetStatus.....           | 39 |
| 2.7.11 | AsusConnMgrModemGetAttachedStatus.....   | 44 |
| 2.7.12 | AsusConnMgrModemSwitchSIM.....           | 47 |
| 2.7.13 | AsusConnMgrModemUnlockSIMByPIN .....     | 48 |
| 2.7.14 | AsusConnMgrModemSetFlightMode .....      | 48 |
| 2.7.15 | AsusConnMgrModemSetAPN .....             | 49 |



|        |  |    |
|--------|--|----|
| 2.7.16 | AsusConnMgrModemSetUser .....              | 50 |
| 2.7.17 | AsusConnMgrModemSetPassword .....          | 51 |
| 2.7.18 | AsusConnMgrModemSetIPType.....             | 51 |
| 2.7.19 | AsusConnMgrModemGetProfile .....           | 52 |
| 2.7.20 | AsusConnMgrModemResetProfile .....         | 54 |
| 2.7.21 | AsusConnMgrModemSwitchCarrier .....        | 55 |
| 2.7.22 | AsusConnMgrModemCheckCarrier .....         | 56 |
| 2.7.23 | AsusConnMgrModemGetICCID.....              | 59 |
| 2.7.24 | AsusConnMgrModemGetIMSI .....              | 60 |
| 2.7.25 | AsusConnMgrModemGetSignalStrength.....     | 61 |
| 2.7.26 | AsusConnMgrModemGetAdvancedSignalInfo..... | 61 |
| 2.7.27 | AsusConnMgrModemGetCellLocationInfo .....  | 64 |
| 2.7.28 | AsusConnMgrSetFailover .....               | 66 |
| 2.7.29 | AsusConnMgrGetFailoverStatus.....          | 67 |
| 2.7.30 | AsusConnMgrSetFailoverGroup .....          | 68 |
| 2.7.31 | AsusConnMgrGetFailoverGroup .....          | 69 |
| 2.8    | LED Control.....                           | 70 |
| 2.8.1  | AsusLedGetInfo .....                       | 70 |
| 2.8.2  | AsusLedGetNumberofLeds.....                | 72 |
| 2.8.3  | AsusLedTurnOn .....                        | 72 |
| 2.8.4  | AsusLedTurnOff .....                       | 73 |
| 2.8.5  | AsusLedSetSystemOccupied .....             | 74 |



# 1 Introduction

ASUS API is a layer between hardware drivers and user applications. When a user application wants to access hardware resources (fan, watchdog, GPIO), it calls the ASUS API function and this function will use driver or system calls to perform the task.

Supported functions:

- Obtaining general information about the system
- System monitoring: thermal, voltage, fan, etc.
- Watchdog, GPIO control
- Power scheduling
- Connectivity management

ASUS API is compatible with EAPI specification and goes a step further to offer additional features. ASUS API is released in the form of the dynamic-link library, so it can be easily used by an arbitrary application developed in C++, C# or higher programming languages. To use ASUS API, application developers only have to add the ASUS API library to their project.

## 1.1 File Description

To use the ASUS API, copy the following files to your application folder. We provide the sample code of how to use the API library, facilitating the development of your programs.

The provided files are:

| Linux:                                    |   |
|---|---|
| output\root\install_asus_library.sh       | The shell script to install the library files, the header files, and the binary files to the environment of the ASUS device product |
| output\root\usr\lib\libasusapi.so         | Shared object library   |
| output\root\usr\lib\libasusapi.a          | Archive library   |
| output\root\usr\include\asusapi\asusapi.h | Header file   |
| output\root\usr\bin\asusapiapp            | Sample application  |
| output\root\examples\dynamic\asusapiapp.c | Code of sample application  |



## 1.2 ASUS API Supported Functions

| ASUS API Functions                   | PE100A         |  |
|--------------------------------------|----------------|--|
| EApiBoardGetStringA                  |                |  |
| EAPI_ID_BOARD_MANUFACTURER_STR       | V              |  |
| EAPI_ID_BOARD_NAME_STR               | V              |  |
| EAPI_ID_BOARD_REVISION_STR           | V              |  |
| EAPI_ID_BOARD_SERIAL_STR             |                |  |
| EAPI_ID_BOARD_BIOS_REVISION_STR      |                |  |
| EAPI_ID_BOARD_HW_REVISION_STR        | V              |  |
| EAPI_ID_BOARD_PLATFORM_TYPE_STR      |                |  |
| EApiBoardGetValue                    |                |  |
| EAPI_ID_GET_EAPI_SPEC_VERSION        | V              |  |
| EAPI_ID_BOARD_BOOT_COUNTER_VAL       |                |  |
| EAPI_ID_BOARD_RUNNING_TIME_METER_VAL |                |  |
| EAPI_ID_BOARD_PNPID_VAL              | V              |  |
| EAPI_ID_BOARD_PLATFORM_REV_VAL       |                |  |
| EAPI_ID_BOARD_DRIVER_VERSION_VAL     |                |  |
| EAPI_ID_BOARD_LIB_VERSION_VAL        | V              |  |
| EAPI_ID_HWMON_CPU_TEMP               |                |  |
| EAPI_ID_HWMON_CHIPSET_TEMP           |                |  |
| EAPI_ID_HWMON_SYSTEM_TEMP            |                |  |
| EAPI_ID_HWMON_VOLTAGE_VCORE          |                |  |
| EAPI_ID_HWMON_VOLTAGE_2V5            |                |  |
| EAPI_ID_HWMON_VOLTAGE_3V3            |                |  |
| EAPI_ID_HWMON_VOLTAGE_VBAT           |                |  |
| EAPI_ID_HWMON_VOLTAGE_5V             |                |  |
| EAPI_ID_HWMON_VOLTAGE_5VSB           |                |  |
| EAPI_ID_HWMON_VOLTAGE_12V            |                |  |
| EAPI_ID_HWMON_FAN_CPU                |                |  |
| EAPI_ID_HWMON_FAN_SYSTEM             |                |  |
| ASUS_ID_HWMON_VOLTAGE_VTT            |                |  |
| ASUS_ID_HWMON_VOLTAGE_DGIN           |                |  |
| ASUS_ID_HWMON_CURRENT_SYSTEM         |                |  |
| AsusBoardSetValue                    |                |  |
| EApiI2CGetBusCap                     |                |  |
| EApiI2CWriteReadRaw                  |                |  |
| EApiI2CReadTransfer                  |                |  |
| EApiI2CWriteTransfer                 |                |  |
| EApiI2CProbeDevice                   |                |  |
| EApiWDogGetCap                       | V              |  |
| EApiWDogStart                        | V              |  |
| EApiWDogTrigger                      | V              |  |
| EApiWDogStop                         | V              |  |
| AsusWDogStartWdtService              |                |  |
| EApiGPIOGetDirectionCaps             | V              |  |
| EApiGPIOGetDirection                 | V              |  |
| EApiGPIOSetDirection                 | V              |  |
| EApiGPIOGetLevel                     | V              |  |
| EApiGPIOSetLevel                     | V              |  |
| AsusSystemBootSet                    |                |  |
| AsusSystemBootGet                    |                |  |
| AsusLedTurnOn                        |                |  |
| AsusLedTurnOff                       |                |  |
| AsusLedGetNumberOfLeds               |                |  |
| AsusLedGetInfo                       |                |  |
| AsusLedSetSystemOccupied             |                |  |
| AsusConnMgrModemGetNumberOfModems    | V <sub>1</sub> |  |
| AsusConnMgrModemGetModemInfo         | V <sub>1</sub> |  |
| AsusConnMgrModemStartNetwork         | V <sub>1</sub> |  |
| AsusConnMgrModemStopNetwork          | V <sub>1</sub> |  |
| AsusConnMgrModemPowerOn              | V <sub>1</sub> |  |



| ASUS API Functions                    | PE100A         |  |
|---------------------------------------|----------------|--|
| AsusConnMgrModemPowerOff              | V <sub>1</sub> |  |
| AsusConnMgrModemRestart               | V <sub>1</sub> |  |
| AsusConnMgrModemSwitchSIM             |                |  |
| AsusConnMgrModemGetAttachedStatus     | V <sub>1</sub> |  |
| AsusConnMgrModemGetStatus             | V <sub>1</sub> |  |
| AsusConnMgrModemUnlockSIMByPIN        | V <sub>1</sub> |  |
| AsusConnMgrModemSetFlightMode         | V <sub>1</sub> |  |
| AsusConnMgrModemSetAPN                | V <sub>1</sub> |  |
| AsusConnMgrModemSetUser               | V <sub>1</sub> |  |
| AsusConnMgrModemSetPassword           | V <sub>1</sub> |  |
| AsusConnMgrModemSetIPType             | V <sub>1</sub> |  |
| AsusConnMgrModemCheckCarrier          | V <sub>1</sub> |  |
| AsusConnMgrModemSwitchCarrier         | V <sub>1</sub> |  |
| AsusConnMgrModemGetICCID              | V <sub>1</sub> |  |
| AsusConnMgrModemGetIMSI               | V <sub>1</sub> |  |
| AsusConnMgrModemGetSignalStrength     | V <sub>1</sub> |  |
| AsusConnMgrModemGetAdvancedSignalInfo | V <sub>1</sub> |  |
| AsusConnMgrModemGetProfile            | V <sub>1</sub> |  |
| AsusConnMgrModemResetProfile          | V <sub>1</sub> |  |
| AsusConnMgrModemGetCellLocationInfo   | V <sub>1</sub> |  |
| AsusConnMgrModemSetKeepAlive          | V <sub>1</sub> |  |
| AsusConnMgrModemGetKeepAliveStatus    | V <sub>1</sub> |  |
| AsusConnMgrSetFailover                | V <sub>1</sub> |  |
| AsusConnMgrGetFailoverStatus          | V <sub>1</sub> |  |
| AsusConnMgrSetFailoverGroup           | V <sub>1</sub> |  |
| AsusConnMgrGetFailoverGroup           | V <sub>1</sub> |  |
|                                       |                |  |

Notes:

V<sub>1</sub> The support of the API depends on the modem module products. Please contact with the vendor for more information.



### 1.3 Supported OS

The following table contains supported Operation Systems for the ASUS products allowed to use ASUS API.

| ASUS Product | Operation System |
|--------------|------------------|
| PE100A       | Yocto 3.2        |

## 2 Function Documentation

### 2.1 Initialization Functions

#### 2.1.1 EApiLibInitialize

```
uint32_t  
EAPI_CALLTYPE  
EApiLibInitialize (void);
```

#### Description

Initialization of ASUS API. Prior to calling any ASUS API function, the library needs to be initialized by calling this function. The status code for all API function will be ASUS\_API\_STATUS\_NOT\_INITIALIZED unless this function is called.

#### Return Status Code

| Return Value                | Description  |
|-----------------------------|--|
| ASUS_API_STATUS_SUCCESS     | The operation was successful.                                  |
| ASUS_API_STATUS_ERROR       | Generic error message. No further error details are available. |
| ASUS_API_STATUS_INITIALIZED | Library initialized.   |

#### 2.1.2 EApiLibUnInitialize

```
uint32_t  
EAPI_CALLTYPE  
EApiLibUnInitialize (void);
```

#### Description

The function to uninitialized the API library. Should be called before program exit.



## Return Status Code

| Return Value                    | Description  |
|---------------------------------|--|
| ASUS_API_STATUS_SUCCESS         | The operation was successful.                                  |
| ASUS_API_STATUS_ERROR           | Generic error message. No further error details are available. |
| ASUS_API_STATUS_NOT_INITIALIZED | Library uninitialized.   |

## 2.2 EAPI Information Functions

### 2.2.1 EApiBoardGetStringA

```

uint32_t
EAPI_CALLTYPE
EApiBoardGetStringA (
    __IN      uint32_t Id,
    __OUT     char    *pBuffer,
    __INOUT   uint32_t *pBufLen);

```

#### Description

Text information about the hardware platform. Supports EAPI Id and ASUS Id.

#### Parameters

| In/Out  | Parameter Name | Description   |
|---------|----------------|---|
| __IN    | Id             | Selects the Get String Sub function Id (refer to the following EAPI Id Table and the ASUS Id Table)   |
| __OUT   | pBuffer        | Pointer to a buffer that receives the value's data  |
| __INOUT | pBufLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pBuffer parameter. When the function returns, this variable contains the size of the data copied to pBuffer including the terminating null character |

#### EAPI Id Table

| Id                             | Description             | Units/Format |
|--------------------------------|-------------------------|--------------|
| EAPI_ID_BOARD_MANUFACTURER_STR | Board Manufacturer Name | string       |
| EAPI_ID_BOARD_NAME_STR         | Board Name              | string       |
| EAPI_ID_BOARD_REVISION_STR     | Board Revision          | string       |
| EAPI_ID_BOARD_SERIAL_STR       | Board Serial Number     | string       |



|                                 |                     |        |
|---------------------------------|---------------------|--------|
| EAPI_ID_BOARD_BIOS_REVISION_STR | Board BIOS Revision | string |
| EAPI_ID_BOARD_HW_REVISION_STR   | Board HW Revision   | string |
| EAPI_ID_BOARD_PLATFORM_TYPE_STR | Board Platform Id   | string |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.  |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range.   |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_MORE_DATA         | The amount of available data exceeds the buffer size.<br>Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |

### 2.2.2 EApiBoardGetValue

```

uint32_t
EAPI_CALLTYPE
EApiBoardGetValue (
    __IN    uint32_t Id,
    __OUT   uint32_t *pValue);

```

#### Description

Information about the hardware platform in value format. Supports EAPI Id and ASUS Id.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Id             | Selects the Get Value Sub function Id (refer to the following EAPI Id Table and the ASUS Id Table) |
| __OUT  | pValue         | Pointer to a buffer that receives the value's data   |

#### EAPI Id Table



| Id                                   | Description                                      | Units/Format           |
|--------------------------------------|--|------------------------|
| EAPI_ID_GET_EAPI_SPEC_VERSION        | EAPI Specification Version used to implement API |                        |
| EAPI_ID_BOARD_BOOT_COUNTER_VAL       | Boot Counter                                     | Boots                  |
| EAPI_ID_BOARD_RUNNING_TIME_METER_VAL | Running Time Meter                               | Minutes                |
| EAPI_ID_BOARD_PNPID_VAL              | Board Vendor PNPID                               | Compressed ASCII PNPID |
| EAPI_ID_BOARD_PLATFORM_REV_VAL       | Platform Specification Version                   |                        |
| EAPI_ID_BOARD_DRIVER_VERSION_VAL     | Vendor Specific Driver Version                   |                        |
| EAPI_ID_BOARD_LIB_VERSION_VAL        | Vendor Specific Library Version                  |                        |
| EAPI_ID_HWMON_CPU_TEMP               | CPU Temperature                                  | 0.1 Kelvins            |
| EAPI_ID_HWMON_CHIPSET_TEMP           | Chipset Temperature                              | 0.1 Kelvins            |
| EAPI_ID_HWMON_SYSTEM_TEMP            | System Temperature                               | 0.1 Kelvins            |
| EAPI_ID_HWMON_VOLTAGE_VCORE          | CPU Core Voltage                                 | Millivolts             |
| EAPI_ID_HWMON_VOLTAGE_2V5            | 2.5V Voltage                                     | Millivolts             |
| EAPI_ID_HWMON_VOLTAGE_3V3            | 3.3V Voltage                                     | Millivolts             |
| EAPI_ID_HWMON_VOLTAGE_VBAT           | Battery Voltage                                  | Millivolts             |
| EAPI_ID_HWMON_VOLTAGE_5V             | 5V Voltage                                       | Millivolts             |
| EAPI_ID_HWMON_VOLTAGE_5VSB           | 5V Standby Voltage                               | Millivolts             |
| EAPI_ID_HWMON_VOLTAGE_12V            | 12V Voltage                                      | Millivolts             |
| EAPI_ID_HWMON_FAN_CPU                | CPU Fan  | RPM                    |
| EAPI_ID_HWMON_FAN_SYSTEM             | System Fan                                       | RPM                    |

### ASUS Id Table

| Id                           | Description    | Units/Format |
|------------------------------|----------------|--------------|
| ASUS_ID_HWMON_VOLTAGE_VTT    | VTT Voltage    | Millivolts   |
| ASUS_ID_HWMON_VOLTAGE_DCIN   | DC-IN Voltage  | Millivolts   |
| ASUS_ID_HWMON_CURRENT_SYSTEM | System Current | Milliamperes |

### Return Status Code

| Return Value            | Description                   |
|-------------------------|-------------------------------|
| ASUS_API_STATUS_SUCCESS | The operation was successful. |



|                                   |   |
|-----------------------------------|---|
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.2.3 AsusBoardSetValue

```
uint32_t
ASUS_CALLTYPE
AsusBoardSetValue (
    __IN      uint32_t Id,
    __IN      uint32_t Value);
```

#### Description

Sets the value of the system hardware component.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Id             | Selects the Id of the system hardware component (refer to the following EAPI Id Table and the ASUS Id Table) |
| __IN   | Value          | Sets the value of the selected system hardware component.  |

#### EAPI Id Table

| Id                       | Description | Units/Format |
|--------------------------|-------------|--------------|
| EAPI_ID_HWMON_FAN_CPU    | CPU Fan     | RPM          |
| EAPI_ID_HWMON_FAN_SYSTEM | System Fan  | RPM          |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |



|                            |                                       |
|----------------------------|---------------------------------------|
| AUS_API_STATUS_UNSUPPORTED | This function or Id is not supported. |
|----------------------------|---------------------------------------|

## 2.3 GPIO Functions

### 2.3.1 EApiGPIOGetDirectionCaps

```
uint32_t
EAPI_CALLTYPE
EApiGPIOGetDirectionCaps (
    __IN      uint32_t Id,
    __OUTPUT  uint32_t *pInputs,
    __OUTPUT  uint32_t *pOutputs);
```

#### Description

Reads the capabilities of the current GPIO implementation from the selected GPIO interface. The direction of this port can be configured by EApiGPIOSetDirection.

#### Parameters

| In/Out   | Parameter Name | Description   |
|----------|----------------|---|
| __IN     | Id             | GPIO Ids  |
| __OUTPUT | pInputs        | Pointer to a buffer that receives the bit mask of the supported inputs  |
| __OUTPUT | pOutputs       | Pointer to a buffer that receives the bit mask of the supported outputs |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |



### 2.3.2 EApiGPIOGetDirection

```
uint32_t
EAPI_CALLTYPE
EApiGPIOGetDirection (
    __IN      uint32_t Id,
    __IN      uint32_t Bitmask,
    __OUT     uint32_t *pDirection);
```

#### Description

Reads the current configuration of the selected GPIO ports.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Id             | GPIO Ids   |
| __IN   | Bitmask        | Bit mask. Only selected bits are returned. Unselected bits return 0  |
| __OUT  | pDirection     | Pointer to a buffer that receives the direction of the selected GPIO ports. Bits with the value EAPI_GPIO_INPUT are inputs, bits with EAPI_GPIO_OUTPUT are outputs |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_INVALID_BITMASK   | The bitmask selects bits/GPIOs which are not supported for the current Id.    |



### 2.3.3 EApiGPIOSetDirection

```

uint32_t
EAPI_CALLTYPE
EApiGPIOSetDirection (
    __IN      uint32_t Id,
    __IN      uint32_t Bitmask,
    __IN      uint32_t Direction);

```

#### Description

Sets the configuration for the selected GPIO ports.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Id             | GPIO Ids  |
| __IN   | Bitmask        | Bit mask. Only selected bits are changed. Unselected bits remain unchanged  |
| __IN   | Direction      | Sets the direction of the selected GPIO ports. Bits with the value EAPI_GPIO_INPUT are inputs, bits with EAPI_GPIO_OUTPUT are outputs |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                  |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range.   |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_INVALID_BITMASK   | The bitmask selects bits/GPIOs which are not supported for the current Id.      |
| ASUS_API_STATUS_INVALID_DIRECTION | The current direction argument attempts to set GPIOs to unsupported directions. |



### 2.3.4 EApiGPIOGetLevel

```
uint32_t
EAPI_CALLTYPE
EApiGPIOGetLevel (
    __IN      uint32_t Id,
    __IN      uint32_t Bitmask,
    __OUT     uint32_t *pLevel);
```

#### Description

Read the level from GPIO ports.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Id             | GPIO Ids   |
| __IN   | Bitmask        | Bit mask. Only selected bits are returned. Unselected bits return 0  |
| __OUT  | pLevel         | Pointer to a buffer that receives the level of the selected GPIO ports. Bits with the value EAPI_GPIO_HIGH are high levels, bits with EAPI_GPIO_LOW are low levels |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_INVALID_BITMASK   | The bitmask selects bits/GPIOs which are not supported for the current Id.    |



### 2.3.5 EApiGPIOSetLevel

```

uint32_t
EAPI_CALLTYPE
EApiGPIOSetLevel (
    __IN      uint32_t Id,
    __IN      uint32_t Bitmask,
    __IN      uint32_t Level);

```

#### Description

Write level to GPIO ports. Depending on the hardware implementation, writing multiple GPIO ports with the bit mask option does not guarantee a time synchronous change of the output levels.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Id             | GPIO Ids   |
| __IN   | Bitmask        | Bit mask. Only selected bits are changed. Unselected bits remain unchanged   |
| __IN   | Level          | Sets the levels of the selected GPIO ports. Bits with the value EAPI_GPIO_HIGH are high levels, bits with EAPI_GPIO_LOW are low levels |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_INVALID_BITMASK   | The bitmask selects bits/GPIOs which are not supported for the current Id.    |



## 2.4 Watchdog

### 2.4.1 EApiWDogGetCap

```

uint32_t
EAPI_CALLTYPE
EApiWDogGetCap (
    __OUTPUT uint32_t *pMaxDelay,
    __OUTPUT uint32_t *pMaxEventTimeout,
    __OUTPUT uint32_t *pMaxResetTimeout);

```

#### Description

Get the capabilities of the watchdog timer.

#### Parameters

| In/Out   | Parameter Name   | Description   |
|----------|------------------|---|
| __OUTPUT | pMaxDelay        | Pointer to a buffer that receives maximum supported initial delay time of the watchdog timer in milliseconds. If the value returns 0, it means not support event timeout. |
| __OUTPUT | pMaxEventTimeout | Pointer to a buffer that receives maximum supported event timeout of the watchdog timer in milliseconds. If the value returns 0, it means not support event timeout.      |
| __OUTPUT | pMaxResetTimeout | Pointer to a buffer that receives maximum supported reset timeout of the watchdog timer in milliseconds.  |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |



## 2.4.2 EApiWDogStart

```
uint32_t
EAPI_CALLTYPE
EApiWDogStart (
    __IN    uint32_t Delay,
    __IN    uint32_t EventTimeout,
    __IN    uint32_t ResetTimeout);
```

### Description

Start the watchdog timer and set the parameters. To adjust the parameters, the watchdog must be stopped via EApiWDogStop and then EApiWDogStart must be called again with the new values.

### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Delay          | Initial delay for the watchdog timer in milliseconds.          |
| __IN   | EventTimeout   | Watchdog timeout interval in milliseconds to trigger an event. |
| __IN   | ResetTimeout   | Watchdog timeout interval in milliseconds to trigger a reset.  |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_RUNNING           | Watchdog timer already started.   |



### 2.4.3 AsusWDogStartWdtService

```
uint32_t
ASUS_CALLTYPE
AsusWDogStartWdtService (
    __IN    uint32_t Delay,
    __IN    uint32_t ResetTimeout);
```

#### Description

Start the Watchdog Timer Service (the WDT Service) and set the parameters. To adjust the parameters, the WDT Service must be stopped via EApiWDogStop and then AsusWDogStartWdtService must be called again with the new values.

After the WDT Service has been started by the AsusWDogStartWdtService function, the WDT Service will automatically send the first trigger within (Delay + ResetTimeout) milliseconds as set with AsusWDogStartWdtService function, following the first trigger every subsequent trigger will be sent by the WDT Service within (ResetTimeout) milliseconds.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Delay          | Initial delay for the watchdog timer in milliseconds.         |
| __IN   | ResetTimeout   | Watchdog timeout interval in milliseconds to trigger a reset. |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_RUNNING           | Watchdog timer already started.   |



#### 2.4.4 EApiWDogTrigger

```
uint32_t  
EAPI_CALLTYPE  
EApiWDogTrigger (void);
```

##### Description

Trigger the watchdog timer.

##### Return Status Code

| Return Value                    | Description  |
|---------------------------------|--|
| ASUS_API_STATUS_SUCCESS         | The operation was successful.                                  |
| ASUS_API_STATUS_ERROR           | Generic error message. No further error details are available. |
| ASUS_API_STATUS_NOT_INITIALIZED | Library uninitialized.   |
| ASUS_API_STATUS_UNSUPPORTED     | This function or Id is not supported.                          |

#### 2.4.5 EApiWDogStop

```
uint32_t  
EAPI_CALLTYPE  
EApiWDogStop (void);
```

##### Description

Stops the operation of the watchdog timer.

The Watchdog Timer Service (the WDT Service) will be stopped as well if the WDT Service is running.

##### Return Status Code

| Return Value                    | Description  |
|---------------------------------|--|
| ASUS_API_STATUS_SUCCESS         | The operation was successful.                                  |
| ASUS_API_STATUS_ERROR           | Generic error message. No further error details are available. |
| ASUS_API_STATUS_NOT_INITIALIZED | Library uninitialized.   |
| ASUS_API_STATUS_UNSUPPORTED     | This function or Id is not supported.                          |



## 2.5 Power Scheduling

### 2.5.1 AsusSystemBootSet

```

uint32_t
ASUS_CALLTYPE
AsusSystemBootSet (
    __IN    uint32_t Id,
    __IN    uint32_t Frequency,
    __IN    uint32_t DayofMonth,
    __IN    uint32_t DayofWeek,
    __IN    uint32_t Hour,
    __IN    uint32_t Minute,
    __IN    uint32_t Second,
);

```

#### Description

Power Scheduling provides the boot up, shutdown, restart, and sleep function for the system state management.

Be able to set Id for the action of Power Scheduling, such as boot up, shutdown, restart, sleep, etc., and be able to schedule the frequency, which can be daily, weekly, monthly, or one shot, on that action.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Id             | Selects Power Scheduling function Id (refer to the following ASUS Power Scheduling Id Table)      |
| __IN   | Frequency      | Selects Power Scheduling Frequency (refer to the following ASUS Power Scheduling Frequency Table) |
| __IN   | DayofMonth     | Selects the day of month, such as 1, 2, ..., 30, and 31.  |
| __IN   | DayofWeek      | Selects the day of week (refer to the following ASUS DayofWeek Table)                             |
| __IN   | Hour           | Selects the hour, such as 0, 1, ..., 22, and 23.  |
| __IN   | Minute         | Selects the minute, such as 0, 1, ..., 58, and 59.  |
| __IN   | Second         | Selects the second, such as 0, 1, ..., 58, and 59.  |

#### ASUS Power Scheduling Id Table

| Id                         | Description                                     |
|----------------------------|---|
| ASUS_ID_SYSTEM_BOOT_BOOTUP | Boot up or wake up function. Boot up or wake up |



|                              |   |
|------------------------------|---|
|                              | the system.                             |
| ASUS_ID_SYSTEM_BOOT_SHUTDOWN | Shutdown function. Shutdown the system. |
| ASUS_ID_SYSTEM_BOOT_SLEEP    | Sleep function. Sleep the system.       |
| ASUS_ID_SYSTEM_BOOT_RESTART  | Restart function. Restart the system.   |

### ASUS Power Scheduling Frequency Table

| Id   | Description   |
|--|---|
| ASUS_SYSTEM_BOOT_DISABLE_FREQUENCY         | Disable the selected function. The arguments DayofMonth, DayofWeek, Hour, Minute, and Second are useless. |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_DAILY    | The selected function will action daily. The arguments DayofMonth, DayofWeek are useless.                 |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_WEEKLY   | The selected function will action weekly. The argument DayofMonth is useless.                             |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_MONTHLY  | The selected function will action monthly. The argument DayofWeek is useless.                             |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_ONE_SHOT | The selected function will action one shot. The arguments DayofMonth, DayofWeek are useless.              |

### ASUS Power Scheduling Frequency Table

| Id                                |
|-----------------------------------|
| ASUS_SYSTEM_BOOT_WEEKLY_SUNDAY    |
| ASUS_SYSTEM_BOOT_WEEKLY_MONDAY    |
| ASUS_SYSTEM_BOOT_WEEKLY_TUESDAY   |
| ASUS_SYSTEM_BOOT_WEEKLY_WEDNESDAY |
| ASUS_SYSTEM_BOOT_WEEKLY_THURSDAY  |
| ASUS_SYSTEM_BOOT_WEEKLY_FRIDAY    |
| ASUS_SYSTEM_BOOT_WEEKLY_SATURDAY  |

### Return Status Code



| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.5.2 AsusSystemBootGet

```

uint32_t
ASUS_CALLTYPE
AsusSystemBootGet (
    __IN    uint32_t Id,
    __OUT   uint32_t *pFrequency,
    __OUT   uint32_t *pDayofMonth,
    __OUT   uint32_t *pDayofWeek,
    __OUT   uint32_t *pHour,
    __OUT   uint32_t *pMinute,
    __OUT   uint32_t *pSecond,
);

```

#### Description

Reads the frequency and the configuration of the Power Scheduling function from the selected function Id.

The frequency and the configuration of the Power Scheduling function can be set by the AsusSystemBootSet().

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Id             | Selects Power Scheduling function Id (refer to the following ASUS Power Scheduling Id Table)   |
| __OUT  | pFrequency     | Pointer to a buffer that receives the frequency of the selected function Id (refer to the following ASUS Power Scheduling Frequency Table) |
| __OUT  | pDayofMonth    | Pointer to a buffer that receives the day of month of the selected function Id   |



|       |            |   |
|-------|------------|---|
| __OUT | pDayofWeek | Pointer to a buffer that receives the day of week of the selected function Id |
| __OUT | pHour      | Pointer to a buffer that receives the hour of the selected function Id        |
| __OUT | pMinute    | Pointer to a buffer that receives the minute of the selected function Id      |
| __OUT | pSecond    | Pointer to a buffer that receives the second of the selected function Id      |

#### ASUS Power Scheduling Id Table

| Id                           | Description                  |
|------------------------------|------------------------------|
| ASUS_ID_SYSTEM_BOOT_BOOTUP   | Boot up or wake up function. |
| ASUS_ID_SYSTEM_BOOT_SHUTDOWN | Shutdown function.           |
| ASUS_ID_SYSTEM_BOOT_SLEEP    | Sleep function.              |
| ASUS_ID_SYSTEM_BOOT_RESTART  | Restart function.            |

#### ASUS Power Scheduling Frequency Table

| Id   | Description   |
|--|---|
| ASUS_SYSTEM_BOOT_DISABLE_FREQUENCY         | The selected function is disabled. The arguments DayofMonth, DayofWeek, Hour, Minute, and Second are useless. |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_DAILY    | The selected function actions daily. The arguments DayofMonth, DayofWeek are useless.                         |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_WEEKLY   | The selected function actions weekly. The argument DayofMonth is useless.                                     |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_MONTHLY  | The selected function actions monthly. The argument DayofWeek is useless.                                     |
| ASUS_SYSTEM_BOOT_ENABLE_FREQUENCY_ONE_SHOT | The selected function actions one shot. The arguments DayofMonth, DayofWeek are useless.                      |

#### ASUS Power Scheduling Frequency Table

| Id |
|----|
|----|



|                                   |
|-----------------------------------|
| ASUS_SYSTEM_BOOT_WEEKLY_SUNDAY    |
| ASUS_SYSTEM_BOOT_WEEKLY_MONDAY    |
| ASUS_SYSTEM_BOOT_WEEKLY_TUESDAY   |
| ASUS_SYSTEM_BOOT_WEEKLY_WEDNESDAY |
| ASUS_SYSTEM_BOOT_WEEKLY_THURSDAY  |
| ASUS_SYSTEM_BOOT_WEEKLY_FRIDAY    |
| ASUS_SYSTEM_BOOT_WEEKLY_SATURDAY  |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

## 2.6 Functions for the I2C Bus

### 2.6.1 EApiI2CGetBusCap

```

uint32_t
EAPI_CALLTYPE
EApiI2CGetBusCap (
    __IN      uint32_t Id,
    __OUTPUT  uint32_t *pMaxBlkLen);

```

#### Description

Gets the capabilities of the selected I2C bus.

#### Parameters

| In/Out   | Parameter Name | Description   |
|----------|----------------|---|
| __IN     | Id             | I2C bus Id  |
| __OUTPUT | pMaxBlkLen     | Size in bytes. Pointer to a buffer that receives the maximum transfer block length for the given interface. |



## Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.6.2 EApiI2CWriteReadRaw

```

uint32_t
EAPI_CALLTYPE
EApiI2CWriteReadRaw (
    __IN      uint32_t Id,
    __IN      uint8_t  Addr,
    __INOPT   void     *pWBuffer,
    __IN      uint32_t WriteBCnt,
    __OUTOPT  void     *pRBuffer,
    __IN      uint32_t RBufLen,
    __IN      uint32_t ReadBCnt);

```

#### Description

Universal function for read and write operations to the I2C bus.

#### Parameters

| In/Out   | Parameter Name | Description  |
|----------|----------------|--|
| __IN     | Id             | I2C bus Id   |
| __IN     | Addr           | Encoded 7Bit I2C Device Address. It can be derived by the macro for address encoding: EAPI_I2C_ENC_7BIT_ADDR()                 |
| __INOPT  | pWBuffer       | Pointer to a buffer containing the data to be transferred. This parameter can be NULL if the data is not required.             |
| __IN     | WriteBCnt      | Size, in bytes, of the information pointed to by the pWBuffer parameter plus 1. If pWBuffer is NULL, this must be zero or one. |
| __OUTOPT | pRBuffer       | Pointerr to a buffer that receives the read data. This parameter can be NULL if the data is not required.                      |



|      |          |   |
|------|----------|---|
| __IN | RBufLen  | Size, in bytes, of the buffer pointed to by the pRBuffer parameter. If the buffer specified by pRBuffer parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. If pRBuffer is NILL, this must be zero. |
| __IN | ReadBCnt | Size, in bytes, to be read to pRBuffer plus 1. If pRBuffer is NULL, this must be zero or one.   |

### Return Status Code

| Return Value                         | Description  |
|--------------------------------------|--|
| ASUS_API_STATUS_SUCCESS              | The operation was successful.  |
| ASUS_API_STATUS_ERROR                | Generic error message. No further error details are available.   |
| ASUS_API_STATUS_NOT_INITIALIZED      | Library uninitialized.   |
| ASUS_API_STATUS_INVALID_PARAMETER    | One or more of the API function call parameters are out of the defined range.  |
| ASUS_API_STATUS_UNSUPPORTED          | This function or Id is not supported.  |
| ASUS_API_STATUS_INVALID_BLOCK_LENGTH | This means that the block length is too long.  |
| ASUS_API_STATUS_BUSY_COLLISION       | The selected device or Id is busy or a data collision was detected.  |
| ASUS_API_STATUS_NOT_FOUND            | Selected device was not found.   |
| ASUS_API_STATUS_WRITE_ERROR          | An error was detected during a write operation.  |
| ASUS_API_STATUS_MORE_DATA            | The amount of available data exceeds the buffer size.<br>Storage buffer overflow was prevented.<br>Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_TIMEOUT              | Timeout due to clock stretching  |



### 2.6.3 EApiI2CReadTransfer

```
uint32_t
EAPI_CALLTYPE
EApiI2CReadTransfer (
    __IN      uint32_t Id,
    __IN      uint32_t Addr,
    __IN      uint32_t Cmd,
    __OUT     void    *pBuffer,
    __IN      uint32_t BufLen,
    __IN      uint32_t ByteCnt);
```

#### Description

Reads from a specific register in the selected I2C device.

Reads from I2C device at the I2C address Addr the amount of ByteCnt bytes to the buffer pBuffer while using the device specific command Cmd. Depending on the addressed I2C device, Cmd can be a specific command or a byte offset.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Id             | I2C bus Id  |
| __IN   | Addr           | Encoded 7Bit I2C Device Address. It can be derived by the macro for address encoding: EAPI_I2C_ENC_7BIT_ADDR()  |
| __IN   | Cmd            | I2C command/offset  |
| __OUT  | pBuffer        | Pointerr to a buffer that receives the read data. This parameter can be NULL if the data is not required.   |
| __IN   | BufLen         | Size, in bytes, of the buffer pointed to by the pBuffer parameter. If the buffer specified by pBuffer parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |
| __IN   | ByteCnt        | Size, in bytes, of data to be read  |

#### Return Status Code

| Return Value                    | Description  |
|---------------------------------|--|
| ASUS_API_STATUS_SUCCESS         | The operation was successful.                                  |
| ASUS_API_STATUS_ERROR           | Generic error message. No further error details are available. |
| ASUS_API_STATUS_NOT_INITIALIZED | Library uninitialized.   |



|                                      |  |
|--------------------------------------|--|
| ASUS_API_STATUS_INVALID_PARAMETER    | One or more of the API function call parameters are out of the defined range.  |
| ASUS_API_STATUS_UNSUPPORTED          | This function or Id is not supported.  |
| ASUS_API_STATUS_INVALID_BLOCK_LENGTH | This means that the block length is too long.  |
| ASUS_API_STATUS_BUSY_COLLISION       | The selected device or Id is busy or a data collision was detected.  |
| ASUS_API_STATUS_NOT_FOUND            | Selected device was not found.   |
| ASUS_API_STATUS_WRITE_ERROR          | An error was detected during a write operation.  |
| ASUS_API_STATUS_MORE_DATA            | The amount of available data exceeds the buffer size.<br>Storage buffer overflow was prevented.<br>Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_TIMEOUT              | Timeout due to clock stretching  |

#### 2.6.4 EAPl2CWriteTransfer

```

uint32_t
EAPI_CALLTYPE
EAPl2CWriteTransfer (
    __IN    uint32_t Id,
    __IN    uint32_t Addr,
    __IN    uint32_t Cmd,
    __IN    void    *pBuffer,
    __IN    uint32_t ByteCnt);

```

#### Description

Write to a specific register in the selected I2C device.

Write to an I2C device at the I2C address Addr the amount of ByteCnt bytes from the buffer \*pBuffer while using the device specific command Cmd. Depending on the addressed I2C device, Cmd can be a specific command or a byte offset.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Id             | I2C bus Id  |
| __IN   | Addr           | Encoded 7Bit I2C Device Address. It can be derived by the macro for |



|      |         |  |
|------|---------|--|
|      |         | address encoding: EAPI_I2C_ENC_7BIT_ADDR()                             |
| __IN | Cmd     | I2C command/offset   |
| __IN | pBuffer | Pointerr to a buffer containing the data to be transferred.            |
| __IN | ByteCnt | Size, in bytes, of the information pointed to by the pBuffer parameter |

### Return Status Code

| Return Value                         | Description  |
|--------------------------------------|--|
| ASUS_API_STATUS_SUCCESS              | The operation was successful.  |
| ASUS_API_STATUS_ERROR                | Generic error message. No further error details are available.   |
| ASUS_API_STATUS_NOT_INITIALIZED      | Library uninitialized.   |
| ASUS_API_STATUS_INVALID_PARAMETER    | One or more of the API function call parameters are out of the defined range.  |
| ASUS_API_STATUS_UNSUPPORTED          | This function or Id is not supported.  |
| ASUS_API_STATUS_INVALID_BLOCK_LENGTH | This means that the block length is too long.  |
| ASUS_API_STATUS_BUSY_COLLISION       | The selected device or Id is busy or a data collision was detected.  |
| ASUS_API_STATUS_NOT_FOUND            | Selected device was not found.   |
| ASUS_API_STATUS_WRITE_ERROR          | An error was detected during a write operation.  |
| ASUS_API_STATUS_MORE_DATA            | The amount of available data exceeds the buffer size.<br>Storage buffer overflow was prevented.<br>Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_TIMEOUT              | Timeout due to clock stretching  |

### 2.6.5 EApiI2CProbeDevice

```

uint32_t
EAPI_CALLTYPE
EApiI2CProbeDevice (
    __IN    uint32_t Id,
    __IN    uint32_t Addr);

```

### Description



Probes I2C address to test I2C device present.

### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Id             | I2C bus Id   |
| __IN   | Addr           | Encoded 7Bit I2C Device Address. It can be derived by the macro for address encoding: EAPI_I2C_ENC_7BIT_ADDR() |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_BUSY_COLLISION    | The selected device or Id is busy or a data collision was detected.           |
| ASUS_API_STATUS_NOT_FOUND         | Selected device was not found.  |
| ASUS_API_STATUS_TIMEOUT           | Timeout due to clock stretching   |

## 2.7 Connectivity Management

### 2.7.1 AsusConnMgrModemGetNumberofModems

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetNumberofModems (
    __OUT uint32_t *pValue);
```

### Description

Get the number of the modems.

### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __OUT  | pValue         | Pointer to a variable that specifies the number of the modems. |



## Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.2 AsusConnMgrModemGetModemInfo

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetModemInfo (
    __OUT    struct ConnMgrModemInfo_s *pModemList,
    __INOUT  uint32_t *pModemCnt);

```

#### Description

Gets the information of the modems.

#### Parameters

| In/Out  | Parameter Name | Description   |
|---------|----------------|---|
| __OUT   | pModemList     | An array of the structures that receives the information of the modems (refer to the following structure: ConnMgrModemInfo_s).  |
| __INOUT | pModemCnt      | Pointer to a variable that specifies the number of the ConnMgrModemInfo_s structures pointed to by the pModemList parameter. When the function returns, this variable contains the number of the modems.<br>If the buffer specified by pModemList parameter is not large enough to hold the number of the modems, the function returns the value ASUS_API_STATUS_MORE_DATA. |

#### Structure of ConnMgrModemInfo\_s



| Parameter Type   | Parameter Name   | Description                           |
|--|------------------|---------------------------------------|
| char   | Index            | The index of the modem                |
| char[]<br>(The array size is defined by<br>MAX_CHAR_LENGTH_MODEM_INFO) | Path             | The path of the modem                 |
| char[]<br>(The array size is defined by<br>MAX_CHAR_LENGTH_MODEM_INFO) | Manufacturer     | The manufacturer of the modem         |
| char[]<br>(The array size is defined by<br>MAX_CHAR_LENGTH_MODEM_INFO) | ModemName        | The modem name                        |
| char[]<br>(The array size is defined by<br>MAX_CHAR_LENGTH_MODEM_INFO) | FirmwareRevision | The firmware revision of the<br>modem |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.  |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range.   |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_MORE_DATA         | The amount of available data exceeds the buffer size.<br>Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |

### 2.7.3 AsusConnMgrModemStartNetwork

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemStartNetwork (__IN uint32_t Index);
```

#### Description

Start the network connectivity.



### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

#### 2.7.4 AsusConnMgrModemStopNetwork

```
uint32_t  
ASUS_CALLTYPE  
AsusConnMgrModemStopNetwork (__IN uint32_t Index);
```

### Description

Stop the network connectivity.

### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |

### Return Status Code

| Return Value                    | Description  |
|---------------------------------|--|
| ASUS_API_STATUS_SUCCESS         | The operation was successful.                                  |
| ASUS_API_STATUS_ERROR           | Generic error message. No further error details are available. |
| ASUS_API_STATUS_NOT_INITIALIZED | Library uninitialized.   |



|                                   |   |
|-----------------------------------|---|
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.5 AsusConnMgrModemPowerOn

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemPowerOn (__IN uint32_t Index);
```

#### Description

Power on the modem.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.6 AsusConnMgrModemPowerOff

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemPowerOff (__IN uint32_t Index);
```

#### Description

Power off the modem.



### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

#### 2.7.7 AsusConnMgrModemRestart

```
uint32_t  
ASUS_CALLTYPE  
AsusConnMgrModemRestart (__IN uint32_t Index);
```

### Description

Power off and power on the modem.

### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |

### Return Status Code

| Return Value                    | Description  |
|---------------------------------|--|
| ASUS_API_STATUS_SUCCESS         | The operation was successful.                                  |
| ASUS_API_STATUS_ERROR           | Generic error message. No further error details are available. |
| ASUS_API_STATUS_NOT_INITIALIZED | Library uninitialized.   |



|                                   |   |
|-----------------------------------|---|
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.8 AsusConnMgrModemGetKeepAliveStatus

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetKeepAliveStatus (
    __OUT    uint32_t *pStatus);
```

#### Description

Get the status of the keep alive feature.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __OUT  | pStatus        | Pointer to a variable that receives the value's data. The value with ASUS_CMM_KEEP_ALIVE_ON means the keep alive feature is on. The value with ASUS_CMM_KEEP_ALIVE_OFF means the keep alive feature is off. |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.9 AsusConnMgrModemSetKeepAlive

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSetKeepAlive (__IN uint32_t Enable);
```



## Description

Allow to enable or disable the keep alive feature.

## Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Enable         | The value with ASUS_CMM_KEEP_ALIVE_ON means to turn on the keep alive feature. The value with ASUS_CMM_KEEP_ALIVE_OFF means to turn off. |

## Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.10 AsusConnMgrModemGetStatus

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetStatus (
    __IN    uint32_t Index,
    __OUT   struct ConnMgrModemStatus_s *pStatus);

```

## Description

Get the status of the network connection and the information of IP.

## Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |



|       |         |   |
|-------|---------|---|
| __OUT | pStatus | Pointer to a structure that receives the status of the network connection and the information of IP (refer to the following structure: ConnMgrModemStatus_s). |
|-------|---------|---|

### Structure of ConnMgrModemStatus\_s

| In/Out Parameter Type | Parameter Name | Description   |
|-----------------------|----------------|---|
| __OUT char *          | pConnected     | Pointer to a variable that specifies the status of the network connection. The variable might be the string “yes” or the string “no”.   |
| __INOUT uint32_t *    | pConnectedLen  | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pConnected parameter. When the function returns, this variable contains the size of the data copied to pConnected including the terminating null character.<br>If the buffer specified by pConnected parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code> . |
| __OUT char *          | pInterface     | Pointer to a buffer that receives the interface name.   |
| __INOUT uint32_t *    | pInterfaceLen  | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pInterface parameter. When the function returns, this variable contains the size of the data copied to pInterface including the terminating null character.<br>If the buffer specified by pInterface parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code> . |
| __OUT char *          | pApn           | Pointer to a buffer that receives the APN name.   |
| __INOUT uint32_t *    | pApnLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pApn parameter. When the function returns, this variable contains the size of the data copied to pApn including the terminating null character.<br>If the buffer specified by pApn parameter is not large enough to hold the data, the function returns the value  |



|  |             |   |
|--|-------------|---|
|  |             | ASUS_API_STATUS_MORE_DATA.  |
| __OUT char *                               | pRoaming    | Pointer to a variable that specifies the status of the roaming. The variable might be the string “allowed” or the string “forbidden”.   |
| __INOUT uint32_t *                         | pRoamingLen | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pRoaming parameter. When the function returns, this variable contains the size of the data copied to pRoaming including the terminating null character.<br>If the buffer specified by pRoaming parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |
| __OUT struct<br>ConnMgrModemIpv4Status_s * | pIpv4Status | Pointer to a structure that receives the information of IPv4 (refer to the following structure: ConnMgrModemIpv4Status_s).  |
| __OUT struct<br>ConnMgrModemIpv6Status_s * | pIpv6Status | Pointer to a structure that receives the information of IPv6 (refer to the following structure: ConnMgrModemIpv6Status_s).  |

### Structure of ConnMgrModemIpv4Status\_s

| In/Out Parameter Type | Parameter Name | Description   |
|-----------------------|----------------|---|
| __OUT char *          | pAddress       | Pointer to a buffer that receives the IP address.   |
| __INOUT uint32_t *    | pAddressLen    | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pAddress parameter. When the function returns, this variable contains the size of the data copied to pAddress including the terminating null character.<br>This variable will be zero if the IP address is invalid.<br>If the buffer specified by pAddress parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |
| __OUT char *          | pGateway       | Pointer to a buffer that receives the gateway address.  |
| __INOUT uint32_t *    | pGatewayLen    | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pGateway parameter. When the function returns, this variable contains the size of the data copied to pGateway including the terminating null character.<br>This variable will be zero if the gateway address is  |



|                    |         |  |
|--------------------|---------|--|
|                    |         | invalid.<br>If the buffer specified by pGateway parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA.  |
| __OUT char *       | pMtu    | Pointer to a buffer that receives the MTU.   |
| __INOUT uint32_t * | pMtuLen | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pMtu parameter. When the function returns, this variable contains the size of the data copied to pMtu including the terminating null character.<br>This variable will be zero if the MTU is invalid.<br>If the buffer specified by pMtu parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA.         |
| __OUT char *       | pDns    | Pointer to a buffer that receives the DNS address.   |
| __INOUT uint32_t * | pDnsLen | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pDns parameter. When the function returns, this variable contains the size of the data copied to pDns including the terminating null character.<br>This variable will be zero if the DNS address is invalid.<br>If the buffer specified by pDns parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |

### Structure of ConnMgrModemIpv6Status\_s

| In/Out Parameter Type | Parameter Name | Description   |
|-----------------------|----------------|---|
| __OUT char *          | pAddress       | Pointer to a buffer that receives the IP address.   |
| __INOUT uint32_t *    | pAddressLen    | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pAddress parameter. When the function returns, this variable contains the size of the data copied to pAddress including the terminating null character.<br>This variable will be zero if the IP address is invalid.<br>If the buffer specified by pAddress parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |
| __OUT char *          | pGateway       | Pointer to a buffer that receives the gateway address.  |
| __INOUT uint32_t *    | pGatewayLen    | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pGateway parameter.  |

|                                 |                      |  |
|---------------------------------|----------------------|--|
|                                 |                      | <p>When the function returns, this variable contains the size of the data copied to pGateway including the terminating null character.</p> <p>This variable will be zero if the gateway address is invalid.</p> <p>If the buffer specified by pGateway parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code>.</p>  |
| <code>__OUT char *</code>       | <code>pMtu</code>    | Pointer to a buffer that receives the MTU.   |
| <code>__INOUT uint32_t *</code> | <code>pMtuLen</code> | <p>Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the <code>pMtu</code> parameter.</p> <p>When the function returns, this variable contains the size of the data copied to <code>pMtu</code> including the terminating null character.</p> <p>This variable will be zero if the MTU is invalid.</p> <p>If the buffer specified by <code>pMtu</code> parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code>.</p>         |
| <code>__OUT char *</code>       | <code>pDns</code>    | Pointer to a buffer that receives the DNS address.   |
| <code>__INOUT uint32_t *</code> | <code>pDnsLen</code> | <p>Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the <code>pDns</code> parameter.</p> <p>When the function returns, this variable contains the size of the data copied to <code>pDns</code> including the terminating null character.</p> <p>This variable will be zero if the DNS address is invalid.</p> <p>If the buffer specified by <code>pDns</code> parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code>.</p> |

### Return Status Code

| Return Value                                   | Description  |
|--|--|
| <code>ASUS_API_STATUS_SUCCESS</code>           | The operation was successful.  |
| <code>ASUS_API_STATUS_ERROR</code>             | Generic error message. No further error details are available.                               |
| <code>ASUS_API_STATUS_NOT_INITIALIZED</code>   | Library uninitialized.   |
| <code>ASUS_API_STATUS_INVALID_PARAMETER</code> | One or more of the API function call parameters are out of the defined range.                |
| <code>ASUS_API_STATUS_MORE_DATA</code>         | The amount of available data exceeds the buffer size. Storage buffer overflow was prevented. |



|                             |   |
|-----------------------------|---|
|                             | Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_UNSUPPORTED | This function or Id is not supported.                 |

### 2.7.11 AsusConnMgrModemGetAttachedStatus

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetAttachedStatus (
    __IN    uint32_t Index,
    __OUT   struct ConnMgrModemAttachedStatus_s *pStatus);

```

#### Description

Get the attached status of the modem, including the state of the modem and the access technology that the modem uses when registered with or connected to a network.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo ().                     |
| __OUT  | pStatus        | Pointer to a structure that receives the attached status of the modem (refer to the following structure: ConnMgrModemAttachedStatus_s). |

#### Structure of ConnMgrModemAttachedStatus\_s

| Parameter Type                      | Parameter Name    | Description   |
|-------------------------------------|-------------------|---|
| enum<br>ASUS_CMM_REGISTRATION_STATE | RegistrationState | Refer to the following enum:<br>ASUS_CMM_REGISTRATION_STATE |
| enum<br>ASUS_CMM_RADIO_INTERFACE    | RadioInterface    | Refer to the following enum:<br>ASUS_CMM_RADIO_INTERFACE    |
| enum<br>ASUS_CMM_FLIGHT_MODE_STATE  | FlightModeState   | Refer to the following enum:<br>ASUS_CMM_FLIGHT_MODE_STATE  |



### Enum of ASUS\_CMM\_REGISTRATION\_STATE

| Parameter                   | Description  |
|-----------------------------|--|
| CMMODEM_STATE_FAILED        | The modem is unusable.   |
| CMMODEM_STATE_UNKNOWN       | State unknown or not reportable.   |
| CMMODEM_STATE_INITIALIZING  | The modem is currently being initialized.  |
| CMMODEM_STATE_LOCKED        | The modem needs to be unlocked.  |
| CMMODEM_STATE_DISABLED      | The modem is not enabled and is powered down.  |
| CMMODEM_STATE_DISABLING     | The modem is currently transitioning to the MM_MODEM_STATE_DISABLED state.   |
| CMMODEM_STATE_ENABLING      | The modem is currently transitioning to the MM_MODEM_STATE_ENABLED state.  |
| CMMODEM_STATE_ENABLED       | The modem is enabled and powered on but not registered with a network provider and not available for data connections.   |
| CMMODEM_STATE_SEARCHING     | The modem is searching for a network provider to register with.  |
| CMMODEM_STATE_REGISTERED    | The modem is registered with a network provider, and data connections and messaging may be available for use.  |
| CMMODEM_STATE_DISCONNECTING | The modem is disconnecting and deactivating the last active packet data bearer. This state will not be entered if more than one packet data bearer is active and one of the active bearers is deactivated. |
| CMMODEM_STATE_CONNECTING    | The modem is activating and connecting the first packet data bearer. Subsequent bearer activations when another bearer is already active do not cause this state to be entered.                            |
| CMMODEM_STATE_CONNECTED     | One or more packet data bearers is active and connected.   |

### Enum of ASUS\_CMM\_RADIO\_INTERFACE

| Parameter                         | Description                            |
|-----------------------------------|--|
| CMMODEM_ACCESS_TECHNOLOGY_UNKNOWN | The access technology used is unknown. |
| CMMODEM_ACCESS_TECHNOLOGY_POTS    | Analog wireline telephone.             |
| CMMODEM_ACCESS_TECHNOLOGY_GSM     | GSM.                                   |
| CMMODEM_ACCESS_TECHNOLOGY_        | Compact GSM.                           |



|                                     |  |
|-------------------------------------|--|
| GSM_COMPACT                         |  |
| CMMODEM_ACCESS_TECHNOLOGY_GPRS      | GPRS.  |
| CMMODEM_ACCESS_TECHNOLOGY_EDGE      | EDGE (ETSI 27.007: "GSM w/EGPRS").             |
| CMMODEM_ACCESS_TECHNOLOGY_UMTS      | UMTS (ETSI 27.007: "UTRAN").                   |
| CMMODEM_ACCESS_TECHNOLOGY_HSDPA     | HSDPA (ETSI 27.007: "UTRAN w/HSDPA").          |
| CMMODEM_ACCESS_TECHNOLOGY_HSUPA     | HSUPA (ETSI 27.007: "UTRAN w/HSUPA").          |
| CMMODEM_ACCESS_TECHNOLOGY_HSPA      | HSPA (ETSI 27.007: "UTRAN w/HSDPA and HSUPA"). |
| CMMODEM_ACCESS_TECHNOLOGY_HSPA_PLUS | HSPA+ (ETSI 27.007: "UTRAN w/HSPA+").          |
| CMMODEM_ACCESS_TECHNOLOGY_1XRTT     | CDMA2000 1xRTT.                                |
| CMMODEM_ACCESS_TECHNOLOGY_EVDO0     | CDMA2000 EVDO revision 0.                      |
| CMMODEM_ACCESS_TECHNOLOGY_EVDOA     | CDMA2000 EVDO revision A.                      |
| CMMODEM_ACCESS_TECHNOLOGY_EVDOB     | CDMA2000 EVDO revision B.                      |
| CMMODEM_ACCESS_TECHNOLOGY_LTE       | LTE (ETSI 27.007: "E-UTRAN")                   |
| CMMODEM_ACCESS_TECHNOLOGY_5GNR      | 5GNR (ETSI 27.007: "NG-RAN"). Since 1.14.      |
| CMMODEM_ACCESS_TECHNOLOGY_ANY       | Mask specifying all access technologies.       |

#### Enum of ASUS\_CMM\_FLIGHT\_MODE\_STATE

| Parameter                | Description             |
|--------------------------|-------------------------|
| ASUS_CMM_FLIGHT_MODE_OFF | The flight mode is off. |
| ASUS_CMM_FLIGHT_MODE_ON  | The flight mode is on.  |

#### Return Status Code

| Return Value            | Description                                     |
|-------------------------|---|
| ASUS_API_STATUS_SUCCESS | The operation was successful.                   |
| ASUS_API_STATUS_ERROR   | Generic error message. No further error details |



|                                   |   |
|-----------------------------------|---|
|                                   | are available.  |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.12 AsusConnMgrModemSwitchSIM

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSwitchSIM (
    __IN      uint32_t Index,
    __IN      uint32_t SimSlotId);

```

#### Description

Switch the SIM.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |
| __IN   | SimSlotId      | SIM slot Ids (refer to the following ASUS SIM Slot Id Table)  |

#### ASUS SIM Slot Id Table

| Id                  | Description | Value |
|---------------------|-------------|-------|
| ASUS_CMM_SIM_SLOT_0 | SIM Slot 0  | 0     |
| ASUS_CMM_SIM_SLOT_1 | SIM Slot 1  | 1     |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |



|                             |                                       |
|-----------------------------|---------------------------------------|
| ASUS_API_STATUS_UNSUPPORTED | This function or Id is not supported. |
|-----------------------------|---------------------------------------|

### 2.7.13 AsusConnMgrModemUnlockSIMByPIN

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemUnlockSIMByPIN (
    __IN    uint32_t Index,
    __IN    char *pPinCode);

```

#### Description

Unlock the SIM by PIN code.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |
| __IN   | pPinCode       | Pointer to a buffer containing the PIN code to be transferred.  |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.14 AsusConnMgrModemSetFlightMode

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSetFlightMode (
    __IN    uint32_t Index,
    __IN    enum ASUS_CMM_FLIGHT_MODE_STATE FlightMode);

```

#### Description



Turn on or turn off the flight mode.

### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: <code>AsusConnMgrModemGetModemInfo ()</code> .  |
| __IN   | FlightMode     | Refer to the following enum:<br><b>ASUS_CMM_FLIGHT_MODE_STATE</b><br>The value with <code>ASUS_CMM_FLIGHT_MODE_ON</code> means to turn on the flight mode. The value with <code>ASUS_CMM_FLIGHT_MODE_OFF</code> means to turn off. |

### Enum of ASUS\_CMM\_FLIGHT\_MODE\_STATE

| Parameter                             | Description             |
|---------------------------------------|-------------------------|
| <code>ASUS_CMM_FLIGHT_MODE_OFF</code> | The flight mode is off. |
| <code>ASUS_CMM_FLIGHT_MODE_ON</code>  | The flight mode is on.  |

### Return Status Code

| Return Value                                   | Description   |
|--|---|
| <code>ASUS_API_STATUS_SUCCESS</code>           | The operation was successful.   |
| <code>ASUS_API_STATUS_ERROR</code>             | Generic error message. No further error details are available.                |
| <code>ASUS_API_STATUS_NOT_INITIALIZED</code>   | Library uninitialized.  |
| <code>ASUS_API_STATUS_INVALID_PARAMETER</code> | One or more of the API function call parameters are out of the defined range. |
| <code>ASUS_API_STATUS_UNSUPPORTED</code>       | This function or Id is not supported.   |

### 2.7.15 AsusConnMgrModemSetAPN

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSetAPN (
    __IN      char *pApn);
  
```

### Description

Set the APN to the profile.



### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | pApn           | Pointer to a buffer containing the APN to be transferred. |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.16 AsusConnMgrModemSetUser

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSetUser (
    __IN      char *pUser);

```

### Description

Set the user name to the profile.

### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | pUser          | Pointer to a buffer containing the user name to be transferred. |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |



|                             |                                       |
|-----------------------------|---------------------------------------|
| ASUS_API_STATUS_UNSUPPORTED | This function or Id is not supported. |
|-----------------------------|---------------------------------------|

### 2.7.17 AsusConnMgrModemSetPassword

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSetPassword (
    __IN      char *pPassword);
```

#### Description

Set the password to the profile.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | pPassword      | Pointer to a buffer containing the password to be transferred. |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.18 AsusConnMgrModemSetIPType

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSetIPType (
    __IN      uint32_t IpType);
```

#### Description

Set the IP type to the profile.

#### Parameters



| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | IpType         | The IP type (refer to the following ASUS IP Type Table) |

### ASUS IP Type Table

| Id                      | Description      | Value |
|-------------------------|------------------|-------|
| ASUS_CMM_IP_TYPE_IPV4   | IPv4 method      | 0     |
| ASUS_CMM_IP_TYPE_IPV6   | IPv6 method      | 1     |
| ASUS_CMM_IP_TYPE_IPV4V6 | IPv4/IPv6 method | 2     |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.19 AsusConnMgrModemGetProfile

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetProfile (
    __OUT    struct ConnMgrModemProfile_s *pProfile);

```

#### Description

Get the information of the profile.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __OUT  | pProfile       | Pointer to a structure that receives the information of the profile (refer to the following structure: ConnMgrModemProfile_s). |

#### Structure of ConnMgrModemProfile\_s

| In/Out Parameter Type | Parameter Name | Description  |
|-----------------------|----------------|--|
| __OUT char *          | pApn           | Pointer to a buffer that receives the APN name of the profile.   |
| __INOUT uint32_t *    | pApnLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pApn parameter. When the function returns, this variable contains the size of the data copied to pApn including the terminating null character.<br>If the buffer specified by pApn parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA.                      |
| __OUT char *          | pUser          | Pointer to a buffer that receives the user name of the profile.  |
| __INOUT uint32_t *    | pUserLen       | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pUser parameter. When the function returns, this variable contains the size of the data copied to pUser including the terminating null character.<br>If the buffer specified by pUser parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA.                   |
| __OUT char *          | pPassword      | Pointer to a buffer that receives the password of the profile.   |
| __INOUT uint32_t *    | pPasswordLen   | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pPassword parameter. When the function returns, this variable contains the size of the data copied to pPassword including the terminating null character.<br>If the buffer specified by pPassword parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA.       |
| __OUT char *          | pIpv4Method    | Pointer to a buffer that receives the IPv4 configuration method which supports "disabled", "auto", "manual", and "link-local".   |
| __INOUT uint32_t *    | pIpv4MethodLen | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pIpv4Method parameter. When the function returns, this variable contains the size of the data copied to pIpv4Method including the terminating null character.<br>If the buffer specified by pIpv4Method parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |



|                    |                |  |
|--------------------|----------------|--|
| __OUT char *       | pIpv6Method    | Pointer to a buffer that receives the IPv6 configuration method which supports "disabled", "auto", "manual", and "link-local".   |
| __INOUT uint32_t * | pIpv6MethodLen | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pIpv6Method parameter. When the function returns, this variable contains the size of the data copied to pIpv6Method including the terminating null character.<br>If the buffer specified by pIpv6Method parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |

### Return Status Code

| Return Value                      | Description  |
|-----------------------------------|--|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.  |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.   |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.   |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range.  |
| ASUS_API_STATUS_MORE_DATA         | The amount of available data exceeds the buffer size. Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.  |

### 2.7.20 AsusConnMgrModemResetProfile

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrModemResetProfile ();
```

#### Description

Set the profile to the default value.

### Return Status Code

| Return Value            | Description                   |
|-------------------------|-------------------------------|
| ASUS_API_STATUS_SUCCESS | The operation was successful. |



|                                 |  |
|---------------------------------|--|
| ASUS_API_STATUS_ERROR           | Generic error message. No further error details are available. |
| ASUS_API_STATUS_NOT_INITIALIZED | Library uninitialized.   |
| ASUS_API_STATUS_UNSUPPORTED     | This function or Id is not supported.                          |

### 2.7.21 AsusConnMgrModemSwitchCarrier

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemSwitchCarrier (
    __IN    uint32_t Index,
    __IN    struct ConnMgrModemCarrierMcc_s *pMcc
    __IN    struct ConnMgrModemCarrierMnc_s *pMnc);

```

#### Description

Switch to the carrier network with the input of the carrier name.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo ().        |
| __IN   | pMcc           | Pointer to a structure containing the data to be transferred (refer to the following structure: ConnMgrModemCarrierMcc_s). |
| __IN   | pMnc           | Pointer to a structure containing the data to be transferred (refer to the following structure: ConnMgrModemCarrierMnc_s). |

#### Structure of ConnMgrModemCarrierMcc\_s

| In/Out Parameter Type | Parameter Name | Description  |
|-----------------------|----------------|--|
| __IN char *           | pMcc           | Pointer to a buffer containing the MCC to be transferred.  |
| __IN uint32_t *       | pMccLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pMcc parameter. |



### Structure of ConnMgrModemCarrierMnc\_s

| In/Out Parameter Type | Parameter Name | Description  |
|-----------------------|----------------|--|
| __IN char *           | pMnc           | Pointer to a buffer containing the MNC to be transferred.  |
| __IN uint32_t *       | pMncLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pMnc parameter. |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.22 AsusConnMgrModemCheckCarrier

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemCheckCarrier (
    __IN    uint32_t Index,
    __OUT   struct ConnMgrModemCarrierInfo_s *pCarrierInfo);

```

### Description

Get the information of the carrier including MCC, MNC, and the name of the carrier.

### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |



|       |              |  |
|-------|--------------|--|
| __OUT | pCarrierInfo | Pointer to a structure that receives the information of the carrier (refer to the following structure: ConnMgrModemCarrierInfo_s). |
|-------|--------------|--|

### Structure of ConnMgrModemCarrierInfo\_s

| In/Out Parameter Type                       | Parameter Name | Description   |
|---|----------------|---|
| __OUT struct<br>ConnMgrModemCarrierMcc_s *  | pMcc           | Pointer to a structure that receives MCC (refer to the following structure: ConnMgrModemCarrierMcc_s).                      |
| __OUT struct<br>ConnMgrModemCarrierMnc_s *  | pMnc           | Pointer to a structure that receives MNC (refer to the following structure: ConnMgrModemCarrierMnc_s).                      |
| __OUT struct<br>ConnMgrModemCarrierName_s * | pName          | Pointer to a structure that receives the name of the carrier (refer to the following structure: ConnMgrModemCarrierName_s). |

### Structure of ConnMgrModemCarrierMcc\_s

| In/Out Parameter Type | Parameter Name | Description   |
|-----------------------|----------------|---|
| __OUT char *          | pMcc           | Pointer to a buffer that receives MCC.  |
| __INOUT uint32_t *    | pMccLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pMcc parameter. When the function returns, this variable contains the size of the data copied to pMcc including the terminating null character.<br>If the buffer specified by pMcc parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |

### Structure of ConnMgrModemCarrierMnc\_s

| In/Out Parameter Type | Parameter Name | Description  |
|-----------------------|----------------|--|
| __OUT char *          | pMnc           | Pointer to a buffer that receives MNC.   |
| __INOUT uint32_t *    | pMncLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pMnc parameter. When the function returns, this variable contains the size of the data copied to pMnc including the terminating null character. |



|  |  |   |
|--|--|---|
|  |  | If the buffer specified by pMnc parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code> . |
|--|--|---|

### Structure of ConnMgrModemCarrierName\_s

| In/Out Parameter Type           | Parameter Name                | Description   |
|---------------------------------|-------------------------------|---|
| <code>__OUT char *</code>       | <code>pOperatorName</code>    | Pointer to a buffer that receives the name of the carrier.  |
| <code>__INOUT uint32_t *</code> | <code>pOperatorNameLen</code> | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the <code>pOperatorName</code> parameter. When the function returns, this variable contains the size of the data copied to <code>pOperatorName</code> including the terminating null character.<br>If the buffer specified by <code>pOperatorName</code> parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code> . |

### Return Status Code

| Return Value                                   | Description  |
|--|--|
| <code>ASUS_API_STATUS_SUCCESS</code>           | The operation was successful.  |
| <code>ASUS_API_STATUS_ERROR</code>             | Generic error message. No further error details are available.   |
| <code>ASUS_API_STATUS_NOT_INITIALIZED</code>   | Library uninitialized.   |
| <code>ASUS_API_STATUS_INVALID_PARAMETER</code> | One or more of the API function call parameters are out of the defined range.  |
| <code>ASUS_API_STATUS_MORE_DATA</code>         | The amount of available data exceeds the buffer size. Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |
| <code>ASUS_API_STATUS_UNSUPPORTED</code>       | This function or Id is not supported.  |



### 2.7.23 AsusConnMgrModemGetICCID

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetICCID (
    __IN      uint32_t Index,
    __OUT     char *pBuffer,
    __INOUT   uint32_t *pBufLen);

```

#### Description

Get the Integrate Circuit Card Identity.

#### Parameters

| In/Out  | Parameter Name | Description  |
|---------|----------------|--|
| __IN    | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo ().  |
| __OUT   | pBuffer        | Pointer to a buffer that receives the value's data.  |
| __INOUT | pBufLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pBuffer parameter. When the function returns, this variable contains the size of the data copied to pBuffer including the terminating null character.<br>If the buffer specified by pBuffer parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |

#### Return Status Code

| Return Value                      | Description  |
|-----------------------------------|--|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.  |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.   |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.   |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range.  |
| ASUS_API_STATUS_MORE_DATA         | The amount of available data exceeds the buffer size. Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.  |



## 2.7.24 AsusConnMgrModemGetIMSI

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetIMSI (
    __IN        uint32_t Index,
    __OUT       char *pBuffer,
    __INOUT     uint32_t *pBufLen);

```

### Description

Get the International Mobile Subscriber Identity.

### Parameters

| In/Out  | Parameter Name | Description  |
|---------|----------------|--|
| __IN    | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo ().  |
| __OUT   | pBuffer        | Pointer to a buffer that receives the value's data.  |
| __INOUT | pBufLen        | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pBuffer parameter. When the function returns, this variable contains the size of the data copied to pBuffer including the terminating null character.<br>If the buffer specified by pBuffer parameter is not large enough to hold the data, the function returns the value ASUS_API_STATUS_MORE_DATA. |

### Return Status Code

| Return Value                      | Description  |
|-----------------------------------|--|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.  |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.   |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.   |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range.  |
| ASUS_API_STATUS_MORE_DATA         | The amount of available data exceeds the buffer size. Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.  |



### 2.7.25 AsusConnMgrModemGetSignalStrength

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetSignalStrength (
    __IN        uint32_t Index,
    __OUT        uint32_t *pValue);

```

#### Description

Get the percentage of the signal strength.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo (). |
| __OUT  | pValue         | Pointer to a variable that receives the value's data.   |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.26 AsusConnMgrModemGetAdvancedSignalInfo

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetAdvancedSignalInfo (
    __IN        uint32_t Index,
    __OUT        struct ConnMgrModemAdvSignalInfo_s *pAdvSignalInfo);

```

#### Description

Get the signal strength of the different measurement.

## Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: <code>AsusConnMgrModemGetModemInfo ()</code> .                                    |
| __OUT  | pAdvSignalInfo | Pointer to a structure that receives the signal strength of the different measurement (refer to the following structure: <code>ConnMgrModemAdvSignalInfo_s</code> ). |

## Structure of ConnMgrModemAdvSignalInfo\_s

| Parameter Type                      | Parameter Name | Description  |
|-------------------------------------|----------------|--|
| struct ConnMgrModemEvdoSignalInfo_s | Evdo           | A structure that describes the signal strength of the different measurement of EVDO technology (refer to the following structure: <code>ConnMgrModemEvdoSignalInfo_s</code> ). |
| struct ConnMgrModemGsmSignalInfo_s  | Gsm            | A structure that describes the signal strength of the different measurement of GSM technology (refer to the following structure: <code>ConnMgrModemGsmSignalInfo_s</code> ).   |
| struct ConnMgrModemUmtsSignalInfo_s | Umts           | A structure that describes the signal strength of the different measurement of UMTS technology (refer to the following structure: <code>ConnMgrModemUmtsSignalInfo_s</code> ). |
| struct ConnMgrModemLteSignalInfo_s  | Lte            | A structure that describes the signal strength of the different measurement of LTE technology (refer to the following structure: <code>ConnMgrModemLteSignalInfo_s</code> ).   |

## Structure of ConnMgrModemEvdoSignalInfo\_s

| Parameter Type | Parameter Name | Description   |
|----------------|----------------|---|
| float          | rssi           | The CDMA EV-DO RSSI (Received Signal Strength Indication), in dBm, given as a floating point value. |
| float          | ecio           | The CDMA EV-DO Ec/Io, in dBm, given as a floating point value.                                      |



|          |           |  |
|----------|-----------|--|
| float    | sinr      | CDMA EV-DO SINR level, in dB, given as a floating point value.   |
| float    | io        | The CDMA EV-DO Io, in dBm, given as a floating point value.  |
| uint32_t | validFlag | Used to specify that the specific signal strength is valid or not.<br>RSSI mapped to Bit 0. Ec/Io mapped to Bit 1. SINR mapped to Bit 3. Io mapped to Bit 4. |

#### Structure of ConnMgrModemGsmSignalInfo\_s

| Parameter Type | Parameter Name | Description  |
|----------------|----------------|--|
| float          | rssi           | The GSM RSSI (Received Signal Strength Indication), in dBm, given as a floating point value. |
| uint32_t       | validFlag      | Used to specify that the specific signal strength is valid or not.<br>RSSI mapped to Bit 0.  |

#### Structure of ConnMgrModemUmtsSignalInfo\_s

| Parameter Type | Parameter Name | Description  |
|----------------|----------------|--|
| float          | rssi           | The UMTS RSSI (Received Signal Strength Indication), in dBm, given as a floating point value.  |
| float          | rscp           | The UMTS RSCP (Received Signal Code Power), in dBm, given as a floating point value.   |
| float          | ecio           | The UMTS Ec/Io, in dB, given as a floating point value.  |
| uint32_t       | validFlag      | Used to specify that the specific signal strength is valid or not.<br>RSSI mapped to Bit 0. RSCP mapped to Bit 1. Ec/Io mapped to Bit 3. |

#### Structure of ConnMgrModemLteSignalInfo\_s

| Parameter Type | Parameter Name | Description  |
|----------------|----------------|--|
| float          | rssi           | The LTE RSSI (Received Signal Strength Indication), in dBm, given as a floating point value. |
| float          | rsrq           | The LTE RSRQ (Reference Signal Received Quality), in dB, given as a floating point value.    |
| float          | rsrp           | The LTE RSRP (Reference Signal Received Power), in dBm, given as a floating point value.     |



|          |           |  |
|----------|-----------|--|
| float    | snr       | The LTE S/R ratio, in dB, given as a floating point value.   |
| uint32_t | validFlag | Used to specify that the specific signal strength is valid or not.<br>RSSI mapped to Bit 0. RSRQ mapped to Bit 1. RSRP mapped to Bit 3. S/R ratio mapped to Bit 4. |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.27 AsusConnMgrModemGetCellLocationInfo

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrModemGetCellLocationInfo (
    __IN    uint32_t Index,
    __OUT   struct ConnMgrModemCellLocationInfo_s *pCellLocInfo);

```

#### Description

Get the information of the cell location.

#### Parameters

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __IN   | Index          | A variable that specifies the index of the modem that can be derived from the API: AsusConnMgrModemGetModemInfo ().                           |
| __OUT  | pCellLocInfo   | Pointer to a structure that receives the information of the cell location (refer to the following structure: ConnMgrModemCellLocationInfo_s). |

#### Structure of ConnMgrModemCellLocationInfo\_s

| In/Out | Parameter Type | Parameter Name | Description |
|--------|----------------|----------------|-------------|
|--------|----------------|----------------|-------------|

|                    |                      |  |
|--------------------|----------------------|--|
| __OUT char *       | pOperatorCode        | Pointer to a buffer that receives the operator code.   |
| __INOUT uint32_t * | pOperatorCodeLen     | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pOperatorCode parameter. When the function returns, this variable contains the size of the data copied to pOperatorCode including the terminating null character.<br>If the buffer specified by pOperatorCode parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code> .             |
| __OUT char *       | pOperatorName        | Pointer to a buffer that receives the operator name.   |
| __INOUT uint32_t * | pOperatorNameLen     | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pOperatorName parameter. When the function returns, this variable contains the size of the data copied to pOperatorName including the terminating null character.<br>If the buffer specified by pOperatorName parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code> .             |
| __OUT char *       | pLocationAreaCode    | Pointer to a buffer that receives the location area code.  |
| __INOUT uint32_t * | pLocationAreaCodeLen | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pLocationAreaCode parameter. When the function returns, this variable contains the size of the data copied to pLocationAreaCode including the terminating null character.<br>If the buffer specified by pLocationAreaCode parameter is not large enough to hold the data, the function returns the value <code>ASUS_API_STATUS_MORE_DATA</code> . |
| __OUT char *       | pTrackingAreaCode    | Pointer to a buffer that receives the tracking area code.  |
| __INOUT uint32_t * | pTrackingAreaCodeLen | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pTrackingAreaCode parameter. When the function returns, this variable contains the size   |



|                                 |                         |   |
|---------------------------------|-------------------------|---|
|                                 |                         | of the data copied to pTrackingAreaCode including the terminating null character. If the buffer specified by pTrackingAreaCode parameter is not large enough to hold the data, the function returns the value <b>ASUS_API_STATUS_MORE_DATA</b> .  |
| <code>__OUT char *</code>       | <code>pCellId</code>    | Pointer to a buffer that receives the cell Id.  |
| <code>__INOUT uint32_t *</code> | <code>pCellIdLen</code> | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pCellId parameter. When the function returns, this variable contains the size of the data copied to pCellId including the terminating null character. If the buffer specified by pCellId parameter is not large enough to hold the data, the function returns the value <b>ASUS_API_STATUS_MORE_DATA</b> . |

### Return Status Code

| Return Value                                   | Description  |
|--|--|
| <code>ASUS_API_STATUS_SUCCESS</code>           | The operation was successful.  |
| <code>ASUS_API_STATUS_ERROR</code>             | Generic error message. No further error details are available.   |
| <code>ASUS_API_STATUS_NOT_INITIALIZED</code>   | Library uninitialized.   |
| <code>ASUS_API_STATUS_INVALID_PARAMETER</code> | One or more of the API function call parameters are out of the defined range.  |
| <code>ASUS_API_STATUS_MORE_DATA</code>         | The amount of available data exceeds the buffer size. Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |
| <code>ASUS_API_STATUS_UNSUPPORTED</code>       | This function or Id is not supported.  |

### 2.7.28 AsusConnMgrSetFailover

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrSetFailover (
    __IN    uint32_t Enable);
```

#### Description



Allow to enable or disable the failover feature.

**Parameters**

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | Enable         | The value with ASUS_CM_FAILOVER_ON means to turn on the failover feature. The value with ASUS_CM_FAILOVER_OFF means to turn off. |

**Return Status Code**

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

**2.7.29 AsusConnMgrGetFailoverStatus**

```
uint32_t
ASUS_CALLTYPE
AsusConnMgrGetFailoverStatus (
    __OUT    uint32_t *pStatus);
```

**Description**

Get the status of the failover feature.

**Parameters**

| In/Out | Parameter Name | Description   |
|--------|----------------|---|
| __OUT  | pStatus        | Pointer to a variable that receives the value's data. The value with ASUS_CM_FAILOVER_ON means the failover feature is on. The value with ASUS_CM_FAILOVER_OFF means the failover feature is off. |

**Return Status Code**

| Return Value | Description |
|--------------|-------------|
|--------------|-------------|



|                                   |   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.7.30 AsusConnMgrSetFailoverGroup

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrSetFailoverGroup (
    __IN      char **pInterface,
    __IN      uint32_t InterfaceCnt);

```

#### Description

Set the failover group on the failover feature to determine the priority of the network interface.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __IN   | pInterface     | Pointer to a buffer containing the list of the network interface name to be transferred. |
| __IN   | InterfaceCnt   | The number of the network interfaces in the group.                                       |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |



### 2.7.31 AsusConnMgrGetFailoverGroup

```

uint32_t
ASUS_CALLTYPE
AsusConnMgrGetFailoverGroup (
    __OUT    char **pInterface,
    __INOUT  uint32_t *ByteCntOfRow,
    __IN     uint32_t ByteCntOfColumn);

```

#### Description

Get the failover group of the failover feature. The output of this function is the list of the network interface name.

#### Parameters

| In/Out  | Parameter Name  | Description   |
|---------|-----------------|---|
| __OUT   | pInterface      | Pointer to a buffer that receives the list of the network interface name.   |
| __INOUT | ByteCntOfRow    | Pointer to a variable that specifies the size, in bytes, of the buffer pointed to by the pInterface parameter. When the function returns, this variable contains the number of the network interfaces.<br>This variable will be zero if there is no group set on the failover feature.<br>If the buffer specified by pInterface parameter is not large enough to hold the number of the network interfaces, the function returns the value ASUS_API_STATUS_MORE_DATA. |
| __IN    | ByteCntOfColumn | The column size, in bytes, of the buffer pointed to by the pInterface parameter.<br>If ByteCntOfColumn parameter is not large enough to hold the size, in bytes, of the return interface name, the function returns the value ASUS_API_STATUS_MORE_DATA.  |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |



|                             |  |
|-----------------------------|--|
| ASUS_API_STATUS_MORE_DATA   | The amount of available data exceeds the buffer size. Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |
| ASUS_API_STATUS_UNSUPPORTED | This function or Id is not supported.  |

## 2.8 LED Control

### 2.8.1 AsusLedGetInfo

```

uint32_t
ASUS_CALLTYPE
AsusLedGetInfo (
    __OUT    struct LedInfo_s *pLedInfo,
    __INOUT  uint32_t *pLedCnt);

```

#### Description

Gets the information of the LEDs.

#### Parameters

| In/Out  | Parameter Name | Description  |
|---------|----------------|--|
| __OUT   | pLedInfo       | An array of the structures that receives the information of the LEDs (refer to the following structure: LedInfo_s).  |
| __INOUT | pLedCnt        | Pointer to a variable that specifies the number of the LedInfo_s structures pointed to by the pLedInfo parameter. When the function returns, this variable contains the number of the LEDs. This variable will be zero if there is no LED support. If the buffer specified by pLedInfo parameter is not large enough to hold the number of the LEDs, the function returns the value ASUS_API_STATUS_MORE_DATA. |

#### Structure of LedInfo\_s

| Parameter Type | Parameter Name | Description  |
|----------------|----------------|--|
| uint32_t       | LedId          | LED Id   |
| uint32_t       | SupportedColor | Used to specify that the specific color is supported or not by this LED. For instance, Bit 0 corresponds to “Color Blue”, and Bit 1 to |



|          |                |  |
|----------|----------------|--|
|          |                | “Color Green”. If Bit 0 is set, the LED is able to light up blue. Refer to the following LED Color Table for the detailed color assignment.  |
| uint32_t | SystemOccupied | Used to specify whether this LED is occupied by the system or not. The value with LED_OCCUPIED_BY_SYSTEM means the LED is only controlled by the system. The value with LED_OCCUPIED_BY_USER means users or applications have the permission to control the LED. |

### LED Color Table

| Id                    | Value      | Description  |
|-----------------------|------------|--|
| LED_LIGHT_COLOR_BLUE  | 0x00000001 | “Color Blue” mapped to Bit 0 of the SupportedColor parameter.  |
| LED_LIGHT_COLOR_GREEN | 0x00000002 | “Color Green” mapped to Bit 1 of the SupportedColor parameter. |
| LED_LIGHT_COLOR_RED   | 0x00000004 | “Color Red” mapped to Bit 2 of the SupportedColor parameter.   |

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.  |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range.   |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |
| ASUS_API_STATUS_MORE_DATA         | The amount of available data exceeds the buffer size.<br>Storage buffer overflow was prevented. Read count was larger than the defined buffer length. |



### 2.8.2 AsusLedGetNumberOfLeds

```
uint32_t
ASUS_CALLTYPE
AsusLedGetNumberOfLeds (
    __OUT      uint32_t *pValue);
```

#### Description

Get the number of LEDs that can be controlled.

#### Parameters

| In/Out | Parameter Name | Description  |
|--------|----------------|--|
| __OUT  | pValue         | Pointer to a variable that specifies the number of the LEDs. |

#### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |

### 2.8.3 AsusLedTurnOn

```
uint32_t
ASUS_CALLTYPE
AsusLedTurnOn (
    __IN      uint32_t LedId,
    __IN      uint32_t Color);
```

#### Description

Turn on the LED with the specific color.

#### Parameters

| In/Out | Parameter Name | Description |
|--------|----------------|-------------|
|--------|----------------|-------------|



|      |       |  |
|------|-------|--|
| __IN | LedId | LED Id   |
| __IN | Color | The value to specify that the specific color (refer to the following LED Color Table for the detailed color assignment). |

### LED Color Table

| Id                    | Value      | Description |
|-----------------------|------------|-------------|
| LED_LIGHT_COLOR_BLUE  | 0x00000001 | Color Blue  |
| LED_LIGHT_COLOR_GREEN | 0x00000002 | Color Green |
| LED_LIGHT_COLOR_RED   | 0x00000004 | Color Red   |

### Return Status Code

| Return Value                              | Description   |
|---|---|
| ASUS_API_STATUS_SUCCESS                   | The operation was successful.   |
| ASUS_API_STATUS_ERROR                     | Generic error message. No further error details are available.  |
| ASUS_API_STATUS_NOT_INITIALIZED           | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER         | One or more of the API function call parameters are out of the defined range.   |
| ASUS_API_STATUS_INVALID_PERMISSION_ACCESS | Invalid permission access to the LED. Please use <code>AsusLedSetSystemOccupied()</code> with the parameter: <code>LED_OCCUPIED_BY_USER</code> to allow the system not to occupy the LED. |
| ASUS_API_STATUS_UNSUPPORTED               | This function or Id is not supported.   |

#### 2.8.4 AsusLedTurnOff

```

uint32_t
ASUS_CALLTYPE
AsusLedTurnOff (
    __IN          uint32_t LedId);

```

#### Description

Turn off the LED.



### Parameters

| In/Out | Parameter Name | Description |
|--------|----------------|-------------|
| __IN   | LedId          | LED Id      |

### Return Status Code

| Return Value                              | Description   |
|---|---|
| ASUS_API_STATUS_SUCCESS                   | The operation was successful.   |
| ASUS_API_STATUS_ERROR                     | Generic error message. No further error details are available.  |
| ASUS_API_STATUS_NOT_INITIALIZED           | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER         | One or more of the API function call parameters are out of the defined range.   |
| ASUS_API_STATUS_INVALID_PERMISSION_ACCESS | Invalid permission access to the LED. Please use <code>AsusLedSetSystemOccupied()</code> with the parameter: <code>LED_OCCUPIED_BY_USER</code> to allow the system not to occupy the LED. |
| ASUS_API_STATUS_UNSUPPORTED               | This function or Id is not supported.   |

### 2.8.5 `AsusLedSetSystemOccupied`

```
uint32_t
ASUS_CALLTYPE
AsusLedSetSystemOccupied (
    __IN    uint32_t LedId,
    __IN    uint32_t SystemOccupied);
```

### Description

Allow the system to occupy the control permission of the LED or not.

### Parameters

| In/Out | Parameter Name | Description |
|--------|----------------|-------------|
| __IN   | LedId          | LED Id      |



|      |                |  |
|------|----------------|--|
| __IN | SystemOccupied | Used to specify whether this LED is occupied by the system or not. The value with LED_OCCUPIED_BY_SYSTEM means the LED will be only controlled by the system. The value with LED_OCCUPIED_BY_USER means users or applications will have the permission to control the LED. |
|------|----------------|--|

### Return Status Code

| Return Value                      | Description   |
|-----------------------------------|---|
| ASUS_API_STATUS_SUCCESS           | The operation was successful.   |
| ASUS_API_STATUS_ERROR             | Generic error message. No further error details are available.                |
| ASUS_API_STATUS_NOT_INITIALIZED   | Library uninitialized.  |
| ASUS_API_STATUS_INVALID_PARAMETER | One or more of the API function call parameters are out of the defined range. |
| ASUS_API_STATUS_UNSUPPORTED       | This function or Id is not supported.   |