

# **RS720Q-E11-RS8U 2U Rackmount Server User Guide**

0100 000110101001010100010000111100

0101001010100101100100101101000011100

E22381 Revised Edition V3 August 2023

#### Copyright © 2023 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTEK COMPUTER INC. ("ASUS").

ASUS provides this manual "as is" without warranty of any kind, either express or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose. In no event shall ASUS, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of use or data, interruption of business and the like), even if ASUS has been advised of the possibility of such damages arising from any defect or error in this manual or product.

Specifications and information contained in this manual are furnished for informational use only, and are subject to change at any time without notice, and should not be construed as a commitment by ASUS. ASUS assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual, including the products and software described in it.

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Safety i	nformatio	۱۷	ii
About t	his guide.	i	ix
Chapte	er 1:	Product Introduction	
1.1	System p	ackage contents1-	2
1.2	Serial nur	nber label1-	3
1.3	System s	pecifications1-	4
1.4	Front pan	el features1-	6
1.5	Rear pane	el features1-	7
1.6	Internal fe	eatures1-	8
1.7	LED infor	mation1-	.9
	1.7.1	Front panel LEDs 1-	9
	1.7.2	HDD status LEDs 1-1	0
	1.7.3	LAN (RJ-45) LEDs 1-1	1
	1.7.4	Rear panel LEDs1-1	2
	1.7.5	Q-Code table1-1	2
Chapte	er 2:	Hardware Information	
2.1	Server no	de2-	2
2.1	Server no 2.1.1	de	
2.1			2
2.1 2.2	2.1.1 2.1.2	Removing a server node2-	2 3
	2.1.1 2.1.2	Removing a server node	2 3 4
	2.1.1 2.1.2 Air Duct	Removing a server node	2 3 4 4
	2.1.1 2.1.2 Air Duct 2.2.1 2.2.2	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-	2 -3 - <b>4</b> -4
2.2	2.1.1 2.1.2 Air Duct 2.2.1 2.2.2	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the air duct       2-         Installing the air duct       2-	2 -3 -4 -4 -5
2.2	2.1.1 2.1.2 Air Duct 2.2.1 2.2.2 Central P	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the air duct       2-         Installing the air duct       2-         rocessing Unit (CPU)       2-	-2 -3 -4 -4 -4 -5
2.2	2.1.1 2.1.2 Air Duct . 2.2.1 2.2.2 Central P 2.3.1 2.3.2	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the air duct       2-         rocessing Unit (CPU)       2-         Installing the CPU and heatsink       2-	2 ·3 ·4 ·4 ·5 ·9
2.2 2.3	2.1.1 2.1.2 Air Duct . 2.2.1 2.2.2 Central P 2.3.1 2.3.2	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the air duct       2-         rocessing Unit (CPU)       2-         Installing the CPU and heatsink       2-         Installing the CPU and liquid cooling module       2-	2 3 4 4 5 9 4
2.2 2.3	2.1.1 2.1.2 Air Duct 2.2.1 2.2.2 Central P 2.3.1 2.3.2 System m	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the air duct       2-         rocessing Unit (CPU)       2-         Installing the CPU and heatsink       2-         Installing the CPU and liquid cooling module       2-         nemory       2-	2 -3 -4 -4 -5 -9 4 4
2.2 2.3	2.1.1 2.1.2 Air Duct 2.2.1 2.2.2 Central P 2.3.1 2.3.2 System m 2.4.1	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the air duct       2-         rocessing Unit (CPU)       2-         Installing the CPU and heatsink       2-         Installing the CPU and liquid cooling module       2-         Installing the CPU and liquid cooling module       2-         Overview       2-1	2 3 4 4 5 9 4 4 4 4 4
2.2 2.3	2.1.1 2.1.2 Air Duct . 2.2.1 2.2.2 Central P 2.3.1 2.3.2 System m 2.4.1 2.4.2	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the air duct       2-         roccessing Unit (CPU)       2-         Installing the CPU and heatsink       2-         Installing the CPU and liquid cooling module       2-         nemory       2-1         Memory Configurations       2-1	2 3 4 4 5 9 4 4 6
2.2 2.3	2.1.1 2.1.2 <b>Air Duct</b> . 2.2.1 2.2.2 <b>Central P</b> 2.3.1 2.3.2 <b>System r</b> 2.4.1 2.4.2 2.4.3 2.4.4	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the CPU and heatsink       2-         Installing the CPU and liquid cooling module       2-         Overview       2-1         Memory Configurations       2-1         Installing a DIMM       2-1	2 3 4 4 5 9 4 4 6 6
2.2 2.3 2.4	2.1.1 2.1.2 <b>Air Duct</b> . 2.2.1 2.2.2 <b>Central P</b> 2.3.1 2.3.2 <b>System r</b> 2.4.1 2.4.2 2.4.3 2.4.4	Removing a server node       2-         Installing a server node       2-         Removing the air duct       2-         Installing the CPU and heatsink       2-         Installing the CPU and liquid cooling module       2-         Demory       2-1         Memory Configurations       2-1         Installing a DIMM       2-1         Removing a DIMM       2-1	2 3 4 4 5 9 4 4 6 6 7

2.6	Expansion	on slots	2-20
	2.6.1	Installing a PCIe expansion card	2-20
	2.6.2	Configuring an expansion card	2-24
	2.6.3	Installing an M.2 card	2-25
2.7	Backpla	ne and Midplane cabling	2-28
2.8	Remova	ble/optional components	2-31
	2.8.1	System fan	2-31
	2.8.2	Power supply module	2-34
2.9	Rail Kit (	Options	2-35
Chapt	er 3:	Motherboard Information	
3.1	Motherb	oard layout	3-2
3.2	Central F	Processing Unit (CPU)	3-5
3.3	Dual Inli	ne Memory Module (DIMM)	3-5
3.4	Jumpers		3-6
3.5	Internal	connectors	3-10
3.6	Internal	LEDs	3-14
Chapt	er 4:	BIOS Setup	
Chapte 4.1		BIOS Setup g and updating your BIOS	4-2
		-	
	Managin	g and updating your BIOS	4-2
•	Managin 4.1.1 4.1.2	g and updating your BIOS ASUS CrashFree BIOS 3 utility	4-2 4-3
4.1	Managin 4.1.1 4.1.2	<b>g and updating your BIOS</b> ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility	4-2 4-3 <b>4-4</b>
4.1	Managin 4.1.1 4.1.2 BIOS set	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility tup program	4-2 4-3 <b>4-4</b> 4-5
4.1	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility tup program BIOS menu screen	4-2 4-3 <b>4-4</b> 4-5 4-5
4.1 4.2	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2 Main me	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility tup program BIOS menu screen Menu bar	
4.1 4.2 4.3	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2 Main me Performa	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility tup program BIOS menu screen Menu bar nu	4-2 4-3 4-3 4-5 4-5 4-5 4-7 4-8
4.1 4.2 4.3 4.4	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2 Main me Performa	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility tup program BIOS menu screen Menu bar nu ance Tuning menu	4-2 4-3 4-4 4-5 4-5 4-5 4-7 4-7 4-8 4-10
4.1 4.2 4.3 4.4	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2 Main me Performa Advance	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility BIOS menu screen Menu bar nu ance Tuning menu ed menu	4-2 4-3 4-4 4-5 4-5 4-5 <b>4-7</b> <b>4-7</b> <b>4-8</b> <b>4-10</b> 4-10
4.1 4.2 4.3 4.4	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2 Main me Performa Advance 4.5.1	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility tup program BIOS menu screen Menu bar nu ance Tuning menu Trusted Computing	
4.1 4.2 4.3 4.4	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2 Main me Performa Advance 4.5.1 4.5.2	g and updating your BIOS ASUS CrashFree BIOS 3 utility ASUS EZ Flash Utility tup program BIOS menu screen Menu bar nu ance Tuning menu d menu Trusted Computing ACPI Settings.	4-2 4-3 4-4 4-5 4-5 4-5 4-7 4-7 4-8 4-10 4-10 4-11 4-11
4.1 4.2 4.3 4.4	Managin 4.1.1 4.1.2 BIOS set 4.2.1 4.2.2 Main me Performa Advance 4.5.1 4.5.2 4.5.3	g and updating your BIOS	4-2 4-3 4-4 4-5 4-5 4-5 4-7 4-7 4-8 4-10 4-10 4-11 4-11 4-11 4-12

	4.5.7	PCI Subsystem Settings	4-17
	4.5.8	USB Configuration	4-18
	4.5.9	Network Stack Configuration	4-19
	4.5.10	NVMe Configuration	4-20
	4.5.11	APM Configuration	4-21
	4.5.12	T1s Auth Configuration	4-22
	4.5.13	Intel(R) Virtual RAID on CPU	4-22
	4.5.14	Third-party UEFI driver configurations	4-23
4.6	Platform	Configuration menu	1-24
	4.6.1	PCH-IO Configuration	4-25
	4.6.2	Miscellaneous Configuration	4-26
	4.6.3	Server ME Configuration	4-26
	4.6.4	Runtime Error Logging Support	4-27
4.7	Socket C	configuration menu	1-28
	4.7.1	Processor Configuration	4-29
	4.7.2	Common RefCode Configuration	4-35
	4.7.3	Uncore Configuration	4-35
	4.7.4	Memory Configuration	4-36
	4.7.5	IIO Configuration	4-41
	4.7.6	Advanced Power Management Configuration	4-41
4.8	Security	menu	1-44
	4.8.1	Secure Boot	4-45
4.9	Boot mer	nu4	1-48
4.10	Tool men	nu4	1-49
4.11	Event Lo	gs menu	4-50
	4.11.1	Change Smbios Event Log Settings	4-50
	4.11.2	View Smbios Event Log	4-51
4.12	Server M	gmt menu	1-52
	4.12.1	System Event Log	4-53
	4.12.2	View FRU Information	4-53
	4.12.3	BMC network configuration	4-54
	4.12.4	View System Event Log	1-56
4.13	Save & E	xit menu	4-57

Chapte	er 5:	RAID Configuration				
5.1	Setting up	p RAID5-	2			
	5.1.1	RAID definitions	2			
	5.1.2	Installing hard disk drives5-	2			
	5.1.3	RAID configuration utilities5-	2			
5.2	Intel <sup>®</sup> Virt	ual Raid on CPU in BIOS5-	3			
	5.2.1	Creating a RAID set	4			
	5.2.2	Deleting a RAID set5-	5			
5.3	Intel <sup>®</sup> Rap	oid Storage Technology enterprise (Windows)5-	6			
	5.3.1	Creating a RAID set5-	7			
	5.3.2	Changing a Volume Type5-	9			
	5.3.3	Deleting a volume5-1	0			
	5.3.4	Preferences	1			
Chapte	er 6:	Driver Installation				
6.1	Running	the Support DVD6-	2			
Appen	dix					
Z13PH-I	D16 block	diagramA-	2			
Notices	Notices					
Service	Service and Support A-5					

# Safety information

# **Electrical Safety**

- Before installing or removing signal cables, ensure that the power cables for the system unit and all attached devices are unplugged.
- To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system.
- When adding or removing any additional devices to or from the system, ensure that the
  power cables for the devices are unplugged before the signal cables are connected. If
  possible, disconnect all power cables from the existing system before you add a device.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your dealer.

# **Operation Safety**

- Any mechanical operation on this server must be conducted by certified or experienced engineers.
- Before operating the server, carefully read all the manuals included with the server package.
- Before using the server, ensure all cables are correctly connected and the power cables are not damaged. If any damage is detected, contact your dealer as soon as possible.
- To avoid short circuits, keep paper clips, screws, and staples away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity, and temperature extremes. Place the server on a stable surface.



This product is equipped with a three-wire power cable and plug for the user's safety. Use the power cable with a properly grounded electrical outlet to avoid electrical shock.

# **Restricted Access Location**

This product is intended for installation only in a Computer Room where:

- Access can only be gained by SERVICE PERSONS or by USERS who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken.
- Access is through the use of a TOOL, or other means of security, and is controlled by the authority responsible for the location.

#### **Heavy System**

**CAUTION!** This server system is heavy. Ask for assistance when moving or carrying the system.

# Lithium-Ion Battery Warning

**CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

### Avertissement sur les batteries Lithium-Ion

**ATTENTION :** Danger d'explosion si la batterie n'est pas correctement remplacée. Remplacer uniquement avec une batterie de type semblable ou équivalent, recommandée par le fabricant. Jeter les batteries usagées conformément aux instructions du fabricant.

CLASS 1 LASER PRODUCT

# About this guide

# Audience

This user guide is intended for system integrators, and experienced users with at least basic knowledge of configuring a server.

# Contents

This guide contains the following parts:

### 1. Chapter 1: Product Introduction

This chapter describes the general features of the server. It includes sections on front panel and rear panel specifications.

### 2. Chapter 2: Hardware Information

This chapter lists the hardware setup procedures that you have to perform when installing or removing system components.

### 3. Chapter 3: Motherboard Information

This chapter gives information about the motherboard that comes with the server. This chapter includes the motherboard layout, jumper settings, and connector locations.

### 4. Chapter 4: BIOS Setup

This chapter tells how to change system settings through the BIOS Setup menus and describes the BIOS parameters.

### 5. Chapter 5: RAID Configuration

This chapter provides instructions for setting up, creating, and configuring RAID sets using the available utilities.

### 6. Chapter 6: Driver Installation

This chapter provides instructions for installing the necessary drivers for different system components.

# Conventions

To ensure that you perform certain tasks properly, take note of the following symbols used throughout this manual.



DANGER/WARNING: Information to prevent injury to yourself when trying to complete a task.



**CAUTION:** Information to prevent damage to the components when trying to complete a task.



**IMPORTANT**: Instructions that you MUST follow to complete a task.



NOTE: Tips and additional information to help you complete a task.

# Typography

Bold text	Indicates a menu or an item to select.	
Italics	Used to emphasize a word or a phrase.	
<key></key>	Keys enclosed in the less-than and greater-than sign means that you must press the enclosed key.	
	Example: <enter> means that you must press the Enter or Return key.</enter>	
<key1>+<key2>+<key3></key3></key2></key1>	If you must press two or more keys simultaneously, the key names are linked with a plus sign (+).	
	Example: <ctrl>+<alt>+<del></del></alt></ctrl>	
Command	Means that you must type the command exactly as shown, then supply the required item or value enclosed in brackets.	
	Example: At the DOS prompt, type the command line: format A:/S	

# References

Refer to the following sources for additional information, and for product and software updates:

### 1. ASUS Control Center (ACC) user guide

This manual tells how to set up and use the proprietary ASUS server management utility.

### 2. ASUS websites

The ASUS websites provide updated information for all ASUS hardware and software products. Visit <u>https://www.asus.com</u> for more information.

# **Product Introduction**

1

This chapter describes the general features of the server. It includes sections on front panel and rear panel specifications.

# 1.1 System package contents

Check your system package for the following items.

Model Name	RS720Q-E11-RS8U
Chassis	ASUS 2U Rackmount Chassis
Motherboard	ASUS Z13PH-D16 Server Board
	2 x 3000W Power Supply
	2 x Front Panel Board (FPB-R2H-A)
	2 x Power Supply Distribution Board (PDB-R2H-B-3200)
	1 x Power Connection Board (PSB-R2H-A)
	1 x Backplane Board (BP8LE32G-25-R2H-D)
	2 x Midplane Board (MP4LE32G-D-R2H-D)
Component	4 x Converter Board (CB8LX12G-R2H-B)
	4 x PCIe Riser Card - Right (RF16R-R2H-D)
	4 x PCIe Riser Card - Left (RF16L-R2H-D)
	4 x M.2 PCIe Riser Card (RG4RG4L-M2X2-R2HE)
	2 x Backplane Fans (40mm x 28mm)
	4 x System Fans (80mm x 38mm)
	8 x Tool-less Hot-swap 2.5" Storage Bays
	1 x ASUS RS720Q-E11-RS8U Series Support DVD (includes User Guide)
	8 x CPU Standard Heatsinks (air cooling SKUs only)
	4 x CPU Cold Plate Loop (liquid cooling SKUs only)
	1 x Bag of Screws
Accessories	2 x AC Power Cables
	1 x Friction Rail Kit
	8 x LGA4677 XCC E1A CPU Carrier (barebone SKUs only)
	8 x LGA4677 MCC E1B CPU Carrier (barebone SKUs only)
	8 x LGA4677 HBM E1C CPU Carrier (barebone SKUs only)



If any of the above items is damaged or missing, contact your retailer.

# 1.2 Serial number label

Please take note of the product's serial number. The Serial number contains 12 characters such as xxSxxxxxxx similar to the figure shown below.

You need to provide the correct serial number to the ASUS Technical Support team member if you need assistance or when requesting support.



# 1.3 System specifications

The ASUS RS720Q-E11-RS8U is a 2U server system featuring the ASUS Z13PH-D16 Server Board. The server supports 4<sup>th</sup> Gen Intel<sup>®</sup> Xeon<sup>®</sup> Processor Scalable family plus other latest technologies through the chipsets onboard.

Model Name	•	RS720Q-E11-RS8U
		2 x Socket (LGA4677) per Node
Processor Support / System Bus		$4^{\text{th}}\text{Gen Intel}^{\$}\text{Xeon}^{\$}$ Processor Scalable Family (air cooling up to
		205W, liquid cooling up to 350W)
		UPI 16 GT/s
Core Logic		Intel <sup>®</sup> C741
Total Slots		16 (8-channel per CPU, 8 DIMM per CPU)
	Capacity	Maximum up to 2+4TB (Per Node, DDR5 + Crow Pass)
		DDR5 4800 RDIMM/RDIMM 3DS (1DIMM per Channel)
	Memory Type	Intel <sup>®</sup> Optane <sup>™</sup> DC persistent memory 300 Series (Crow Pass)
Memory		* Refer to ASUS server AVL for the latest update
		64GB, 32GB, 16GB RDIMM
	Memory Size	256GB, 128GB RDIMM 3DS
	Memory Size	512GB, 256GB, 128GB Intel <sup>®</sup> Optane <sup>™</sup> DC persistent memory 300 Series (Crow Pass)
		* Refer to www.asus.com/support for the latest update
	Total PCI/	
	PCIe Slots	2 PCIe slots per Node
Expansion	Slot Type	Per Node:
Slots	Siot Type	2 x PCle x16 (Gen5 x16 link), LP, HHHL (CPU1)
	M.2	Per Node:
		2 x M.2 (Up to 22110, PCIe 4.0 from CPU1)
		Per Node:
Storage	SATA/SAS	Optional Broadcom SAS3008 (supports RAID 0, 1)
Controller	Controller	- 2 x SAS 12Gb/s ports or;
		- 2 x SATA 6Gb/s ports
		Per System:
Storage	Storage Bay	- 8 x 2.5" Hot-swap Storage Bays (8 x SATA/SAS/NVMe)
g-	otorago bay	Per Node:
		- 2 x 2.5" Hot-swap Storage Bays (2 x SATA/SAS/NVMe)
		Per Node:
Networking		2 x LAN Port Intel <sup>®</sup> X710-AT2 10GbE LAN controller
		1 x Management Port
VGA		Aspeed AST2600 64MB
		Per Node:
Overhier		Up to 1 single slot GPU, LP
Graphics		* Advanced Cooling Upgrade kit required. Certain GPUs with high TDP may only be supported under specific conditions. For additional details about specialized system optimization, contact ASUS Technical Support.

(continued on the next page)


Model Name		RS720Q-E11-RS8U	
		Per Node:	
		2 x USB 3.2 Gen 1 ports	
Rear I/O Conn	ectors	1 x VGA port	
		2 x RJ-45 10GbE LAN ports	
		1 x RJ-45 Management LAN port	
		Per Node:	
		Front:	
		- 1 x Power Switch/LED	
		- 1 x Location Switch/LED	
0		- 1 x Message LED	
Switch/LED		- 2 x LAN LED	
		Rear:	
		- 1 x Power Switch/LED	
		- 1 x Q-Code/Port 80 LED	
Security Optio	ns	TPM-SPI / PFR	
	Software	ASUS Control Center (Classic)	
Management Solution	Out of Band Remote Management	On-Board ASMB11-iKVM for KVM-over-IP	
		Windows <sup>®</sup> Server, RHEL, SLES, CentOS, Ubuntu	
OS support		* Refer to <u>www.asus.com/event/server/OS_support_list/OS.html</u> for the latest update	
<b>Regulatory Co</b>	mpliance	BSMI, CE, CB, FCC (ClassA)	
Dimensions		800mm x 444mm x 88mm (2U)	
Dimensions		31.5" x 17.48" x 3.46"	
<b>Gross Weight</b>	Kg	41.5 kg	
Net Weight Kg and HDD not i		32.5 kg	
Power Supply		1+1 Redundant 3000W 80 PLUS Titanium Power Supply	
(following diffe	erent	Rating: 220-240 Vac, 15.5A (x2), 50-60Hz, Class I	
configuration	by region)	* 1+1 redundant mode only supports CPUs under 205W	
		Operation temperature: 10°C ~ 35°C	
Environment		Non-operation temperature: -40°C ~ 60°C	
		Non-operation humidity: 20% ~ 90% (Non condensing)	
<u> </u>			



Specifications are subject to change without notice.

# 1.4 Front panel features

The barebone server displays easily accessible features such as the power and reset buttons, LED indicators, and optical drive.




### Asset tag


The Asset tag is a small polyester film located on the right side of the server's front panel. It provides information about the server such as asset barcode or serial number and is useful in asset tracking and inventory management.

# 1.5 Rear panel features

# RS720Q-E11-RS8U



# Z13PH-D16 (Node)






This port is for ASUS ASMB11-iKVM controller and for technicians only.

# 1.6 Internal features

The barebone server includes the basic components as shown.



- 1. Front panel boards
- 2. Hot-swap storage device trays
- 3. HDD backplane
- 4. System fan (SYS\_FAN1)
- 5. System fan (SYS\_FAN2)
- 6. System fan (SYS\_FAN3)
- 7. System fan (SYS\_FAN4)
- 8. BP\_FAN1 (top) and BP\_FAN2 (bottom)
- 9. SATA/SAS converter board (optional)
- 10. Midplane
- 11. ASUS Z13PH-16 server board
- 12. Power supply and power fan



Ensure that the air duct is positioned on the gaps between the memory slots.




Turn off the system power and detach the power supply before removing or replacing any system component.

### \*WARNING\* HAZARDOUS MOVING PARTS KEEP FINGERS AND OTHER BODY PARTS AWAY


# 1.7 LED information

# 1.7.1 Front panel LEDs



LED	D Icon Display status Description		Description	
Power LED		ON	System power ON	
Message LED		OFF	System is normal; no incoming event	
Message LED		ON	A hardware monitor event is indicated	
	&₁ &}₂	OFF	No LAN connection	
LAN LEDs		Blinking	LAN is transmitting or receiving data	
		ON	LAN connection is present	
		ON	Location switched is pressed	
Location LED	ID	OFF	Normal status (Press the location switch again to turn off.)	

# 1.7.2 HDD status LEDs



Storage Device LED Description			
	ON	Storage device has failed	
Status (RED)	Blinking	RAID rebuilding or locating	
Activity (GREEN)	ON	Storage device power ON	
	Blinking	Read/write data from/into the SATA/SAS/NVMe storage device	
	OFF	Storage device not found	

# 1.7.3 LAN (RJ-45) LEDs


### Dedicated Management LAN port (DM\_LAN1) LED indications

ACT/LINK LED SPEED LED




ACT/LI	NK LED	SPEED LED		
Status Description		Status	Description	
OFF No link		OFF	10 Mbps connection	
GREEN Linked		ORANGE	100 Mbps connection	
BLINKING Data activity		GREEN	1 Gbps connection	

### Intel<sup>®</sup> X710-AT2 10GbE LAN port LEDs



ACT/LI	NK LED	SPEED LED		
Status Description		Status	Description	
OFF	No link	OFF	100 Mbps connection	
GREEN	Linked	ORANGE	1-5 Gbps connection	
BLINKING Data activity		GREEN	10 Gbps connection	

# 1.7.4 Rear panel LEDs



LED	Display status	Description	
Power LED	ON	System power is on	
BMC Heartbeat LED	Blinking	BMC is operating normally	
DMO Leasting LED	OFF	System is normal; no incoming event	
BMC Location LED	ON	Received user command to locate the system	
	OFF	System is normal; no incoming event	
BMC Message LED	ON	A hardware monitor event is indicated	
CATERR LED	ON	System has experienced a catastrophic error	
Standby Power LED	ON	System standby power is on	

# 1.7.5 Q-Code table

Action	PHASE	POST CODE	TYPE	DESCRIPTION
	İ	01	Progress	First post code(POWER_ON_POST_CODE)
	Security Phase	02	Progress	Load BSP microcode(MICROCODE_POST_CODE)
		03	Progress	Set cache as ram for PEI phase(CACHE_ENABLED_POST_CODE)
		06	Progress	CPU Early init.(CPU_EARLY_INIT_POST_CODE)
		04	Progress	initializes South bridge for PEI preparation
		10	Progress	PEI Core Entry
		15	Progress	NB initialize before installed memory
		19	Progress	SB initialize before installed memory
	PEI(Pre-EFI initialization) phase	78~00	Progress	Wait BMC ready(duration: 120 seconds).
		A1	MRC Progress	QPI initialization
		A3	MRC Progress	QPI initialization
		A7	MRC Progress	QPI initialization
		A8	MRC Progress	QPI initialization
		A9	MRC Progress	QPI initialization
		AA	MRC Progress	QPI initialization
		AB	MRC Progress	QPI initialization
Normal boot		AC	MRC Progress	QPI initialization
		AD	MRC Progress	QPI initialization
		AE	MRC Progress	QPI initialization
		AF	MRC Progress	QPI initialization Complete
		2F	Progress	Memory Init.
		B0	MRC Progress	Memory Init.
		B1	MRC Progress	Memory Init.
		AF	MRC Progress	RC Reset if require
		B4	MRC Progress	Memory Init.
		B2	MRC Progress	Memory Init.
		B3	MRC Progress	Memory Init.
		B5	MRC Progress	Memory Init.
		B6	MRC Progress	Memory Init.
		B7	MRC Progress	Memory Init.
		B8	MRC Progress	Memory Init.
		B9	MRC Progress	Memory Init.
		BA	MRC Progress	Memory Init.

(continued on the next page)

Action	PHASE	POST CODE	ТҮРЕ	DESCRIPTION
		BB	MRC Progress	Memory Init.
		BC	MRC Progress	Memory Init.
		BF	MRC Progress	Memory Init. Done
		5A	MRC Progress	Other config. After RC end
	PEI(Pre-EFI initialization) phase	31	Progress	Memory already installed.
		32	Progress	CPU Init.
		34	Progress	CPU Init.
		36	Progress	CPU Init.
		4F	Progress	DXE Initial Program Load(IPL)
		60	Progress	DXE Core Started
		61	Progress	DXE NVRAM Init.
		62	Progress	SB run-time init.
		63	Progress	DXE CPU Init
		68	Progress	NB Init.
	DXE(Driver Execution Environment) phase	69	Progress	NB Init.
		6A	Progress	NB Init.
		70	Progress	SB Init.
		71	Progress	SB Init.
		72	Progress	SB Init.
		78	Progress	ACPI Init.
		79	Progress	CSM Init.
		90	Progress	BDS started
		91	Progress	Connect device event
		92	Progress	PCI Bus Enumeration.
		93	Progress	PCI Bus Enumeration.
		94	Progress	PCI Bus Enumeration.
Normal boot		95	Progress	PCI Bus Enumeration.
		96	Progress	PCI Bus Enumeration.
		97	Progress	Console outout connect event
	BDS(Boot Device Selection) phase	98	Progress	Console input connect event
		99		
			Progress	AMI Super IO start
		9A	Progress	AMI USB Driver Init.
		9B	Progress	AMI USB Driver Init.
		9C	Progress	AMI USB Driver Init.
		9D	Progress	AMI USB Driver Init.
		b2	Progress	Legacy Option ROM Init.
		b3	Progress	Reset system
		b4	Progress	USB hotplug
		b6	Progress	NVRAM clean up
		b7	Progress	NVRAM configuration reset
		A0	Progress	IDE, AHCI Init.
		A1	Progress	IDE, AHCI Init.
		A2	Progress	IDE, AHCI Init.
		A3	Progress	IDE, AHCI Init.
		A8	Progress	BIOS Setup Utility password verify
		A9	Progress	BIOS Setup Utility start
		AB	Progress	BIOS Setup Utility input wait
		AD	Progress	Ready to boot event
		AE	Progress	Legacy boot event
	Operating system phase	AA	Progress	APIC mode
		AC	Progress	PIC mode
			1 1091000	T TO THOUG






# **Hardware Information**

This chapter lists the hardware setup procedures that you have to perform when installing or removing system components.


# 2.1 Server node

# 2.1.1 Removing a server node


1. Remove the screw located on the node latch.



2. Hold the server node lever and press the green node latch.



3. Firmly pull the server node out of the server chassis.




# 2.1.2 Installing a server node




When installing only two nodes, install the nodes to node slot number 1 and 3 or number 2 and 4. Refer to the **Rear panel features** section for details.

1. Align the node with the node slot on the chassis, then push the node all the way into the node slot.



2. Secure the node latch using the screw previously removed.




# 2.2 Air Duct

The RS720Q-E11-RS8U server system comes with a motherboard fan air duct to enable better air flow inside the motherboard while the system is running.

# 2.2.1 Removing the air duct

- 1. Remove the three (3) screws securing the air duct on both sides of the node chassis.
- 2. Carefully lift the air duct out of the chassis.



## 2.2.2 Installing the air duct

1. Position the air duct on top of the motherboard, then carefully fit it on top of the motherboard. Refer to the following illustration for the correct orientation of the air duct.




Insert the air duct on the gaps between the memory slots.

Ľ

Ensure that the air duct is firmly fitted to the motherboard.

2. Secure the air duct using the three (3) screws removed previously.



# 2.3 Central Processing Unit (CPU)

The motherboard comes with a surface mount LGA 4677 socket designed for the  $4^{\rm th}$  Gen Intel<sup>®</sup> Xeon<sup>®</sup> Processor Scalable Family processors.

- Upon purchase of the motherboard, ensure that the PnP cap is on the socket and the socket contacts are not bent. Contact your retailer immediately if the PnP cap is missing, or if you see any damage to the PnP cap/socket contacts/motherboard components. ASUS will bear the cost of repair only if the damage is shipment/transitrelated.
  - Keep the cap after installing the motherboard. ASUS will process Return Merchandise Authorization (RMA) requests only if the motherboard comes with the PnP cap on the socket.
  - The product warranty does not cover damage to the socket contacts resulting from incorrect CPU installation/removal, or misplacement/loss/incorrect removal of the PnP cap.


# 2.3.1 Installing the CPU and heatsink

To install a CPU:


- 1. Remove the server node. For more information, see the **Removing a server node** section.
- 2. Remove the air duct. For more information, see the Removing the air duct section.
- 3. Remove the PnP caps from the CPU sockets.



Keep the PnP cap. ASUS will process Return Merchandise Authorization (RMA) requests only if the motherboard comes with the PnP cap on the socket.



4. Attach the CPU to the carrier bracket, ensure the triangle mark is on the same side as the bracket lever, then attach the CPU and carrier bracket to the heatsink.






The CPU carrier differs depending on the type of CPU. Ensure that the CPU carrier corresponds to the CPU being installed.

5. Align the CPU and heatsink assembly in the correct orientation so that the triangle marks on both the CPU and socket are aligned in the same direction, then place the heatsinks on top of the CPU sockets.

The CPU and CPU Carrier fits in only one correct orientation. DO NOT force the CPU and CPU Carrier into the socket to prevent damaging the CPU pins on the socket.




- The heatsink differs depending on the CPU socket, please refer to the illustration below for more information on the heatsink and the corresponding CPU socket.
- The heatsink should be oriented with the airflow direction indicator pointing towards the rear of the system.



 Once the heatsink is placed on top of the CPU socket (A), push the lock latches outwards on all four corners of the heatsink so that the heatsink and CPU assembly is secured to the CPU socket (B).




Ensure the triangle mark on the CPU is located in the same corner as the CPU socket.



 Do two (2) clockwise turns on each of the heatsink screws in the cross order pattern shown on the illustration until the heatsink screws are tightened and the heatsink is secured onto the motherboard.



Intel<sup>®</sup> recommends a using a torque driver with a T-30 bit and a torque value of 8 lbf-in to prolong the longevity of all PEEK nuts after the quality of the load post is corrected.




- 8. Reinstall the air duct. For more information, see the **Installing the air duct** section.
- 9. Reinstall the server node. For more information, see the **Installing a server node** section.


# 2.3.2 Installing the CPU and liquid cooling module

To install the CPUs and liquid cooling module:

- 1. Remove the server node. For more information, see the **Removing a server node** section.
- 2. Remove the air duct. For more information, see the **Removing the air duct** section.
- Attach the CPU to the carrier bracket, ensure the triangle mark is on the same side as the bracket lever, then attach the CPU and carrier brackets to the liquid cooling modules.




- 4. Remove the two (2) screws securing the riser card to the chassis.
- 5. Firmly hold the riser card, then pull it up to detach it from the PCIe x16 slot on the motherboard.



6. Remove the PnP caps from the CPU sockets.



Keep the PnP cap. ASUS will process Return Merchandise Authorization (RMA) requests only if the motherboard comes with the PnP cap on the socket.




 Align the CPU and liquid cooling module assembly in the correct orientation as shown in the illustration below, then place the liquid cooling modules on top of the CPU sockets.



The CPU and CPU Carrier fits in only one correct orientation. DO NOT force the CPU and CPU Carrier into the socket to prevent damaging the CPU pins on the socket.

8. Align and insert the riser card into the PCIe slot on the motherboard.




9. Once the liquid cooling modules are placed on top of the CPU sockets, push the lock latches outwards on all four corners of the liquid cooling modules so that the CPU and liquid cooling module assembly is secured to the CPU socket.



The CPU and CPU Carrier fits in only one correct orientation. DO NOT force the CPU and CPU Carrier into the socket to prevent damaging the CPU pins on the socket.


10. Secure the riser card with the screws that you removed earlier in step 4.



11. Do two (2) clockwise turns on each of the heatsink screws in the cross order pattern shown on the illustration until the heatsink screws are tightened and the heatsink is secured onto the motherboard.



Intel<sup>®</sup> recommends a using a torque driver with a T-30 bit and a torque value of 8 lbf-in to prolong the longevity of all PEEK nuts after the quality of the load post is corrected.




## 2.4 System memory

## 2.4.1 Overview

The motherboard comes with sixteen (16) Double Data Rate 5 (DDR5) Dual Inline Memory Modules (DIMM) sockets.

The figure illustrates the location of the DDR5 DIMM sockets:

## Z13PH-D16 288-pin DDR5 DIMM sockets



## 2.4.2 Memory Configurations

You may install 16GB, 32GB, 64GB RDIMMs; 128GB, 256GB RDIMM 3DS; or 128GB, 256GB, 512GB Intel<sup>®</sup> Optane<sup>™</sup> persistent memory 300 Series (Crow Pass) into the DIMM sockets using the memory configurations in this section.



- Refer to ASUS Server AVL for the updated list of compatible DIMMs.
- Always install DIMMs with the same CAS latency. For optimum compatibility, it is recommended that you obtain memory modules from the same vendor.

#### **Dual CPU configuration**

You can refer to the following recommended memory population for a dual CPU configuration:

Dual CPU	Dual CPU configuration															
CPU	CPU1						CPU2									
Slot	A1	B1	C1	D1	E1	F1	G1	H1	A1	B1	C1	D1	E1	F1	G1	H1
2 DIMMs	$\checkmark$								$\checkmark$							
4 DIMMs	$\checkmark$						~		$\checkmark$						~	
8 DIMMs	$\checkmark$		~		~		~		$\checkmark$		~		~		~	
12 DIMMs	$\checkmark$		$\checkmark$	~	~	$\checkmark$	~		$\checkmark$		~	$\checkmark$	~	~	~	
16 DIMMs	~	✓	~	~	✓	~	~	~	$\checkmark$	✓	$\checkmark$	~	✓	~	✓	✓

If you wish to install PMem as well, please refer to the following table for configurations:

If two CPUs are installed, ensure that both CPUs share the same PMem configuration.


Channel	н	G	F	E		А	В	С	D
DDR5+CPS	DIMM_H1	DIMM_G1	DIMM_F1	DIMM_E1	CPU	DIMM_A1	DIMM_B1	DIMM_C1	DIMM_D1
4+4	DDR5	CPS	DDR5	CPS	CPU	CPS	DDR5	CPS	DDR5
6+1		DDR5	DDR5	DDR5		DDR5	CPS	DDR5	DDR5

## 2.4.3 Installing a DIMM



Make sure to unplug the power supply before adding or removing DIMMs or other system components. Failure to do so may cause severe damage to both the motherboard and the components.

- 1. Unlock a DIMM socket by pressing the retaining clips outward.
- Align a DIMM on the socket such that the notch on the DIMM matches the DIMM slot key on the socket.






A DIMM is keyed with a notch so that it fits in only one direction. To avoid damaging the DIMM, DO NOT force a DIMM into a socket in the wrong direction.

 Hold the DIMM by both of its ends, then insert the DIMM vertically into the socket. Apply force to both ends of the DIMM simultaneously until the retaining clips snap back into place.


Ensure that the DIMM is sitting firmly on the DIMM slot.



Always insert the DIMM into the socket VERTICALLY to prevent DIMM notch damage.

## 2.4.4 Removing a DIMM

- 1. Simultaneously press the retaining clips outward to unlock the DIMM.
- 2. Remove the DIMM from the socket.





Support the DIMM lightly with your fingers when pressing the retaining clips. The DIMM might get damaged when it flips out with extra force.



## 2.5 Storage devices

The system supports two (2) hot-swap storage devices per node. The storage device installed on the drive tray connects to the Midplane via the Backplane.

## 2.5.1 Installing a 2.5" hot-swap SATA/SAS/NVMe storage device

Ensure that the storage devices installed correspond to the correct node. For more information on the nodes and the storage bays, please refer to the **Front panel features** and **Rear panel features** sections.


 Press the spring lock to release the tray lever and to partially eject the tray from the bay.




2. Firmly hold the tray lever and carefully pull the drive tray out of the bay.



3. Place the 2.5" storage device into the tray until it clicks into place.



4. Align and insert the 2.5-inch storage device and drive tray assembly into the drive bay.




5. Repeat steps 1-4 to install any other 2.5-inch storage devices.

# 2.5.2 Removing a 2.5" hot-swap SATA/SAS/NVMe storage device

- 1. Follow steps 1 and 2 of the **Installing a 2.5**" hot-swap SATA/SAS/NVMe storage device section to remove the drive tray.
- 2. Push the 2.5" storage device through the openings on the bottom of the tray until the 2.5" storage device pops out of the tray.

DO NOT touch the circuit board on the 2.5" storage device. Ensure to push the 2.5" storage device through the opening on the bottom of the tray.



3. Follow step 4 of the **Installing a 2.5**" hot-swap SATA/SAS/NVMe storage device section to install the storage device and drive tray assembly into the drive bay.

## 2.6 Expansion slots

The following subsections describe the slots and expansion cards that they support.



Make sure to unplug the power supply before adding or removing expansion cards. Failure to do so may cause you physical injury and damage motherboard components.

## 2.6.1 Installing a PCIe expansion card


The onboard PCI Express slots on the motherboard comes pre-installed with two riser cards that each support one x16 slot (Gen5 x16 link) for installing low profile PCIe x16 cards.

#### To install a PCIe expansion card to the left riser card:


- 1. Remove the two (2) screws securing the left riser card to the chassis.
- Firmly hold the left riser card, then pull it up to detach it from the PCIe x16 slot on the motherboard.



Make sure to remove the air duct before removing the riser card. Please refer to the **Removing the air duct** section for more information.



3. Remove the metal bracket from the riser card.




4. Prepare the expansion card.



Before installing an expansion card, read the documentation that came with it and make sure to make the necessary hardware settings.

5. Align and insert the golden finger connectors of the expansion card to the PCIe slot connector on the riser card as shown.




6. Align and insert the riser card and expansion card assembly into the PCIe slot on the motherboard.



The expansion card fits in one orientation only. If it does not fit, try reversing it.

7. Secure the riser card with the screws that you removed earlier in step 1.




#### To install a PCIe expansion card to the right riser card:


- 1. Please refer to steps 1 to 2 in the previous section to remove the left riser card.
- 2. Remove the two (2) screws securing the right riser card to the chassis.
- 3. Firmly hold the right riser card, then pull it up to detach it from the PCIe x16 slot on the motherboard.



Make sure to remove the air duct before removing the riser card. Please refer to the **Removing the air duct** section for more information.



4. Remove the metal bracket from the riser card.




5. Prepare the expansion card.



Before installing an expansion card, read the documentation that came with it and ensure to make the necessary hardware settings.

6. Align and insert the golden finger connectors of the expansion card to the PCIe slot connector on the riser card as shown.

7. Align and insert the golden finger connectors of the expansion card to the PCIe slot connector on the riser card as shown.




8. Align and insert the riser card and expansion card assembly into the PCIe slot on the motherboard.



The expansion card fits in one orientation only. If it does not fit, try reversing it.

9. Secure the riser card with the screws that you removed earlier in step 2.



10. Refer to steps 6 to 7 in the previous section to reinstall the left riser card.

## 2.6.2 Configuring an expansion card

After installing the expansion card, configure it by adjusting the software settings.

- 1. Turn on the system and change the necessary BIOS settings, if any. See Chapter 5 for information on BIOS setup.
- 2. Assign an IRQ to the card. Refer to the **Standard Interrupt assignments** table for more information.
- 3. Install the software drivers for the expansion card.

IRQ	Priority	Standard function
0	1	System Timer
1	2	Keyboard Controller
2	-	Programmable Interrupt
3*	11	Communications Port (COM2)
4*	12	Communications Port (COM1)
5*	13	
6	14	Floppy Disk Controller
7*	15	
8	3	System CMOS/Real Time Clock
9*	4	ACPI Mode when used
10*	5	IRQ Holder for PCI Steering
11*	6	IRQ Holder for PCI Steering
12*	7	PS/2 Compatible Mouse Port
13	8	Numeric Data Processor
14*	9	Primary IDE Channel
15*	10	Secondary IDE Channel

#### Standard Interrupt assignments

 $^{\star}$  These IRQs are usually available for ISA or PCI devices.

## 2.6.3 Installing an M.2 card




The illustrations in this section are for reference only. The M.2 card may differ depending on the M.2 card you purchased.



The **M.2\_SLOT1** slot on the motherboard does not support hot-plug. If you wish to install or remove the M.2 baseboard and/or M.2 card, make sure to power off the system before installing or removing the M.2 baseboard and/or M.2 card.


1. Remove the screw securing the M.2 baseboard from the motherboard, then lift and remove the M.2 baseboard.



 The M.2 baseboard comes pre-installed with two (2) stands and screws. To install a M.2 card on the front or rear side of the baseboard, please refer to the below instructions:

#### To install a M.2 card to the front of the baseboard:


a. Remove the two (2) indicated stands and screws from the front of the baseboard.






The additional stand and screw is used for the M.2 card slot on the rear of the baseboard. It is recommended to install the stand and screw in an unused screw hole when not in use.


b. Install the stand in one of the indicated screw holes on the front side of the baseboard depending on the length of the M.2 card.



c. Insert your M.2 card into the M.2 slot on the M.2 baseboard.



d. Push down on the M.2 card, then secure it to the M.2 baseboard using the screw removed previously.




#### To install an M.2 card to the back of the baseboard:


a. (Optional) Reinstall the stand in one of the indicated screw holes on the back side of the baseboard depending on the length of the M.2 card.




b. Insert your M.2 card into the M.2 slot on the M.2 baseboard.



c. Push down on the M.2 card, then secure it to the M.2 baseboard using the screw removed previously.





- 3. Align and insert the M.2 baseboard into the M.2\_SLOT1 slot on the motherboard, then push down until the M.2 baseboard is securely seated in the slot.
- 4. Secure the M.2 baseboard to the system using the screw removed previously.




## 2.7 Backplane and Midplane cabling

Remove the top cover before configuring the backplane and midplane cabling by removing the four (4) screws securing the top cover (A), then push the top cover towards the rear of the system and remove the top cover (B).







A	Connect N1_N3_PWR1 on the Backplane to BPPWR1 on the Lower Midplane
B	Connect N2_N4_PWR1 on the Backplane to BPPWR1 on the Upper Midplane
C	Connect SMBUS1 on the Backplane to SMBUS1 on the Upper and Lower Midplane
D	Connect $\ensuremath{\text{N1\_SLIMPCIE1}}$ and $\ensuremath{\text{N1\_SLIMPCIE2}}$ on the Backplane to $\ensuremath{\text{N1\_MCIO1}}$ on the Lower Midplane
Ø	Connect $\textbf{N1\_SLIMSAS1}$ on the Backplane to $\textbf{SLIMSAS1}$ on the Converter Board for Node 1
F	Connect $N2\_SLIMPCIE1$ and $N2\_SLIMPCIE2$ on the Backplane to $N1\_MCIO1$ on the Upper Midplane
G	Connect $\ensuremath{\text{N2\_SLIMSAS1}}$ on the Backplane to $\ensuremath{\text{SLIMSAS1}}$ on the Converter Board for Node 2
0	Connect $N3\_SLIMPCIE1$ and $N3\_SLIMPCIE2$ on the Backplane to $N3\_MCIO1$ on the Lower Midplane
0	Connect $\ensuremath{\text{N3\_SLIMSAS1}}$ on the Backplane to $\ensuremath{\text{SLIMSAS1}}$ on the Converter Board for Node 3
J	Connect $N4\_SLIMPCIE1$ and $N4\_SLIMPCIE2$ on the Backplane to $N3\_MCIO1$ on the Upper Midplane
K	Connect $\textbf{N4\_SLIMSAS1}$ on the Backplane to $\textbf{SLIMSAS1}$ on the Converter Board for Node 4

## 2.8 Removable/optional components

This section describes installation or removal instructions for the following components:

- 1. System fans
- 2. Power supply module




Ensure that the system is turned off before removing any components.


## 2.8.1 System fan

To replace a system fan:


1. Remove the four (4) screws securing the top cover (A), then push the top cover towards the rear of the system and remove the top cover (B).




- 2. Prepare a replacement fan of the same type and size.
- 3. Disconnect the system fan cable from the fan connector on the Midplane.




4. Lift the fan, then set it aside.



5. Insert the replacement fan into the fan compartment.



6. Connect the system fan cable to the fan connector on the midplane.




7. Repeat steps 3 to 6 to replace the other system fans.


## 2.8.2 Power supply module

To replace a power supply unit (PSU):

1. Lift up the PSU lever (A), then press the PSU latch (B) and carefully pull the PSU out of the system chassis using the PSU lever (C) while the PSU latch is still pressed down.



- 2. Prepare the replacement PSU.
- 3. Align and insert the replacement PSU into the empty PSU bay until it clicks in place.





The system automatically combines the two power supply modules as a single one. The combined output power varies with input voltages. Refer to the table below for details.

#### 3000W



To enable the hot-swap feature (redundant mode), keep the total power consumption
of the system under the maximum output power of an individual power supply module.



- Always use PSUs with the same watt and power rating. Combining PSUs with different wattage (e.g. 1 x 1600 W + 1 x 2200 W) may yield unstable results and potential damage to your system.
- For steady power input, use only the power cables that come with the server system package.

## 2.9 Rail Kit Options

This server system supports the rail kit options listed below. For more information on rail kit installation, refer to corresponding documentation on the ASUS support site or on the official product site for this server system.



- We strongly recommend that at least two able-bodied persons perform the installation of the rail kit.
- We recommend the use of an appropriate lifting tool or device, if necessary.
- Friction rail kit




# Motherboard Information 3


This chapter includes the motherboard layout and brief descriptions of the jumpers and internal connectors.

## 3.1 Motherboard layout

## Top side



#### Bottom side



Central Processing Unit (CPU)	Page
1. CPU socket(s)	3-5

Dua	Page	
1.	DIMM sockets	3-5


Jun	Jumpers			
1.	Clear RTC RAM (3-pin CLRTC1)	3-6		
2.	ME firmware force recovery setting (3-pin ME_RCVR1)	3-7		
3.	BMC Setting (3-pin BMC_EN1)	3-7		
4.	PMBus 1.2 PSU select jumper (3-pin SMART_PSU1)	3-8		
5.	DMLAN setting (3-pin DM_IP_SEL1)	3-8		
6.	PCH_MFG setting (3-pin PCH_MFG1)	3-9		
7.	VGA setting (3-pin VGA_SW1)	3-9		

Inte	Internal connectors		
1.	Trusted Platform Module connector (13-1 pin TPM1)	3-10	
2.	Serial port connector (10-1 pin COM1)	3-10	
3.	VROC_KEY connector (3-pin VROC_KEY1)	3-11	
4.	Power connector	3-11	
5.	BMC Debug UART connector (3-pin BMC_DEBUGUART1)	3-12	
6.	CPLD JTAG connector (6-pin CPLD_JTAG1)	3-12	
7.	System Management Bus (SMBUS) connector (5-1 pin SMBUS1)	3-13	
8.	Platform Firmware Resilience (PFR) module connector (ROT_CON)	3-13	

Inte	Internal LEDs		
1.	Standby Power LED (SBPWR1)	3-14	
2.	CAT ERR LED (CATERR1)	3-14	
3.	BMC Heartbeat LED (BMCLED1)	3-15	
4.	BMC Location LED (LOCLED1)	3-15	
5.	BMC Message LED (MESLED1)	3-16	
6.	DIMM LED (DIMMLED1)	3-16	
7.	Asynchronous DRAM Refresh (ADR) LED (ADRLED1)	3-17	

## 3.2 Central Processing Unit (CPU)


The motherboard comes with a surface mount LGA 4677 socket designed for the  $4^{\rm th}$  Gen Intel® Xeon® Processor Scalable Family processors.



## Z13PH-D16 CPU LGA 4677 Socket

## 3.3 Dual Inline Memory Module (DIMM)

The motherboard comes with sixteen (16) Double Data Rate 5 (DDR5) Dual Inline Memory Modules (DIMM) sockets.



## Z13PH-D16 288-pin DDR5 DIMM sockets

## 3.4 Jumpers

#### 1. Clear RTC RAM (CLRTC1)

This jumper allows you to clear the Real Time Clock (RTC) RAM in CMOS. You can clear the CMOS memory of date, time, and system setup parameters by erasing the CMOS RTC RAM data. The onboard button cell battery powers the RAM data in CMOS, which include system setup information such as system passwords.

To erase the RTC RAM:

- 1. Turn OFF the computer and unplug the power cord.
- 2. Move the jumper cap from pins 1–2 (default) to pins 2–3. Keep the cap on pins 2–3 for about 5–10 seconds, then move the cap back to pins 1–2.
- 3. Plug the power cord and turn ON the computer.
- Hold down the <Del> key during the boot process and enter BIOS setup to reenter data.




Except when clearing the RTC RAM, never remove the cap on CLRTC jumper default position. Removing the cap will cause system boot failure!




If the steps above do not help, remove the onboard battery and move the jumper again to clear the CMOS RTC RAM data. After the CMOS clearance, reinstall the battery.

## Z13PH-D16 Clear RTC RAM



#### 2. ME firmware force recovery setting (3-pin ME\_RCVR1)


This jumper allows you to force the Intel Management Engine (ME) firmware to enter recovery mode if needed.



#### Z13PH-D16 ME recovery setting

#### 3. BMC Setting (3-pin BMC\_EN1)


This jumper allows you to enable or disable the ASMB11.



## Z13PH-D16 BMC setting

#### 4. PMBus 1.2 PSU select jumper (3-pin SMART\_PSU1)


This jumper allows you to set the motherboard (node) to immediately respond to PSU alert events.



#### Z13PH-D16 Smart Ride Through setting

#### 5. DMLAN setting (3-pin DM\_IP\_SEL1)


This jumper allows you to select the DMLAN setting. Set to pins 2-3 to force the DMLAN IP to static mode (IP=10.10.10.10, submask=255.255.255.0).



#### Z13PH-D16 DM\_IP\_SEL1 setting

#### 6. PCH\_MFG setting (3-pin PCH\_MFG1)

This jumper allows you to update the BIOS ME block.




## Z13PH-D16 PCH\_MFG setting

#### 7. VGA setting (3-pin VGA\_SW1)

This jumper allows you to enable or disable the onboard VGA.


## Z13PH-D16 VGA setting



## 3.5 Internal connectors

#### 1. Trusted Platform Module connector (14-1 pin TPM1)


This connector supports a Trusted Platform Module (TPM) system, which can securely store keys, digital certificates, passwords, and data. A TPM system also helps enhance network security, protects digital identities, and ensures platform integrity.



#### Z13PH-D16 TPM connector

#### 2. Serial port connector (10-1 pin COM1)


This connector is for a serial (COM) port. Connect the serial port module cable to this connector, then install the module to a slot opening at the back of the system chassis.



#### Z13PH-D16 Serial port connector

#### 3. VROC\_KEY connector (4-pin VROC\_KEY1)

This connector allows you to connect a KEY module to enable CPU RAID functions with  $Intel^{\circ}$  CPU RSTe.



#### Z13PH-D16 VROC\_KEY1 connector




The KEY module is purchased separately.

#### 4. Power connector

This power connector connects to the Midplane.


#### Z13PH-D16 ATX power connectors



#### 5. BMC Debug UART connector (3-pin BMC\_DEBUGUART1)


This connector is used for reading the BMC UART Debug log.

#### Z13PH-D16 BMC\_DEBUGUART1 connector



#### 6. CPLD JTAG connector (6-pin CPLD\_JTAG1)


This connector is used for burning the CPLD JTAG.



## Z13PH-D16 CPLD\_JTAG connector

### 7. System Management Bus (SMBUS) connector (5-1 pin SMBUS1)


This connector controls the system and power management-related tasks. This connector processes the messages to and from devices rather than tripping the individual control lines.



# Z13PH-D16 SMBUS connector

### 8. Platform Firmware Resilience (PFR) module connector (ROT\_CON)

This connector allows you to connect a PFR module to enable platform firmware resilience functions.




# Z13PH-D16 ROT\_CON1 connector

# 3.6 Internal LEDs

# 1. Standby Power LED (SBPWR1)

The motherboard comes with a standby power LED. The green LED lights up to indicate that the system is ON, in sleep mode, or in soft-off mode. This is a reminder that you should shut down the system and unplug the power cable before removing or plugging in any motherboard components. The illustration below shows the location of the onboard LED.



# Z13PH-D16 Standby Power LED

# 2. CAT ERR LED (CATERR1)


The CAT ERR LED indicates that the system has experienced a fatal or catastrophic error and cannot continue to operate.

# CATERR1

# Z13PH-D16 CATERR1 LED


# 3. BMC Heartbeat LED (BMCLED1)

The BMC Heartbeat will blink continuously when BMC is operating normally.



# 4. BMC Location LED (LOCLED1)


When the locator button is pressed, both the front and rear Location LEDs of the system will light up.



# Z13PH-D16 Location LED


### 5. BMC Message LED (MESLED1)

When an error occurs, both the front and rear Message LEDs of the system will light up.



### DIMM LED (DIMMLED1) 6.

The DIMM LED indicates that the 12V DIMM power is ready.



# Z13PH-D16 DIMMLED1

# 7. Asynchronous DRAM Refresh (ADR) LED (ADR\_LED)

The ADR LED indicates that the Asynchronous DRAM Refresh (ADR) has been completed.

# ADRLED1

# Z13PH-D16 ADRLED1



# 4

# **BIOS Setup**

This chapter tells how to change the system settings through the BIOS Setup menus. Detailed descriptions of the BIOS parameters are also provided.

# 4.1 Managing and updating your BIOS

The following utilities allow you to manage and update the motherboard Basic Input/Output System (BIOS) setup:

# 1. ASUS CrashFree BIOS 3

To recover the BIOS using a bootable USB flash disk drive when the BIOS file fails or gets corrupted.

# 2. ASUS EzFlash

Updates the BIOS using a USB flash disk.

Refer to the corresponding sections for details on these utilities.

# 4.1.1 ASUS CrashFree BIOS 3 utility

The ASUS CrashFree BIOS 3 is an automatic recovery tool that allows you to restore the BIOS file if it fails or gets corrupted during the updating process. You can update a corrupted BIOS file using a USB flash drive that contains the updated BIOS file.



Prepare a USB flash drive containing the updated motherboard BIOS before using this utility.

# Recovering the BIOS from a USB flash drive

To recover the BIOS from a USB flash drive:

- 1. Insert the USB flash drive with the original or updated BIOS file into a USB port on the system.
- 2. The utility will automatically recover the BIOS and reset the system when the BIOS recovery is finished.



DO NOT shut down or reset the system while recovering the BIOS to prevent system boot failure!



The recovered BIOS may not be the latest BIOS version for this motherboard. Visit the ASUS website at <u>www.asus.com</u> to download the latest BIOS file.

# 4.1.2 ASUS EZ Flash Utility

The ASUS EZ Flash Utility feature allows you to update the BIOS without having to use a DOS-based utility.



Before you start using this utility, download the latest BIOS from the ASUS website at <u>www.</u> asus.com.

To update the BIOS using EZ Flash Utility:

- 1. Insert the USB flash disk that contains the latest BIOS file into the USB port.
- 2. Enter the BIOS setup program. Go to the **Tool** menu, then select **ASUS EZ Flash Utility**. Press <Enter>.

ASUSTek. EzFlash Utility		
Current Platform : Z Version : C Build Date :	102	New Platform Platform : Z13PH-D16 Version : 0201 Build Date :08/22/2022
FSO	System Volume Information Z13PH-D16 BIOS Windows CDIR>	
[Up/Down/Left/Right]:Switch [Enter]:Choose [q]:Exit		

- 3. Press <Tab> to switch to the **Drive** field.
- Press the Up/Down arrow keys to find the USB flash disk that contains the latest BIOS, then press <Enter>.
- 5. Press <Tab> to switch to the Folder Info field.
- 6. Press the Up/Down arrow keys to find the BIOS file, then press <Enter> to perform the BIOS update process. Reboot the system when the update process is done.



- This function can support devices such as a USB flash disk with FAT 32/16 format and single partition only.
- DO NOT shut down or reset the system while updating the BIOS to prevent system boot failure!



Ensure to load the BIOS default settings to ensure system compatibility and stability. Press <F5> and select **Yes** to load the BIOS default settings.

# 4.2 BIOS setup program

This motherboard supports a programmable firmware chip that you can update using the provided utility described in the **Managing and updating your BIOS** section.

Use the BIOS Setup program when you are installing a motherboard, reconfiguring your system, or prompted to "Run Setup." This section explains how to configure your system using this utility.

Even if you are not prompted to use the Setup program, you can change the configuration of your computer in the future. For example, you can enable the security password feature or change the power management settings. This requires you to reconfigure your system using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM of the firmware chip.

The firmware chip on the motherboard stores the Setup utility. When you start up the computer, the system provides you with the opportunity to run this program. Press <Del> during the Power-On Self-Test (POST) to enter the Setup utility; otherwise, POST continues with its test routines.

If you wish to enter Setup after POST, restart the system by pressing <Ctrl>+<Alt>+<Delete>, or by pressing the reset button on the system chassis. You can also restart by turning the system off and then back on. Do this last option only if the first two failed.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.

- The default BIOS settings for this motherboard apply for most conditions to ensure optimum performance. If the system becomes unstable after changing any BIOS settings, load the default settings to ensure system compatibility and stability. Press <F5> and select **Yes** to load the BIOS default settings.
- Support for BIOS functions and options may vary based on AVL testing progress. Please contact your sales representative for more information.
- The BIOS setup screens shown in this section are for reference purposes only, and may not exactly match what you see on your screen.
- Visit the ASUS website (<u>www.asus.com</u>) to download the latest BIOS file for this motherboard.

# 4.2.1 BIOS menu screen

Menu items	Menu bar	Configuration fi	elds	General help
	Aptio	Setup – AMI		
Main Advanced Platfo	rm Configuration Soc	ket Configura <mark>tion</mark>	Security	Boot Tool I
BIOS Information			Choose t	he system default
BIOS Vendor	America	n Megatrends	language	•
Core Version	5.26			
Compliancy		8; PI 1.7		
BIOS Version	0201 ×6			
Build Date	05/11/2			
Access Level	Adminis	trator		
Intel X710 LAN1 MAC	30:5A:3	F:00:93:01		
Intel X710 LAN2 MAC	30:5A:3	F:00:93:02		
BMC Firmware Revision	1.00.01			
RC Version	77.D01			
			↔: Sele	ect Screen
Processor Information			↑↓: Sele	ect Item
Туре	Genuine	e Intel(R) CPU 00	Enter: S	Gelect
	00%@			ange Opt.
Speed	1500MHz			eral Help
				/ious Values
Memory Information				imized Defaults
Total Memory	32 GE			ve Changes & Reset
Memory Frequency	4800 MH	Z		int Screen
			ESC: Exi	It
System Language	[Englis	inj		
	Version 2 22 1284	Copyright (C) 202	2 AMT	
	101 01011 2.22.1204	- 00pgi 18iit (0) 202i		

Navigation keys

# 4.2.2 Menu bar

The menu bar on top of the screen has the following main items:

Main	For changing the basic system configuration
Advanced	For changing the advanced system settings
Platform Configuration	For changing the platform settings
Socket Configuration	For changing the socket settings
Security	For changing the security settings
Boot	For changing the system boot configuration
Tool	For configuring options for special functions
Event Logs	For changing the event log settings
Server Mgmt	For changing the Server Mgmt settings
Exit	For selecting the exit options

To select an item on the menu bar, press the right or left arrow key on the keyboard until the desired item is highlighted.

# Menu items

The highlighted item on the menu bar displays the specific items for that menu. For example, selecting Main shows the Main menu items.

The other items (Advanced, Platform Configuration, Socket Configuration, Security, Boot, Tool, Event Logs, Server Mgmt, and Exit) on the menu bar have their respective menu items.

# Submenu items

A solid triangle before each item on any menu screen means that the item has a submenu. To display the submenu, select the item, then press <Enter>.

# **Navigation keys**

At the bottom right corner of a menu screen are the navigation keys for the BIOS setup program. Use the navigation keys to select items in the menu and change the settings.

# General help

At the top right corner of the menu screen is a brief description of the selected item.

# **Configuration fields**

These fields show the values for the menu items. If an item is user-configurable, you can change the value of the field opposite the item. You cannot select an item that is not user-configurable.

A configurable field is enclosed in brackets, and is highlighted when selected. To change the value of a field, select it and press <Enter> to display a list of options.

# Pop-up window

Select a menu item and press <Enter> to display a pop-up window with the configuration options for that item.

# Scroll bar

A scroll bar appears on the right side of a menu screen when there are items that do not fit on the screen. Press the Up/Down arrow keys or <Page Up> / <Page Down> keys to display the other items on the screen.

# 4.3 Main menu

When you enter the BIOS Setup program, the Main menu screen appears. The Main menu provides you an overview of the basic system information, and allows you to set the system date, time, language, and security settings.

Aptio Setup – AMI Main Advanced Platform Configuration Socket Configuration Security Boot Tool ▶		
BIDS Information BIDS Vendor Core Version Compliancy BIDS Version Build Date Access Level	American Megatrends 5.26 UEFI 2.8; PI 1.7 0201 x64 05/11/2022 Administrator	Choose the system default language
Intel X710 LAN1 MAC Intel X710 LAN2 MAC BMC Firmware Revision	30:5A:3F:00:93:01 30:5A:3F:00:93:02 1.00.01	
RC Version	77.D01	
Processor Information Type	Genuine Intel(R) CPU 00 00%@	↑↓: Select Item Enter: Select +/-: Change Opt.
Speed	1500MHz	F1: General Help F2: Previous Values
Memory Information		F5: Optimized Defaults
Total Memory Memory Frequency	32 GB 4800 MHz	F10: Save Changes & Reset F12: Print Screen ESC: Exit
System Language	[English]	V
Version 2.22.1284 Copyright (C) 2022 AMI		

# System Language [English]

Allows you to select the system default language.

# System Date [MM/DD/YYYY]

Allows you to set the system date.

# System Time [HH:MM:SS]

Allows you to set the system time.

# 4.4 Performance Tuning menu

The Performance Tuning menu items allow you to change performance related settings for different scenarios.

Main Performance Tuning Advanced	Aptio Setup – AMI Platform Configuration	Socket Configuration Security
Optimized Performance Setting	[Default]	Dynamically adjusts the
Core Optimizer	[Disabled]	frequency of all CPU cores
Engine Boost	[Disabled]	based on their current
Power Balancer	[Disabled]	utilization, delivering better

# **Optimized Performance Setting [Default]**

Allows you to select performance settings for different scenarios.

[Default] Default settings.

- [By Benchmark] Optimize for different kinds of benchmarks. Select this option, then select a benchmark type from the >> list.
- [By Workload] Optimize for different kinds of workloads. Select this option, then select a workload type from the >> list.



This function will reset some BIOS settings that you have changed back to their default values. Please check your BIOS settings again.



The following item appears only when **Power Balancer** is set to [**Disabled**], or if Optimized Performance Setting is set to [**Default**] or [**By Benchmark**].

# Core Optimizer [Disabled]

Allows you to keep the processor operating at the turbo highest frequency for the maximum performance.

Configuration options: [Disabled] [Auto] [Manual]



The following item appears only when you set Core Optimizer to [Manual].

# CPU Max frequency [XXXX]

The default value for this option will be the maximum supported frequency of the CPU installed and may vary between different CPUs.



The following item appears only when you set **Optimized Performance Setting** to **[Default]** or **[By Benchmark]**.

# Engine Boost [Disabled]

Enable this item to boost the CPU's frequency. Recommended operation at an ambient temperature of 25°C or below for optimized performance. Configuration options: [Disabled] [Normal] [Aggressive]



Operate with an ambient temperature of 25°C or lower for optimized performance.



The following item appears only when you set **Core Optimizer** to [Disabled], or if Optimized Performance Setting is set to [Default] or [By Benchmark].

### Power Balancer [Disabled]

Allows you to dynamically adjust the frequency of all CPU cores based on their current utilization, delivering better performance per watt for improved system energy efficiency.

Configuration options: [Disabled] [Enabled by BIOS] [Enabled by ACC]



When setting **Power Balancer** to **[Enabled by ACC]**, make sure that you have the latest ASUS Control Center software installed to support Power Balancer. Please see below for recommended software versions:

- ACC: 1.4.3.5 version or above.



The following item appears only when you set **Power Balancer** to [Enabled by BIOS] or [Enabled by ACC].

Policy [Auto]

Configuration options: [Auto] [Manual]



The following item appears only when you set Policy to [Manual].

### CPU Max frequency [XXXX]


The default value for this option will be the maximum supported frequency of the CPU installed and may vary between different CPUs.

# 4.5 Advanced menu

The Advanced menu items allow you to change the settings for the CPU and other system devices.



Take caution when changing the settings of the Advanced menu items. Incorrect field values can cause the system to malfunction.



# AutoVMD [Enabled]

Allows you to enable or disable Intel VMD feature support and Intel VROC (NVMe RAID). Configuration options: [Disabled] [Enabled]

# 4.5.1 Trusted Computing

Advanced	Aptio Setup – AMI 1	
Configuration Security Device Support NO Security Device Found	[Enable]	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and

# Configuration

# Security Device Support [Enabled]

Allows you to enable or disable the BIOS support for security device. Configuration options: [Disabled] [Enabled]

# 4.5.2 ACPI Settings

Advanced	Aptio Setup – AMI	
ACPI Settings		Enables or Disables BIOS ACPI
Enable ACPI Auto Configuration		Auto Configuration.

# Enable ACPI Auto Configuration [Disabled]

Allows you to enable or disable the BIOS ACPI Auto Configuration. Configuration options: [Disabled] [Enabled]

# 4.5.3 Redfish Host Interface Settings

Aptio Setup - AMI Advanced		
Redfish Host Interface	Settings	Enable/Disable AMI Redfish
Redfish		

# Redfish [Disabled]

Allows you to enable or disable Redfish. Configuration options: [Disabled] [Enabled]



The following items appear only when Redfish is set to [Enabled].

# Authentication mode [Basic Authentication]

Allows you to select the authentication mode. Configuration options: [Basic Authentication] [Session Authentication]

# **Redfish BMC Settings**

## **IP address**

Allows you to enter the IP address.


### **IP Mask address**

Allows you to enter the IP Mask address.

# **IP Port**

Allows you to enter the IP Port.

# 4.5.4 Onboard LAN Configuration



# **Onboard X710 LAN Configuration**

### Intel X710 LAN1

### LAN Enable [LAN1, LAN2 Enabled]

Allows you to enable or disable the onboard LAN. Configuration options: [Disabled] [LAN1 Enabled Only] [LAN1, LAN2 Enabled]

# 4.5.5 Serial Port Console Redirection

Advanced	Aptio Setup – AMI	
COM1 Console Redirection ▶ Console Redirection Settings	[Disabled]	Console Redirection Enable or Disable.
COM2 Console Redirection ▶ Console Redirection Settings	[Disabled]	
Console Redirection	Port Is Disabled	
Serial Port for Out-of-Band Managema	ent/	
Windows Emergency Management Service		++: Select Screen
Console Redirection EMS	[Enabled]	†∔: Select Item
Console Redirection Settings		Enter: Select
		+/−: Change Opt. F1: General Help
		F2: Previous Values
		F5: Optimized Defaults

# COM1/COM2

# **Console Redirection [Disabled]**

Allows you to enable or disable the console redirection feature. Configuration options: [Disabled] [Enabled]



The following item is available only when **Console Redirection** for **COM1** or **COM2** is set to **[Enabled]**.

### **Console Redirection Settings**

These items become configurable only when you enable the **Console Redirection** item. The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

### Terminal Type [ANSI]

Allows you to set the terminal type.

[VT100]	ASCII char set.
[VT100Plus]	Extends VT100 to support color, function keys, etc.
[VT-UTF8]	Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
[ANSI]	Extended ASCII char set.

### Bits per second [115200]

Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds. Configuration options: [9600] [19200] [38400] [57600] [115200]

### Data Bits [8]

Configuration options: [7] [8]

# Parity [None]

A parity bit can be sent with the data bits to detect some transmission errors. [Mark] and [Space] parity do not allow for error detection.

[None]	None
[Even]	Parity bit is 0 if the num of 1's in the data bits is even.
[Odd]	Parity bit is 0 if num of 1's in the data bits is odd.
[Mark]	Parity bit is always 1.
[Space]	Parity bit is always 0.

# Stop Bits [1]

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning.) The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

Configuration options: [1] [2]

### Flow Control [None]

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

Configuration options: [None] [Hardware RTS/CTS]

# VT-UTF8 Combo Key Support [Enabled]

This allows you to enable the VT -UTF8 Combination Key Support for ANSI/VT100 terminals.

Configuration options: [Disabled] [Enabled]

### Recorder Mode [Disabled]

With this mode enabled only text will be sent. This is to capture Terminal data. Configuration options: [Disabled] [Enabled]

### Resolution 100x31 [Enabled]

This allows you enable or disable extended terminal solution. Configuration options: [Disabled] [Enabled]

### Putty Keypad [VT100]

This allows you to select the FunctionKey and Keypad on Putty. Configuration options: [VT100] [LINUX] [XTERMR6] [SC0] [ESCN] [VT400]

# Serial Port for Out-of-Band Management/ Windows Emergency Management Services (EMS)

# Console Redirection EMS [Enabled]

Allows you to enable or disable the console redirection feature. Configuration options: [Disabled] [Enabled]



The following item is available only when Console Redirection EMS is set to [Enabled].

# **Console Redirection Settings**

# Out-of-Band Mgmt Port [COM1]

Microsoft Windows Emergency Management Services (EMS) allow for remote management of a Windows Server OS through a serial port. Configuration options: [COM1] [COM2]

# Terminal Type EMS [VT-UTF8]

VT-UTF8 is the preferred terminal type for out0of-band management. The next best choice is VT100+, and then VT100. See above, in Console Redirection Settings page for more help with Terminal Type/Emulation. Configuration options: [VT100] [VT100+] [VT-UTF8] [ANSI]

### Bits per second EMS [115200]

Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds. Configuration options: [9600] [19200] [57600] [115200]

# Flow Control EMS [None]

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

Configuration options: [None] [Hardware RTS/CTS] [Software Xon/Xoff]

# 4.5.6 SIO Configuration

Aptio Setup – AMI Advanced	
AMI SIO Driver Version : A5.17.00	View and Set Basic properties of the SIO Logical device.
Super IO Chip Logical Device(s) Configuration ▶ [*Active*] Serial Port 1 ▶ [*Active*] Serial Port 2	Like IO Base, IRQ Range, DMA Channel and Device Mode.
WARNING: Logical Devices state on the left side of the control, reflects the current Logical Device state. Changes made during Setup Session will be shown after you restart the system.	



Logical Devices state on the left side of the control, reflects the current Logical Device state. Changes made during Setup Session will be shown after you restart the system.

# [\*Active\*] Serial Port 1 / [\*Active\*] Serial Port 2

Allows you to view and set basic properties of the SIO Logical device. Like IO Base, IRQ Range, DMA Channel, and Device Mode.

### Use This Device [Enabled]

Allows you to enable or disable this Logical Device. Configuration options: [Disabled] [Enabled]



The following item appears only when Use This Device is set to [Enabled].



Disabling SIO Logical Devices may have unwanted side effects. PROCEED WITH CAUTION.

# Possible: [Use Automatic Settings]

Allows the user to change the device resource settings. New settings will be reflected no this setup page after system restarts.

Configuration options: [Use Automatic Settings] [IO=3F8h; IRQ=4; DMA;] [IO=3F8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;] [IO=2F8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;] [IO=3E8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;] [IO=2E8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;] DMA;]

# 4.5.7 PCI Subsystem Settings

Allows you to configure PCI, PCI-X, and PCI Express Settings.

Aptio Setup - AMI Advanced		
PCI Bus Driver Version	A5.01.28	Enables or Disables 64bit capable Devices to be Decoded
PCI Devices Common Settings:		in Above 4G Address Space
		(Only if System Supports 64
Re-Size BAR Support	[Disabled]	bit PCI Decoding).
SR-IOV Support	[Enabled]	
BME DMA Mitigation	[Disabled]	

# Above 4G Decoding [Enabled]

Allows you to enable or disable 64-bit capable devices to be decoded in above 4G address space. It only works if the system supports 64-bit PCI decoding. Configuration options: [Disabled] [Enabled]

# Re-Size BAR Support [Disabled]

If system has Resizable BAR capable PCIe Devices, this option enables or disables Resizable BAR Support. (Only if system supports 64-bit PCI Decoding). Configuration options: [Disabled] [Enabled]

# SR-IOV Support [Enabled]

Allows you to enable or disable Single Root IO Virtualization Support if the system has SR-IOV capable PCIe devices. Configuration options: [Disabled] [Enabled]

# **BME DMA Mitigation [Disabled]**

Allows you to re-enable the Bus Master Attribute disabled during PCI enumeration for PCI bridges after SMM lock. Configuration options: [Disabled] [Enabled]

RS720Q-E11-RS8U

# 4.5.8 USB Configuration

Advanced	Aptio Setup – AMI	
USB Configuration		This is a workaround for OSes without XHCI hand-off support.
USB Controllers:		The XHCI ownership change
1 XHCI		should be claimed by XHCI
USB Devices:		driver.
3 Drives, 2 Keyboards, 1 Mouse	, I HUD	
XHCI Hand–off		
USB Mass Storage Driver Support	[Enabled]	
USB Keyboard and Mouse Simulator	[Enabled]	
Mass Storage Devices:		
JetFlashTranscend 4GB 8.07	[Auto]	
AMI Virtual CDROMO 1.00	[Auto]	++: Select Screen
AMI Virtual HDiskO 1.00	[Auto]	f∔: Select Item

# XHCI Hand-off [Enabled]

Allows you to enable or disable workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver. Configuration options: [Enabled] [Disabled]

# USB Mass Storage Driver Support [Enabled]

Allows you to enable or disable the USB Mass Storage driver support. Configuration options: [Disabled] [Enabled]

# USB Keyboard and Mouse Simulator [Enabled]

Allows you to enable or disable simulation of a USB keyboard and mouse for the PS/2 module in Windows 7. Ensure that the appropriate USB drivers are installed before this option is disabled.

Configuration options: [Disabled] [Enabled]

# 4.5.9 Network Stack Configuration

Aptio Setup – AMI Advanced		
Network Stack	[Enabled]	Enable/Disable UEFI Network
Ipv4 PXE Support	[Disabled]	Stack
IPv4 HTTP Support	[Disabled]	
Ipv6 PXE Support	[Disabled]	
IPv6 HTTP Support	[Disabled]	
PXE boot wait time	0	
Media detect count	1	

# Network Stack [Enabled]

Enables or disables the UEFI network stack. Configuration options: [Disabled] [Enabled]



The following items appear only when Network Stack is set to [Enabled].

### Ipv4 PXE Support [Disabled]

Enables or disables the Ipv4 PXE Boot Support. If disabled, Ipv4 PXE boot support will not be available.

Configuration options: [Disabled] [Enabled]

# Ipv4 HTTP Support [Disabled]

Enables or disables the Ipv4 HTTP Boot Support. If disabled, Ipv4 HTTP boot support will not be available.

Configuration options: [Disabled] [Enabled]

### Ipv6 PXE Support [Disabled]

Enables or disables the Ipv6 PXE Boot Support. If disabled, Ipv6 PXE boot support will not be available.

Configuration options: [Disabled] [Enabled]

### Ipv6 HTTP Support [Disabled]

Enables or disables the Ipv6 HTTP Boot Support. If disabled, Ipv6 HTTP boot support will not be available.

Configuration options: [Disabled] [Enabled]

### PXE boot wait time [0]

Set the wait time to press ESC key to abort the PXE boot. Use the <+> or <-> to adjust the value. The values range from 0 to 5.

### Media detect count [1]

Set the number of times presence of media will be checked. Use the <+> or <-> to adjust the value. The values range from 1 to 50.

# 4.5.10 NVMe Configuration

This page will display the NVMe controller and drive information.

Aptio Setup - AMI Advanced	
NVMe Configuration	
No NVME Device Found	

## Device



The devices and names shown in the NVMe configuration list depends on the connected devices. If no devices are connected, **No NVMe Device Found** will be displayed.

# Self Test Option [Short]

This option allows you to select either Short or Extended Self Test. Short option will take couple of minutes, and the extended option will take several minutes to complete. Configuration options: [Short] [Extended]

### Self Test Action [Controller Only Test]

This item allows you to select either to test Controller alone or Controller and NameSpace. Selecting Controller and Namespace option will take a lot longer to complete the test.


Configuration options: [Controller Only Test] [Controller and NameSpace Test]

### **Run Device Self Test**

Press <Enter> to perform device self test for the corresponding Option and Action selected by the user. Pressing the <ESC> key will abort the test. The results shown below is the most recent result logged in the device.

# 4.5.11 APM Configuration

This page will allow you to configure the Advanced Power Management (APM) settings.



# Restore AC Power Loss [Last State]

When set to **[Power Off]**, the system goes into off state after an AC power loss. When set to **[Power On]**, the system will reboot after an AC power loss. When set to **[Last State]**, the system goes into either off or on state, whatever the system state was before the AC power loss.

Configuration options: [Power Off] [Power On] [Last State]

# Power On By PCI-E [Disabled]

- [Disabled] Disables wake events from PCI-E devices.
- [Enabled] Enables wake evens from PCI-E devices.

# Power On By RTC [Disabled]

- [Disabled] Disables RTC to generate a wake event.
- [Enabled] When set to [Enabled], the items **RTC Alarm Date (Days)** and **Hour/Minute/Second** will become user-configurable with set values.

# 4.5.12 T1s Auth Configuration

Allows you to configure the Server Certificate Authority (CA).

Advanced	Aptio Setup – AMI	
▶ Server CA Configuration		Press <enter≻ configure<br="" to="">Server CA.</enter≻>

# Enroll Cert

Allows you to enroll a certificate using a certificate file or manually input a certificate GUID.

# **Enroll Cert Using File**

Allows you to enroll a certificate using a certificate file. You will be prompted to select a storage device and navigate to the location of the certificate file.

### Cert GUID

Allows you to enroll a certificate by manually inputting the certificate GUID.

### **Commit Changes and Exit**

Exit Server CA configuration after saving the changes.

### **Discard Changes and Exit**

Exit Server CA configuration without saving any changes.

# **Delete Cert**

Allows you to delete the certificate.

# 4.5.13 Intel(R) Virtual RAID on CPU

Allows you to manage Intel(R) Virtual RAID on CPU.



# 4.5.14 Third-party UEFI driver configurations

Additonal configuration options for third-party UEFI drivers installed to the system will appear in the section marked in red in the screenshot below.

Main Advanced Platform Configurati	Aptio Setup – AMI on Socket Configuration	Security Boot Tool 🛛 🕨
AutoVMD Trusted Computing ACPI Settings Redfish Host Interface Settings Onboard LAN Configuration Serial Port Console Redirection SID Configuration PCI Subsystem Settings USB Configuration Network Stack Configuration NVMe Configuration APM Configuration	[Enabled]	AutoVMD
<ul> <li>T1s Auth Configuration</li> <li>Intel(R) Vintual RAID on CPU</li> <li>Intel(R) Ethernet Controller X710 for 30:5A:3F:00:93:01</li> <li>VLAN Configuration (MAC:305A3F009301)</li> <li>MAC:305A3F009301-IPv6 Network Configurent MAC:305A3F009301-IPv4 Network Configurent Intel(R) Ethernet Controller X710 for 30:5A:3F:00:93:02</li> <li>VLAN Configuration (MAC:305A3F009302)</li> <li>MAC:305A3F009302-IPv6 Network Configurent MAC:305A3F009302-IPv4 Network Configurent</li> </ul>	nation nation ∙ 10GBASE-T - nation	++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes & Reset F12: Print Screen ESC: Exit
Version 2.	22.1284 Copyright (C) 202	2 AMI

# 4.6 Platform Configuration menu

 $\langle \mathbf{A} \rangle$ 

The Platform Configuration menu items allow you to change the platform settings.

Setting items in this menu to incorrect values may cause the system to malfunction!

Aptio Setup – AMI Main Advanced <mark>Platform Configuration</mark> Socket Configuration Security Boot Tool	
<ul> <li>PCH-IO Configuration</li> <li>Miscellaneous Configuration</li> <li>Server ME Configuration</li> <li>Runtime Error Logging</li> </ul>	PCH Parameters
Setup Warning: Setting items on this Screen to incorrect values may cause system to malfunction!	
	++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes & Reset F12: Print Screen
Version 2.22.1284 Copyright (	ESC: Exit

# 4.6.1 PCH-IO Configuration

Platform Conf	Aptio Setup – AMI iguration	
PCH-IO Configuration		Device Options Settings
▶ SATA And RST Configuration		
DeepSx Power Policies IEH Mode	[Disabled] [Enabled]	

# SATA And RST Configuration

Allows you to configure SATA and RST settings.

### **Controller 1-3 SATA And RST Configuration**

### SATA Configuration [Enabled]

Allows you to enable or disable the SATA Controller Configuration options: [Disable] [Enable]



The following items appear only when SATA Configuration is set to [Enabled].

### SATA Mode Selection [AHCI]

Allows you to configure how the SATA Controller operates. Configuration options: [AHCI] [RAID]

# SATA SGPIO Enable [Disabled]

Allows you to enable or disable Serial GPIO for the SATA Controller. Configuration options: [Disabled] [Enabled]

### SATA Port 0-7 [Enabled]

Allows you to enable or disable the selected SATA port.

Configuration options: [Disabled] [Enabled]

### SATA Port 0-7 Hot Plug [Enabled]

Allows you to designate the selected SATA port as hot pluggable.

Configuration options: [Disabled] [Enabled]

### SATA Port 0-7 Spin Up Device [Disabled]

Allows you to designate the selected SATA port as a spin up device. If this option is enabled for any port, staggered spin up will be performed and only the drives which have this option enabled will spin up at boot. If disabled for all ports, all drives will spin up at boot.

Configuration options: [Disabled] [Enabled]

# DeepSx Power Policies [Disabled]

Allows you to configure the DeepSx power policy. Configuration options: [Disabled] [Enabled in S5]

### IEH Mode [Enabled]

Allows you to enable or bypass Interrupt Error Handling (IEH). Configuration options: [Bypass Mode] [Enabled]

# 4.6.2 Miscellaneous Configuration




# Active Video [Onboard Device]

Allows you to select the active video type. Configuration options: [Auto] [Onboard Device] [PCIE Device]

# 4.6.3 Server ME Configuration

Displays the Server ME Technology parameters on your system. Scroll using <Page Up> / <Page Down> keys to see more items.



# Altitude [8000]

Allows you to set the altitude of the platform location above the sea level, expressed in meters. The hex number is decoded as 2's complement signed integer. Provide the 8000h value if the altitude is unknown.

# MCTP Bus Owner [0]

Allows you to enter the MCTP bus owner location on PCIe: [15:8] bus, [7:3] device, [2:0] function. If all zeros sending bus owner will be disabled.

# 4.6.4 Runtime Error Logging Support



# System Errors [Enable]

Allows you to enable or disable System Errors setup options. Configuration options: [Disable] [Enable]



The following item is available only when System Errors is set to [Enabled].

# Whea Settings

### Whea Support [Enable]

Allows you to enable or disable Whea support. Configuration options: [Disable] [Enable]

# 4.7 Socket Configuration menu

The Socket Configuration menu items allow you to change the socket settings.

	io Setup – AMI Socket Configuration <mark>Security Boot Tool ♪</mark>
<ul> <li>Processor Configuration</li> <li>Common RefCode Configuration</li> <li>Uncore Configuration</li> <li>Memory Configuration</li> <li>IIO Configuration</li> <li>Advanced Power Management Configuration</li> </ul>	Displays and provides options to change the Processor Settings
	++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes & Reset F12: Print Screen ESC: Exit
Version 2.22.1	284 Copyright (C) 2022 AMI

# 4.7.1 Processor Configuration

Scroll using the <Page Up> / <Page Down> keys to view more items.

	Aptio Setup – AMI Socket Configuration
Processor Configuration	Change Per-Socket Settings
<ul> <li>Per-Socket Configuration Processor Socket Processor ID Processor Frequency Processor Max Ratio Processor Min Ratio Microcode Revision L1 Cache RAM(Per Core) L2 Cache RAM(Per Package)</li> </ul>	606A6 - ICX D0 Socket 0 Socket 1 000606A6* 000606A6 3.600GHz 3.600GHz 24H 24H 0BH 0BH 0D000280 00000280 80KB 80KB 1280KB 1280KB 14942KB 128492KB
Processor O Version Processor 1 Version	Intel(R) Xeon(R) Gold 6 334 CPU @ 3.60GHz Intel(R) Xeon(R) Gold 6 334 CPU @ 3.60GHz 334 CPU @ 3.60GHz +/-: Change Opt. F1: General Helo
Hyper-Threading [ALL] Max CPUID Value Limit Handware Prefetcher L2 RFO Prefetch Disable Adjacent Cache Prefetch DCU Streamer Prefetcher DCU IP Prefetcher	[Enable]     F2: Previous Values       [Disable]     F5: Optimized Defaults       [Enable]     F10: Save Changes & Reset       [Disable]     F10: Save Changes & Reset       [Enable]     F12: Print Screen       [Enable]     ESC: Exit       [Enable]     [Enable]

# **Per-Socket Configuration**

Allows you to change Per-Socket Settings.

### CPU Socket 0/1 Configuration

### Core Disable Bitmap(Hex) [0]

Allows you to set the Core Disable Bitmap. Set this item to [0] to enable all cores. Set this item to [FFFFFFFFF] to disable all cores.



At least one core per CPU must be enabled. Disabling all cores is an invalid configuration.

# Hyper Threading [Enabled]

Allows you to enable or disable the Hyper-Threading Technology function. When disabled, only one thread per activated core is enabled. This is the software method to enable or disable Logical Processor threads.

Configuration options: [Disabled] [Enabled]

# IED Trace Memory [Disabled]

Allows you to allocate memory for PSMI trace.

Configuration options: [Disabled] [4M] [8M] [16M] [32M] [64M] [128M] [256M] [512M] [1G]

# Skip Flex Ratio Override [Disabled]

Allows you to skip flex ratio overrides to use power-on default flex ratio values. In multi-socket systems, this will allow mixed flex ratio limits.

Configuration options: [Disabled] [Enabled]

# Check CPU BIST Result [Enabled]

Allows you to check or ignore BIST results. If enabled, cores with failed BIST results will be disabled.

Configuration options: [Disabled] [Enabled]

# 3StrikeTimer [Enabled]

Allows you to enable or disable the 3 strike counter. Configuration options: [Disabled] [Enabled]

# Fast String [Enabled]

Allows you to enable or disable fast strings for REP MOVS/STOS.

Configuration options: [Disabled] [Enabled]

# Machine Check [Enabled]

Allows you to enable or disable the machine check.

Configuration options: [Disabled] [Enabled]

# Hardware Prefetcher [Enabled]

Allows you to enable or disable the hardware prefetcher.

Configuration options: [Disabled] [Enabled]

# L2 RFO Prefetch Disable [Disabled]

Allows you to turn enable or disable L2 RFO prefetcher. Configuration options: [Disabled] [Enabled]

# Adjacent Cache Prefetch [Enabled]

Allows you to enable or disable prefetching of adjacent cache lines. Configuration options: [Disabled] [Enabled]

# **DCU Streamer Prefetcher [Enabled]**

Allows you to enable or disable prefetcher of next L1 data line. Configuration options: [Disabled] [Enabled]

# DCU IP Prefetcher [Enabled]

Allows you to enable or disable prefetch of next L1 line based upon sequential load history. Configuration options: [Disabled] [Enabled]

# LLC Prefetch [Disabled]

Allows you to enable or disable LLC Prefetch on all threads. Configuration options: [Disabled] [Enabled]

# DCU Mode [Normal]

[Normal]	The whole DCU is used for caching.
[Mirror-Mode]	DCU is organized as 2x16KB mirrored copies.

# AMP Prefetch [Disabled]

Allows you to enable or disable AMP Prefetch. Configuration options: [Disabled] [Enabled]

#### Extended APIC [Enabled]

Allows you to enable or disable the extended APIC support. Configuration options: [Disabled] [Enabled]

I	/
Ľ	

Enabling Extended APIC will automatically enable VT-d and Interrupt Remapping.

#### APIC Physical Mode [Disabled]

Allows you to enable or disable the APIC physical destination mode. Configuration options: [Disabled] [Enabled]

#### PECI Trust Mode [Use per-PECI agent trust mode]

Allows you to select the PECI trust mode

Configuration options: [All PECI Agents untrusted] [All PECI Agents trusted] [Use per-PECI agent trust mode]



The following items are available only when **PECI Trust Mode** is set to **[Use per-PECI agent trust mode]**.

#### Legacy Agent [Enabled]

Allows you to enable or disable legacy agent trust. Configuration options: [Disabled] [Enabled]

#### SMBus Agent [Disabled]

Allows you to enable or disable SMBus agent trust. Configuration options: [Disabled] [Enabled]

#### IE Agent [Enabled]

Allows you to enable or disable IE agent trust. Configuration options: [Disabled] [Enabled]

#### Generic Agent [Disabled]

Allows you to enable or disable generic agent trust. Configuration options: [Disabled] [Enabled]

#### eSPI Agent [Disabled]

Allows you to enable or disable eSPI agent trust. Configuration options: [Disabled] [Enabled]

#### DfxRedManu Agent [Disabled]

Allows you to enable or disable DfxRedManu agent trust. Configuration options: [Disabled] [Enabled]

#### DfxOrange Agent [Disabled]

Allows you to enable or disable DfxOrange agent trust. Configuration options: [Disabled] [Enabled]

#### DBP-F [Disabled]

Allows you to enable or disable DBP-F. Configuration options: [Disabled] [Enabled]

#### IIO LLC Ways [14:0] (Hex) [0]

Allows you to set the bitmask for IIO LLC Ways. All bits set in the mask must be contiguous.

#### SMM Blocked and Delayed [Disabled]

Allows you to enable or disable SMM Blocked and Delayed. Configuration options: [Disabled] [Enabled]

#### eSMM Save State [Disabled]

Allows you to enable or disable the eSMM save state feature. Configuration options: [Disabled] [Enabled]

#### Smbus Error Recovery [Enabled]

Allows you to enable or disable Smbus Error Recovery. Configuration options: [Disabled] [Enabled]

#### Intel(R) TXT [Disabled]

Allows you to enable or disable Intel®TXT. Configuration options: [Disabled] [Enabled]

#### VMX [Enabled]

Allows you to enable or disable Vanderpool Technology. Configuration options: [Disabled] [Enabled]

#### Enable SMX [Disabled]

Allows you to enable or disable Safer Mode Extensions. Configuration options: [Disabled] [Enabled]

#### Lock Chipset [Enabled]

Allows you to lock or unlock the chipset. Configuration options: [Disabled] [Enabled]

#### MSR Lock Control [Enabled]

Allows you to lock or unlock MSR 3Ah and CSR 80h. Configuration options: [Disabled] [Enabled]

#### PPIN Control [Unlock/Enabled]

Allows you to enable or disable PPIN Control. Configuration options: [Lock/Disabled] [Unlock/Enabled]

#### AES-NI [Enabled]

Allows you to enable or disable the AES-NI support. Configuration options: [Disabled] [Enabled]

#### TME, TME-MT, TDX

#### Total Memory Encryption (TME) [Disabled]

Allows you to enable or disable Total Memory Encryption (TME). Configuration options: [Disabled] [Enabled]



The following item appears only when Total Memory Encryption (TME) is set to [Enabled].

#### Total Memory Encryption (TME) Bypass [Auto]

Allows you to configure Total Memory Encryption (TME) Bypass. Configuration options: [Auto] [Disabled] [Enabled]

#### Software Guard Extension (SGX)



The following items are available only when **Total Memory Encryption (TME)** is set to **[Enabled]**.

#### SGX Factory Reset [Disabled]

Allows you to factory reset SGX and reset all SGX BIOS knobs to default values.

#### SW Guard Extensions (SGX) [Disabled]

Allows you to enable or disable Software Guard Extensions (SGX) Configuration options: [Disabled] [Enabled]

#### SGX Package Info In-Band Access [Disabled]

Allows you to enable or disable Software Guard Extensions (SGX) Package Info Inband Access.

Configuration options: [Disabled] [Enabled]

#### In Field Test (IFT)



The following items appear only when Total Memory Encryption (TME) is set to [Enabled].

#### Enable SAF [Enabled]

Allows you to enable or disable Scan at Field (SAF). Configuration options: [Disabled] [Enabled]

#### SAF Size [128M]

Allows you to set the SAF size region inside the PRM.

#### **PSMI** Configuration

#### Global PSMI Enable [Enabled]

Configuration options: [Disabled] [Enabled] [Force setup]



The following item appears only when **Global PSMI Enable** is set to [Enabled] or [Force setup].

#### Socket 0/1 Configuration

#### **PSMI Enable [Disabled]** Configuration options: [Disabled] [Enabled]



The following items appear only when PSMI Enable is set to [Enabled].

#### PSMI Handler Size [256K] Configuration options: [256K] [512K] [1M]

**PSMI Trace Region 0-4 [Disable]** Configuration options: [Disabled] [Enabled]



The following items appear only when **PSMI Trace Region** is set to [Enabled].

#### Buffer Size [1M]

Configuration options: [1M] [2M] [4M] [8M] [16M] [32M] [64M] [128M] [256M] [512M] [1G] [2G] [4G] [8G] [16G] *Cache Type [Any]* Configuration options: [Any] [Uncached] [Write Combine]

#### **Processor CFR Configuration**

#### Provision S3M CFR [Enabled]

Allows you to enable or disable S3M CFR provisioning. Configuration options: [Disabled] [Enabled]

#### Manual Commit S3M FW CFR [Disabled]

Allows you to manually commit S3M FW CFR. Configuration options: [Disabled] [Enabled]

#### Provision PUcode CFR [Enabled]

Allows you to enable or disable PUCode CFR provisioning. Configuration options: [Disabled] [Enabled]

#### Manual Commit PUCode CFR [Disabled]

Allows you to manually commit PUCode CFR. Configuration options: [Disabled] [Enabled]

#### Socket0-3 CFR Revision Info

Allows you to view the CFR revision information for the selected socket.

## 4.7.2 Common RefCode Configuration

Aptio Setup – AMI Socket Configuration			
Common RefCode Configur	ration	Divide physical NUMA nodes into evenly sized virtual NUMA	
Numa	[Enable]	nodes in ACPI table. This may improve Windows performance on	
Uniform Memory Access current system configur	(UMA) cannot be enabled with the ration	CPUs with more than 64 logical processors.	
Virtual Numa			

#### Virtual Numa [Enabled]

Allows you to enable or disable virtual non-uniform memory access (NUMA). Configuration options: [Disabled] [Enabled]

#### UMA-Based Clustering [Quadrant (4-Clusters)]

Allows you to set the UMA-based clustering mode.

Configuration options: [Hemisphere (2-clusters)] [Quadrant (4-clusters)]

## 4.7.3 Uncore Configuration

	Aptio Setup – AMI Socket Configuration	
Uncore Configuration		Displays and provides option to change the Uncore General
<ul> <li>Uncore General Configuration</li> <li>Uncore Per Socket Configuration</li> </ul>		Settings

#### **Uncore General Configuration**

#### **Uncore Status**

Allows you to view the Uncore status.

#### MMCFG Base [Auto]

Allows you to set the MMCFG Base. Configuration options: [1G] [1.5G] [1.75G] [2G] [2.25G] [3G] [Auto]

#### MMCFG Size [Auto]

Allows you to set the MMCFG Size. Configuration options: [64M] [128M] [256M] [512M] [1G] [2G] [Auto]

#### MMIO High Base [32T]

Allows you to set the MMIO High Base. Configuration options: [56T] [40T] [32T] [24T] [16T] [4T] [2T] [1T] [512G] [3584T]

#### MMIO High Base [256G]

Allows you to set the MMIO High Granularity Size. Configuration options: [1G] [4G] [16G] [64G] [256G] [1024G]

#### Limit CPU PA to 46 bits [Enabled]

Allows you to limit CPU physical address to 46 bits to support older Hyper-V. Automatically disables TME-MT if enabled. Configuration options: [Disabled] [Enabled]

#### **Uncore Per-Socket Configuration**

#### CPU 1-8 UPI Port

#### Link Disable [No]

Allows you to enable or disable the selected UPI port.

Configuration options: [No (Enable)] [Yes (Disable)]

#### Current UPI Link Speed [Auto]

Allows you to select the UPI link frequency. The Auto setting is based on Si Compatibility.

Configuration options: [12.8GT/s] [14.4GT/s] [16.0GT/s] [Auto]

## 4.7.4 Memory Configuration

	Aptio Setup – AMI Socket Configuration	
		Enforces Plan Of Record restrictions for DDR frequency programming.
Enforce DDR Memory Frequency POR Enforce Population POR Memory Frequency Sockets in parallel Attempt Fast Boot Attempt Fast Boot Data Scrambling for PMem Data Scrambling for PMem	[POR] [Enable] [Auto] [Auto] [Enable] [Enable] [Auto] [Foreble]	
Data Scrambling for DDR4/5 Enable ADR Memory Topology Memory Map Memory RAS Configuration P Mem Configuration	(Enable) [Enable]	++: Select Screen ↑↓: Select Item Enter: Select ≁/-: Change Opt, F1: General Help

#### Enforce DDR Memory Frequency POR [POR]

Allows you to enforce POR restrictions for DDR frequency and voltage programming. If this item is set to **[Disabled]**, system memory can be run at frequencies higher than the memory supports, specified in the Memory Frequency field (limited by processor support). Configuration options: [POR] [Disabled]

#### **Enforce Population POR [Enabled]**

Allows you to enforce POR restrictions for memory population.

Configuration options: [Disabled] [Enabled]

#### Memory Frequency [Auto]

Allows you to set the maximum memory frequency in MHz. If Enforce POR is disabled, system memory can be run at frequencies higher than the memory supports (limited by processor support).

Configuration options: [Auto] [3200] [3600] [4000] [4400] [4800]

#### Sockets in Parallel [All]

Allows you to set the number of sockets operating in parallel.

Configuration options: [All] [1] [2] [4]

#### Attempt Fast Boot [Enabled]

Allows you to enable or disable fast boot. Portions of memory reference code will be skipped when possible to increase boot speed on warm boots.

Configuration options: [Disabled] [Enabled]

#### Attempt Fast Cold Boot [Enabled]

Allows you to enable or disable fast cold boot. Portions of memory reference code will be skipped when possible to increase boot speed on cold boots.

Configuration options: [Disabled] [Enabled]

#### Data Scrambling for PMem [Auto]

Allows you to enable or disable data scrambling for PMem. If set to Auto, data scrambling will be enabled or disabled depending on stepping.

Configuration options: [Disabled] [Enabled] [Auto]

#### Data Scrambling for DDR4/5 [Enabled]

Allows you to enable or disable data scrambling for DDR4/5. Configuration options: [Disabled] [Enabled]

#### Enable ADR [Enabled]

Allows you to enable or disable ADR. Automatically enabled if fADR is enabled. Configuration options: [Disabled] [Enabled]

#### **Memory Topology**

Displays memory topology with DIMM population information.

#### **Memory Map**

Allows you to set memory mapping settings.

#### Volatile Memory Mode [2LM]

Selects 1LM or 2LM mode for volatile memory. For 2LM memory mode, BIOS will try to configure 2LM, but if BIOS is unable to configure 2LM, volatile memory mode will fall beck to 1LM.

Configuration options: [1LM] [2LM]

#### **Memory RAS Configuration**

Displays and provides options to change the memory RAS Settings.

#### Dynamic ECC Mode Selection [Enabled]

Allows you to enable or disable Dynamic ECC Mode Selection. Configuration options: [Disabled] [Enabled] [Enabled + Allow 128b ECC]

#### Enable PCode WA for SAI PG [Disabled]

Allows you to enable or disable the PCode workaround for SAI Policy Group for A Step. Configuration options: [Disabled] [Enabled]

#### Mirror Mode [Disabled]

Allows you to set the mirror mode. Full mirror mode will set the entire 1LM memory in system to be mirrored, consequently reducing the memory capacity by half. Partial mirror mode will set the mirror size according to the Partial Mirror Size field. If rank sparing is enabled, partial mirroring will not take effect.

Configuration options: [Disabled] [Full Mirror Mode] [Partial Mirror Mode]



The following items appear only when Mirror Mode is set to [Partial Mirror Mode].

#### Partial Mirror 1 Size (GB) [0]

Allows you to set the size of the created SAD in GB.

#### Mirror TAD0 [Disabled]

Allows you to enable or disable mirror of the entire memory for TAD0. Configuration options: [Disabled] [Enabled]

#### UEFI ARM Mirror [Disabled]

Allows you to enable or disable imitation of UEFI based address range mirror. Configuration options: [Disabled] [Enabled]



The following items appear only when UEFI ARM Mirror is set to [Enabled].

#### ARM Mirror Percentage [0]

Allows you to set the percantage to be mirrored in basis points. 12.75% is represented as 1275.

#### Memory Correctable Error Flood Policy [Frequency]

Allows you to set the Memory Correctable Error Flood Policy.

[Disabled] Ignore Memory CE Flood.

[Once] Only first Memory CE will trigger SMI.

[Frequency] Disable SMI when Memory CE reaches threshold within time limit.

#### Correctable Error Threshold [7FFF]

Allows you to set the Correctable Error Threshold (0x01 - 0x7fff) used for sparing and leaky bucket.

#### Trigger SW Error Threshold [Disabled]

Allows you to enable or disable the Trigger SW Error Threshold. Configuration options: [Disabled] [Enabled]



The following items appear only when Trigger SW Error Threshold is set to [Enabled].

#### SW Per Bank Threshold [3]

Allows you to set the SW Per Bank Correctable Error Threshold (1 - 0x7FFF) used for bank level errors.

SW Correctable Error Time Window [24] Allows you to set the SW Correctable Error time window in hours (0 - 24)

#### Leaky Bucket Time Window Based Interface [Disabled]

Allows you to enable or disable the Leaky Bucket Time Window Based Interface. Configuration options: [Disabled] [Enabled]



The following items appear only when Leaky Bucket Time Window Based Interface is set to [Enabled].

Leaky Bucket Time Window Based Interface Hour [24] Allows you to set the time window hour.

Leaky Bucket Time Window Based Interface Minute [0] Allows you to set the time window minute.



The following items appear only when Leaky Bucket Time Window Based Interface is set to [Disabled].

Leaky Bucket Low Bit [28] Allows you to set the Leaky Bucket low bit. Leaky Bucket High Bit [29] Allows you to set the Leaky Bucket high bit.

#### ADDDC Sparing [Disabled]

Allows you to enable or disable ADDDC Sparing. Configuration options: [Disabled] [Enabled]

#### Patrol Scrub [Enabled at End of POST]

Allows you to enable or disable Patrol Scrub. Configuration options: [Disabled] [Enabled at End of POST]



The following items appear only when Patrol Scrub is set to [Enabled at End of POST].

#### Patrol Scrub Interval [24]

Allows you to set the number of hours (1-24) required to complete a full scrub.

#### DDR5 ECS [Disabled]

Allows you to enable or disable DDR5 Error Check and Scrub (ECS) Configuration options: [Disabled] [Enabled]

#### **PMem Configuration**

Displays and provides options to change the PMem settings.

#### PMem Secure Erase Unit

Allows you to securely erase the persistent memory region of the selected DIMMs.

#### PMem Factory Reset/Clear [Disabled]

Allows you to factory reset or clear PMem. PMem Power Policy settings will also be set to default values.

Configuration options: [Disabled] [Enabled]

#### PMem Average Power Limit (in mW) [15000]

Allows you to set the power limit in mW used for average power. Valid range starts from 10,000mW and must be a multiple of 250mW.

#### PMem Turbo/Memory Bandwidth Boost (MBB) [Disabled]

Allows you to enable or disable the Turbo/Memory Bandwidth Boost (MBB) feature. Configuration options: [Disabled] [Enabled]



The following items appear only when Trigger SW Error Threshold is set to [Enabled].

#### PMem MBB Average Power Time Constant [15000]

Allows you to set the base time window for power usage requirements in msec. Valid range is between 1,000msec and 120,000msec and must be a multiple of 1,000msec.

#### PMem MBB Power Limit [18000]

Allows you to set the power limit for the Memory Bandwidth Boost power consumption. Valid range starts from 15,000mW.

#### Publish ARS Capability [Enabled]

Allows you to enable or disable publishing of the Address Range Scrub capability to the OS.

Configuration options: [Disabled] [Enabled]

#### PMem ECC Read Check [Enabled]

Allows you to enable or disable PMem ECC Read Check.

Configuration options: [Disabled] [Enabled]

#### PMem Latch System Shutdown State [Enabled]

Allows you to set the Latch System Shutdown State. Configuration options: [Disabled] [Enabled]

#### Power Cycle on PMem Surprise Clock Stop [Enabled]

Allows you to enable or disable the power policy when PMem receives a surprise clock stop.

Configuration options: [Disabled] [Enabled]

#### Snoopy Mode for AD [Disabled]

Allows you to enable or disable AD-specific features to avoid directory updates to PMem memory from non-NUMA optimized workloads. Configuration options: [Disabled] [Enabled]

#### LSx Implementation [ASL]

Allows you to select the LSx implementation method. Configuration options: [SWSMI] [ASL]

#### Extended Type 17 Structure [Enabled]

Allows you to enable or disable extended Type 17 SMBIOS structures. Configuration options: [Disabled] [Enabled]

#### SMBus Max Access Time [350]

Allows you to set the maximum amount of time in milliseconds the UEFI management driver is allowed to use the SMBus.

#### SMBus Release Delay [150]

Allows you to set the delay in milliseconds before releasing after the UEFI management driver requests a SMbus release.

#### NVDimm Mailbox in NFIT [Disabled]


Allows you to enable or disable publishing NVDIMM registers in NFIT structures. Configuration options: [Disabled] [Enabled]

#### Seamless: Opt-in DIMMs [Keep]

Allows you to keep, enable, or disable opt-in DIMMs if supported by FW. FW activation does not update the FW digest CSR.

Configuration options: [Keep] [Disabled] [Enabled]

## 4.7.5 IIO Configuration



#### Intel(R) VT for Directed I/O (VT-d)

#### Intel(R) VT for Directed I/O (VT-d) [Enabled]

Allows you to enable or disable the Intel Virtualization Technology for Directed I/O (VT-d) by reporting the I/O device assignment to VMM through DMAR ACPI Tables. Configuration options: [Disabled] [Enabled]

### 4.7.6 Advanced Power Management Configuration



#### CPU P State Control

Displays and provides options to change the CPU P State settings.

#### AVX Licence Pre-Grant Override [Disabled]

Enabled AVX ICCP pre-grant level override. Configuration options: [Disabled] [Enabled]



The following item appears only when AVX Licence Pre-Grant Override is set to [Enable].

#### AVX ICCP pre-grant level [128 Heavy]

Pre-grants an AVX level to the core. Base frequency is not updated. Configuration options: [128 Heavy] [256 Light] [256 Heavy] [512 Light] [512 Heavy]

#### SpeedStep (Pstates) [Enabled]

Allows you to enable or disable EIST (P-States). Configuration options: [Disabled] [Enabled]



The following items appear only when SpeedStep (Pstates) is set to [Enable].

#### AVX P1 [Nominal]

AVX P1 level selection. Configuration options: [Nominal] [Level 1] [Level 2]

#### Turbo Mode [Enabled]

Allows you to enable or disable processor turbo mode. Requires EMTTM to be enabled.

Configuration options: [Disabled] [Enabled]

#### Dynamic SST-PP [Disabled]

Allows you to enable or disable dynamic SST-PP selection. Configuration options: [Disabled] [Enabled]



The following item appears only when Dynamic SST-PP is set to [Disabled].

#### Intel SST-PP [Auto]

Intel SST-PP level selection. Configuration options: [Auto] [Level 0] [Level 3] [Level 4]

#### Activate SST-BF [Disabled]

Allows you to enable or disable SST-BF. Configuration options: [Disabled] [Enabled]

#### Configure SST-BF [Enabled]

Allows BIOS to configure SST-BF High Priority Cores so that SW does not have to configure.

Configuration options: [Disabled] [Enabled]

#### Boot performance mode [Max Performance]

Allows you to select the performance state that the BIOS will set before OS hand off. Configuration options: [Max Performance] [Max Efficient] [Set by Intel Node Manager]

#### Energy Efficient Turbo [Enable]

Allows you to enable or disable Energy Efficient Turbo. Configuration options: [Disable] [Enable]

#### Hardware PM State Control

#### Hardware P-States [Native Mode]

Allows you to select a hardware P-state. Configuration options: [Disabled] [Native Mode] [Out of Band Mode] [Native Mode with No Legacy Support]

#### **Frequency Prioritization**

#### SST-CP [Disabled]

Allows you to enable or disable per-core power budgeting. Configuration options: [Disabled] [Enabled]

#### **CPU C State Control**

#### Enable Monitor MWAIT [Auto]

Allows you to enable or disable Monitor and MWAIT instructions. Configuration options: [Disable] [Enable] [Auto]

#### CPU C1 auto demotion [Enabled]

Allows CPU to automatically demote to C1. Takes effect after reboot. Configuration options: [Disabled] [Enabled]

#### CPU C1 auto undemotion [Enabled]

Allows CPU to automatically undemote from C1. Takes effect after reboot. Configuration options: [Disabled] [Enabled]

#### CPU C6 Report [Auto]

Allows you to enable or disable CPU C6 (ACPI C3) report to OS. Configuration options: [Disabled] [Enabled] [Auto]

#### Enhanced Halt State (C1E) [Enabled]

Core C1E auto promotion Control. Takes effect after reboot. Configuration options: [Disabled] [Enabled]

#### OS ACPI Cx [ACPI C2]

Allows you to select whether CC3/CC6 is reported to OS ACPI C2 or ACPI C3. Configuration options: [ACPI C2] [ACPI C3]

#### Package C State Control

#### Package C State [Auto]

Allows you to select Package C State limit. Configuration options: [C0/C1 state] [C2 state] [C6 (non-retention state] [C6 (retention state] [No limit] [Auto]

## 4.8 Security menu

This menu allows a new password to be created or a current password to be changed. The menu also enables or disables the Secure Boot state and lets the user configure the System Mode state.

	Aptio Setup — AMI	
Main Advanced Platform Confi	guration Socket Configuration	Security Boot Tool
Password Description If ONLY the Administrator's pas limits access to Setup and is o Setup. If ONLY the User's password is password and must be entered to In Setup the User will have Adm The password length must be in is a power on password and must boot or enter Setup. In Setup t have Administrator rights. The password length must be	nly asked for when entering set, then this is a power on boot or enter Setup. inistrator rights. the following range: be entered to	To clear the administrator password, key in the current password in the Enter Current Password box, and then press <enter> when prompted to create/confirm the password.</enter>
in the following range:		++: Select Screen
Minimum length	3	f↓: Select Item
Maximum length	20	Enter: Select
Administrator Password User Password		+/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes & Reset F12: Print Screen
▶ Secure Boot		ESC: Exit
		22 AMI

#### **Administrator Password**

To set an administrator password:

- 1. Select the Administrator Password item and press <Enter>.
- 2. From the Create New Password box, key in a password, then press <Enter>.
- 3. Confirm the password when prompted.

To change an administrator password:

- 1. Select the Administrator Password item and press < Enter>.
- 2. From the Enter Current Password box, key in the current password, then press <Enter>.
- 3. From the Create New Password box, key in a new password, then press <Enter>.
- 4. Confirm the password when prompted.



To clear the administrator password, follow the same steps as in changing an administrator password, but press <Enter> when prompted to create/confirm the password.

#### **User Password**

To set a user password:

- 1. Select the User Password item and press <Enter>.
- 2. From the Create New Password box, key in a password, then press <Enter>.
- 3. Confirm the password when prompted.

To change a user password:

- 1. Select the User Password item and press <Enter>.
- 2. From the Enter Current Password box, key in the current password, then press <Enter>.
- 3. From the Create New Password box, key in a new password, then press < Enter>.
- 4. Confirm the password when prompted.

To clear a user password:

- 1. Select the Clear User Password item and press <Enter>.
- 2. Select Yes from the Warning message window, then press <Enter>.

#### 4.8.1 Secure Boot

This item allows you to customize the Secure Boot settings.

	Aptio Setup – AMI	
		Security
Secure Boot state	User	Secure Boot feature is Active if Secure Boot is Enabled,
Secure Boot	[Disabled] Not Active	Platform Key(PK) is enrolled and the System is in User mode. The mode change requires
Secure Boot Mode	[Custom]	platform reset
▶ Install Default Secure Boot Keys		
▶ Clear Secure Boot Keys		
▶ Key Management		

#### Secure Boot [Disabled]

Secure Boot feature is active if Secure Boot is Enabled, Platform Key (PK) is enrolled and the system is in User mode. The mode change requires platform reset. Configuration options: [Disabled] [Enabled]

#### Secure Boot Mode [Custom]

Allows you to set the Secure Boot selector. In Custom mode, Secure Boot Policy variables can be configured physically by the present user without full authentication. Configuration options: [Custom] [Standard]



The following items are available only when Secure Boot Mode is set to [Custom].

#### Install Default Secure Boot Keys

This option will load the default secure boot keys, including the PK (Platform key), KEK (keyexchange key), db (signature database), and dbx (revoked signature database). All the secure boot keys states will change from unloaded to loaded. Save changes and reset the system for the changes to take effect.

#### **Clear Secure Boot Keys**

This option will delete all previously applied secure boot keys, including the PK (Platform key), KEK (key-exchange key), db (signature database), and dbx (revoked signature database). All the secure boot keys states will change from unloaded to loaded. Save changes and reset the system for the changes to take effect.

#### **Key Management**

This item only appears when the item **Secure Boot Mode** is set to **[Custom]**. The Key Management item allows you to modify Secure Boot variables and set Key Management page.

	Aptio Setup – AMI	Security
Vendor Keys	Valid	Install factory default Secure Boot keys after the platform
Factory Key Provision ▶ Install Default Secure Boot ▶ Clear Secure Boot Keys ▶ Enroll Efi Image	[Enabled] Keys	reset and while the System is in Setup mode
<ul> <li>Save all Secure Boot variable</li> <li>Secure Boot variable   Size</li> <li>PK Management   886</li> <li>KEK Management   6322</li> <li>DB Management   6322</li> </ul>	;  Keys  Key Source ;  1  Default 3  Default	
<ul> <li>DBX Management   3724 </li> <li>Authorized TimeStamps(dbt) </li> <li>OsRecovery Signatures(dbr) </li> </ul>	0  0  No Keys	++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults

#### Factory Key Provision [Enabled]

Allows you to provision factory default Secure Boot keys when the system is in Setup Mode.

Configuration options: [Disabled] [Enabled]

#### Install Default Secure Boot Keys

This option will load the default secure boot keys, including the PK (Platform key), KEK (key-exchange key), db (signature database), and dbx (revoked signature database). All the secure boot keys states will change from unloaded to loaded. Save changes and reset the system for the changes to take effect.

#### **Clear Secure Boot Keys**

This option will delete all previously applied secure boot keys, including the PK (Platform key), KEK (key-exchange key), db (signature database), and dbx (revoked signature database). All the secure boot keys states will change from unloaded to loaded. Save changes and reset the system for the changes to take effect.

#### Enroll Efi Image

This item will allow the image to run in Secure Boot mode. Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db).

#### Save all Secure Boot Variables

This option will save NVRAM content of Secure Boot policy variables to the file (EFI\_ SIGNATURE\_LIST data format) in root foler on a target file system device.

#### **PK Management**

Configuration options: [Details] [Save To File] [Set New Key] [Delete key]

#### KEK Management / DB Management / DBX Management

Configuration options: [Details] [Save To File] [Set New Key] [Append Key] [Delete key]

#### Authorized TimeStamps / OsRecovery Signatures

Configuration options: [Set New Key] [Append Key]

## 4.9 Boot menu

The Boot menu items allow you to change the system boot options.

Aptio Setup – AMI Main Advanced Platform Configuration Socket Configuration Security <mark>Boot</mark> Tool ♪			
Boot Configuration Setup Prompt Timeout Bootup NumLock State Boot Logo Display	5 [On] [Disabled]	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.	
Boot Option Priorities Boot Option #1	[UEFI: JetFlashTranscend 46B 8.07, Partition 1 (4.06B)]		
		<pre>++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes &amp; Reset F12: Print Screen ESC: Exit</pre>	
Versic	n 2.22.1284 Copyright (C) 20	22 AMI	

#### Setup Prompt Timeout [1]

Allows you to set the number of seconds that the firmware waits before initiating the original default boot selection. 65535(OxFFFF) means indefinite waiting. Use the <+> or <-> to adjust the value.

#### Bootup NumLock State [On]

Allows you to select the power-on state for the NumLock. Configuration options: [Off] [On]

#### Boot Logo Display [Disabled]

[Disabled] Hide the logo during POST.

[Enabled] Display the logo during POST.

#### **Boot Option Priorities**

These items specify the boot device priority sequence from the available devices. The number of device items that appears on the screen depends on the number of devices installed in the system.



- To select the boot device during system startup, press <F11> when logo appears.
- To access Windows OS in Safe Mode, please press <F8> after POST.

## 4.10 Tool menu

The Tool menu items allow you to configure options for special functions. Select an item, then press <Enter> to display the submenu.

Aptio Setup – AMI Main Advanced Platform Configuration Socket Configuration	Security Boot Tool
Start ASUS EzFlash IPMI Hardware Monitor ASUS SMBIOS Viewer ASUS Storage Viewer	Press ENTER to run the utility to select and update BIOS.
	++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes & Reset F12: Print Screen ESC: Exit
Version 2.22.1284 Copyright (C) 202	

#### Start ASUS EzFlash

Allows you to start the ASUS EzFlash BIOS ROM Utility. Refer to the ASUS EzFlash Utility section for details.

#### **IPMI Hardware Monitor**

Allows you to start the IPMI hardware monitor.

#### **ASUS SMBIOS Viewer**

Allows you to start the ASUS SMBIOS Viewer.

#### **ASUS Storage Viewer**

Allows you to start the ASUS Storage Viewer.

## 4.11 Event Logs menu

The Event Logs menu items allow you to change the event log settings and view the system event logs.



## 4.11.1 Change Smbios Event Log Settings

Press <Enter> to change the Smbios Event Log configuration.



All values changed here do not take effect until computer is restarted.

Event Logs	Aptio Setup – AMI	
Enabling/Disabling Options Smbios Event Log	[Enabled]	Change this to enable or disable all features of Smbios Event Logging during boot.
Erasing Settings		
Erase Event Log	[No]	
When Log is Full	[Do Nothing]	
Custom Options		
Log EFI Status Code	[Enabled]	
Convert EFI Status Codes to	[Disabled]	
Standard Smbios Type	[DISUDICU]	
NOTE: All values changed here do	not take	
effect until computer is restarted.		++: Select Screen

#### **Enabling/Disabling Options**

#### Smbios Event Log [Enabled]

Change this to enable or disable all features of Smbios Event Logging during boot. Configuration options: [Disabled] [Enabled]



The following items only appear when Smbios Event Log is set to [Enabled].

#### **Erasing Settings**

#### Erase Event Log [No]

Choose options for erasing Smbios Event Log. Erasing is done prior to any logging activation during reset.

Configuration options: [No] [Yes, Next reset] [Yes, Every reset]

#### When Log is Full [Do Nothing]

Choose options for reactions to a full Smbios Event Log. Configuration options: [Do Nothing] [Erase Immediately]

#### **Custom Options**

#### Log EFI Status Code [Enabled]

Allows you to enable or disable the logging of EFI Status Codes as OEM reserved type E0 (if not already converted to legacy).

Configuration options: [Disabled] [Enabled]



The following item only appears when Log EFI Status Code is set to [Enabled].

#### Convert EFI Status Codes to Standard Smbios Type [Disabled]

Allows you to enable or disable the converting of EFI Status Codes to Standard Smbios Types (not all may be translated).

Configuration options: [Disabled] [Enabled]

## 4.11.2 View Smbios Event Log

Press <Enter> to view all smbios event logs.

Aptio Setup - AMI Event Logs					
DATE	TIME	ERROR CODE	SEVERITY	COUNT	DESCRIPTION Log Area Reset
01/01/98					-
07/18/22	14:56:50	EFI 03051002	Major	01	

## 4.12 Server Mgmt menu

The Server Management menu displays the server management status and allows you to change the settings.

✓ Event Logs Server Mgmt Exit	Aptio Setup – AMI	
BMC Self Test Status BMC Device ID BMC Device Revision BMC Firmware Revision IPMI Version DS Matchdog Timer DS Wtd Timer Timeout DS Wtd Timer Policy Serial Mux	PASSED 32 81 1.00.01 2.0 [Disabled] 10 [Reset] [Disabled]	If enabled, starts a BIOS timer which can only be shut off by Management Software after the OS loads. Helps determine that the OS successfully loaded or follows the OS Boot Watchdog Timer policy.
<ul> <li>System Event Log</li> <li>View FRU information</li> <li>BMC network configuration</li> <li>View System Event Log</li> </ul>		<pre>++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes &amp; Reset F12: Print Screen ESC: Exit</pre>

#### OS Watchdog Timer [Disabled]

This item allows you to start a BIOS timer which can only be shut off by Management Software after the OS loads. Helps determine if the OS successfully loaded or follows the OS Boot Watchdog Timer policy.

Configuration options: [Disabled] [Enabled]

The following items are available only when OS Watchdog Timer is set to [Enabled].

#### OS Wtd Timer Timeout [10]

Allows you to enter a value between 1 to 30 minutes for OS Boot Watchdog Timer Expiration. Not available if OS Boot Watchdog Timer is disabled. Configuration options: [1] - [30]

#### OS Wtd Timer Policy [Reset]

This item allows you to configure the how the system should respond if the OS Boot Watch Timer expires. Not available if OS Boot Watchdog Timer is disabled. Configuration options: [Do Nothing] [Reset] [Power Down] [Power Cycle]


#### Serial Mux [Disabled]

Allows you to enable or disable Serial Mux configuration.

Configuration options: [Disabled] [Enabled]

## 4.12.1 System Event Log

Allows you to change the SEL event log configuration.



#### SEL Components [Enabled]

Allows you to enable or disable event logging for error/progress codes during boot. Configuration options: [Disabled] [Enabled]



The following item is available only when SEL Components is set to [Enabled].

#### Erase SEL [No]

Allows you to choose options for erasing SEL. Configuration options: [No] [Yes, On next reset] [Yes, On every reset]

## 4.12.2 View FRU Information

Allows you to view the FRU information.

## 4.12.3 BMC network configuration

The sub-items in this configuration allow you to configure the BMC network parameters. Scroll using <Page Up> / <Page Down> keys to see more items.

BMC network configuration **************************** Configure IPv4 support *******		<ul> <li>Select to configure LAN</li> <li>channel parameters statically</li> </ul>
***		or dynamically(by BIOS or
		BMC). Unspecified option will
		not modify any BMC network
DM_LAN		parameters during BIOS phase
Station IP address		
Subnet mask		
Station MAC address	30-5A-3F-00-93-03	
Router IP address	0.0.0.0	
Router MAC address	00-00-00-00-00	
Shared LAN		++: Select Screen
Configuration Address source	[Unspecified]	↑↓: Select Item
Current Configuration Address	DynamicAddressBmcDhcp	Enter: Select
source		+/-: Change Opt.
Station IP address	0.0.0.0	F1: General Help
Subnet mask	0.0.0.0	F2: Previous Values
Station MAC address	30-5A-3F-00-93-04	F5: Optimized Defaults
Router IP address	0.0.0	F10: Save Changes & Reset
Router MAC address	00-00-00-00-00	F12: Print Screen
Router MAC address	00-00-00-00-00	F12: Print Screen ESC: Exit

#### **Configure IPV4 support**

#### DM\_LAN / Shared LAN

#### Configuration Address source [Unspecified]

Allows you to set the LAN channel parameters statically or dynamically (by BIOS or by BMC). **[Unspecified]** option will not modify any BMC network parameters during BIOS phase.

Configuration options: [Unspecified] [Static] [DynamicBmcDhcp]



The following items are available only when **Configuration Address source** is set to **[Static]**.

#### Station IP address

Allows you to set the station IP address.

#### Subnet mask

Allows you to set the subnet mask. We recommend that you use the same Subnet Mask you have specified on the operating system network for the used network card.

#### **Router IP Address**

Allows you to set the router IP address.

#### **Router MAC Address**

Allows you to set the router MAC address.

#### **Configure IPV6 support**

#### DM\_LAN / Shared LAN

#### IPV6 support [Enabled]

Allows you to enable or disable IPV6 support. Configuration options: [Enabled] [Disabled]



The following items appear only when IPV6 support is set to [Enabled].

#### Configuration Address source [Unspecified]

Allows you to set the LAN channel parameters statically or dynamically (by BIOS or by BMC). [Unspecified] option will not modify any BMC network parameters during BIOS phase. Configuration options: [Unspecified] [Static] [DynamicBmcDhcp]



The following items are available only when **Configuration Address source** is set to **[Static]**.

#### Station IPV6 address

Allows you to set the station IPV6 address.

Prefix Length [0]

Allows you to set the prefix length (maximum Prefix Length is 128).

#### Configuration Router Address source [Unspecified]

Allows you to set the LAN channel parameters statically or dynamically (by BIOS or by BMC). [Unspecified] option will not modify any BMC network parameters during BIOS phase. Configuration options: [Unspecified] [Static] [DynamicBmcDhcp]



The following items are available only when **Configuration Router Address source** is set to [Static].

#### **IPV6 Router IP Address**

Allows you to set the IPV6 router address.

#### Prefix Length [0]

Allows you to set the prefix length (maximum Prefix Length is 128).

#### Prefix Value

Allows you to set the prefix value.

## 4.12.4 View System Event Log

This item allows you to view the system event log records. Scroll using <Page Up> / <Page Down> keys to see more items.

Aptio Setup – AMI Server Mgmt	
No. of log entries in SEL : 0	
<< System Event Log Is Empty >>	++: Select Screen 1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes & Reset
	F12: Print Screen ESC: Exit

## 4.13 Save & Exit menu

The Save & Exit menu items allow you to save or discard your changes to the BIOS items.

Aptio Setup - AMI ≰ Event Logs Server Mgmt <mark>Exit</mark>	
Save Options Discard Changes & Exit	Exit system setup without saving any changes.
Save Changes & Reset Discard Changes and Reset	
Save Changes Discard Changes	
Default Options Load Optimized Defaults	
Boot Override UEFI: JetFlashTranscend 46B 8.07, Partition 1 (4.06B) Launch EFI Shell from USB drives	++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F5: Optimized Defaults F10: Save Changes & Reset F12: Print Screen ESC: Exit

Pressing <Esc> does not immediately exit this menu. Select one of the options from this menu or <F10> from the legend bar to exit.

#### **Discard Changes and Exit**

Exit system setup without saving any changes.

#### Save Changes and Reset

Reset system after saving the changes.

#### **Discard Changes and Reset**

Reset system setup without saving any changes.

#### **Save Changes**

Save changes done so far to any of the setup options.

#### **Discard Changes**

Discard changes done so far to any of the setup options.

#### **Restore Defaults**

Restore/load default values for all the setup options.

#### **Boot Override**

These items displays the available devices. The device items that appears on the screen depends on the number of devices installed in the system. Click an item to start booting from the selected device.


# 5

## **RAID Configuration**

This chapter provides instructions for setting up, creating, and configuring RAID sets using the available utilities.

## 5.1 Setting up RAID

The motherboard supports the Intel<sup>®</sup> Rapid Storage Technology enterprise Option ROM Utility with RAID 0, RAID 1, RAID 10, and RAID 5 support (for Windows OS and Linux).

## 5.1.1 RAID definitions

RAID 0 (Data striping) optimizes two identical hard disk drives to read and write data in parallel, interleaved stacks. Two hard disks perform the same work as a single drive but at a sustained data transfer rate, double that of a single disk alone, thus improving data access and storage. Use of two new identical hard disk drives is required for this setup.

RAID 1 (Data mirroring) copies and maintains an identical image of data from one drive to a second drive. If one drive fails, the disk array management software directs all applications to the surviving drive as it contains a complete copy of the data in the other drive. This RAID configuration provides data protection and increases fault tolerance to the entire system. Use two new drives or use an existing drive and a new drive for this setup. The new drive must be of the same size or larger than the existing drive.

RAID 10 is data striping and data mirroring combined without parity (redundancy data) having to be calculated and written. With the RAID 10 configuration you get all the benefits of both RAID 0 and RAID 1 configurations. Use four new hard disk drives or use an existing drive and three new drives for this setup.

RAID 5 stripes both data and parity information across three or more hard disk drives. Among the advantages of RAID 5 configuration include better HDD performance, fault tolerance, and higher storage capacity. The RAID 5 configuration is best suited for transaction processing, relational database applications, enterprise resource planning, and other business systems. Use a minimum of three identical hard disk drives for this setup.



If you want to boot the system from a hard disk drive included in a created RAID set, copy first the RAID driver from the support DVD to a floppy disk before you install an operating system to the selected hard disk drive.

## 5.1.2 Installing hard disk drives

The motherboard supports Serial ATA and NVMe for RAID set configuration. For optimal performance, install identical drives of the same model and capacity when creating a disk array.

To install the SATA or NVMe hard disks for RAID configuration, please refer to the **Storage devices** section for more information.

## 5.1.3 RAID configuration utilities

Depending on the RAID connectors that you use, you can create a RAID set using the utilities embedded in each RAID controller. For example, use the **Intel® Rapid Storage Technology** if you installed Serial ATA hard disk drives on the Serial ATA connectors supported by the chipset.

Refer to the succeeding section for details on how to use the RAID configuration utility.

## 5.2 Intel<sup>®</sup> Virtual Raid on CPU in BIOS

This feature allows you to do CPU RAID functions with Intel® CPU RSTe.



- Due to chipset behavior, enabling the Intel<sup>®</sup> RSTe CPU RAID functions requires an Intel<sup>®</sup> VROC hardware key module.
- Refer to the Internal connectors section for the location of the VROC\_KEY1 connector.
- The KEY module is purchased separately.

To enter the Intel<sup>®</sup> Virtual Raid on CPU in BIOS:

- 1. Enter the BIOS Setup during POST.
- 2. Go to the Advanced menu > Intel(R) Virtual Raid on CPU > All Intel VMD Controllers, then press <Enter> to display the Intel<sup>®</sup> Virtual Raid on CPU menu.



Refer to the **BIOS Setup** chaper for details on entering and navigating through the BIOS Setup.

Aptio Setup Utility – Copyright (C) 2019 American Megatrends, Inc. Advanced	
	This page allows you to create
▶ Create RAID Volume	a RAID volume
Non-RAID Physical Disks:	
▶ Slot 110, B/D/F: 1/0/0, CPU1, VMD0 Port 0x3, INTEL SSDPE	
▶ Slot 111, B/D/F: 2/0/0, CPU1, VMDO Port 0x3, INTEL SSDPE	

## 5.2.1 Creating a RAID set

To create a RAID set:

1. From the Intel<sup>®</sup> Virtual Raid on CPU menu, select **Create RAID Volume** and press <Enter>. The following screen appears:

Aptio Setup Utility – Copyright (C) 2019 American Megatrends, Inc. Advanced		
Create RAID Volume		X – to Select Disk
Name: RAID Level: Enable RAID spanned over VMD Contr	Volume0 [RAIDO(Stripe)] [ ]	
Select Disks: Slot 110, B/D/F: 1/0/0, CPU1, VMD0 Slot 111, B/D/F: 2/0/0, CPU1, VMD0	[X] [X]	
Strip Size: Capacity (MB):	[128KB] 724944	
▶ Create Volume		++: Select Screen 14: Select Item Enter: Select +/-: Change Opt.

- 2. When the Name item is selected, enter a name for the RAID set and press <Enter>.
- When the RAID Level item is selected, press <Enter> to select the RAID level to create, and then press <Enter>.
- 4. When the Enable RAID spanned over VMD Controllers item is selected, press <Enter> and select X to enable this function.
- Under Select Disks, press <Enter> and select X for the disks you want to include in the RAID set.
- 6. When the Strip Size item is selected, press <Enter> to select strip size for the RAID array (for RAID 0, 10 and 5 only), and then press <Enter>. The available strip size values range from 4 KB to 128 KB. The following are typical values:
  - RAID 0: 128 KB
  - RAID 10: 64 KB
  - RAID 5: 64 KB



We recommend a lower strip size for server systems, and a higher strip size for multimedia computer systems used mainly for audio and video editing.

- When the Capacity (MB) item is selected, enter the RAID volume capacity that you want and press <Enter>. The default value indicates the maximum allowed capacity.
- When the Create Volume item is selected, press <Enter> to create the RAID volume and return to the Intel<sup>®</sup> Rapid Storage Technology menu.

## 5.2.2 Deleting a RAID set



Be cautious when deleting a RAID set. You will lose all data on the hard disk drives when you delete a RAID set.

To delete a RAID set:

1. From the Intel<sup>®</sup> Virtual Raid on CPU menu, select the RAID volume you want to delete and press <Enter>. The following screen appears:

Aptio Set	up Utility – Copyright (C) 2019 Ameri Advanced	can Megatrends, Inc.
RAID VOLUME INFO		
Volume Actions ▶ Delete		
Name: RAID Level: Strip Size: Size: Status: Bootable: Block size:	Volume0 RAIDO(Stripe) 128KB 700.0GB Normal Yes 512	
	CPU1, VMDO Port 0x3, INTEL SSDPE CPU1, VMDO Port 0x3, INTEL SSDPE	++: Select Screen 14: Select Item

 When the Delete item is selected, press <Enter>, then select Yes to delete the RAID volume and return to the Intel<sup>®</sup> Virtual Raid on CPU menu, or select No to cancel.

	Aptio Setup Utility – Copyright (C) 2019 American Megatrends, Inc. Advanced	
ſ		Deleting a volume will reset the disks to non–RAID.
	Delete the RAID volume? ALL DATA ON VOLUME WILL BE LOST!	
	Yes No	

# 5.3 Intel<sup>®</sup> Rapid Storage Technology enterprise (Windows)

The Intel® Rapid Storage Technology enterprise allows you to create RAID 0, RAID 1, RAID 10 (RAID 1+0), and RAID 5 set(s) from Serial ATA hard disk drives that are connected to the Serial ATA connectors supported by the Southbridge.



You need to manually install the Intel® Rapid Storage Technology enterprise utility on a Windows® operating system. Please refer to the installation instructions in Chapter 7.

To enter the Intel<sup>®</sup> Rapid Storage Technology enterprise utility under Windows operating system:

- 1. Turn on the system and go to the windows desktop.
- 2. Click the Intel® Rapid Storage Technology enterprise icon to display the main menu.

Your storage system is configured for data protection, increased performance and optimal data storage capacity. You can create additional volumes to further optimize your storage system.

Distel 8 Rapid Storage Technology enterprise		10 ×
Home Preferences		intel
Current Status Your system is functioning normal	y.	
Secon Create Volume		ATAPI Device Properties  Ducation: Controller 0, Port 5
Devices	Volumes	Location type: Internal Negotiated link rate: 1.5 Gb/s
🔻 🐋 Intel(R) C600 series chipset SAS RAID Controller		Model: ASUS DVD-E818A7T a Secial number: Not Available
* 🖼 SAS disk (559 GB)		Firmware: 1.00
• 📹 SAS disk (559 GB)		
• 🖅 SAS disk (559 GB)		
• 🖅 SAS disk (559 GB)		
• 🖅 SAS disk (559 GB)		
• 📹 SAS disk (SS9 GB) • 📹 SAS disk (SS9 GB)		
• 🕞 SAS disk (559 Ge)		
<ul> <li>Satel(R) C600 series chipset SATA RAID Controller</li> </ul>		
• 🚰 SATA disk (559 G8)		
• 🖅 SATA disk (559 GB)		
• 🖅 SATA disk (559 GB) • 🛒 SATA disk (559 GB)		
ATAPI Device		
Pic when benne		
Information		
Your storage system is configured for data protection, incre	ased performance and optimal data storage capacity. You can further optimize your storage system by creating additional vo	umes. To begin the process, click 'Create Volume'.
Click any device or volume to display its properties.		
SAS_Array_0000 D		
ISR10: Initializing 2% complete		
L		




You can click Rescan to re-scan any attached hard disks.

## 5.3.1 Creating a RAID set

To create a RAID set:

- 1. From the utility main menu, select Create Volume and select volume type.
- 2. Click Next.



- 3. Enter a name for the RAID set, then select the array disks.
- 4. Select Volume Size tab, you can drag the bar to decide the volume size.
- 5. Click Next.

L. Select	Configure Volume	Proposed Configuration
2. Configure	Name: Volume_0000	New Array
3. Confirm	Select the array disks (minimum selection required):	Volume_0000
	SAS disk on Controller 1, Phy 0 (279 GB)	
	SAS disk on Controller 1, Phy 0 (279 GB)	
	SAS disk on Controller 1, Phy 2 (279 GB)	
	SAS disk on Controller 1, Phy 4 (279 GB)	
	and also on controller 1, Phy 6 (275 Gb)	
	Volume Size Advanced	
	Volume Size 4.468 MB	
	Array allocation: 2% 灾	
	Each Next Carcol	More help on this p

- (E)
- If you do not want to keep the data on one of the selected disks, select NO when prompted.
- If you want to Enable volume write-back cache or Initialize volume, click Advanced.

6. Confirm the volume creation, than click **Create Volume** to continue.

~	
111	
/	
~	

This process could take a while depending on the number and size of the disks. You can continue using other applications during this time.


健 Create Volume		X
(2) Create Volume.       1. Select       2. Configure       3. Confirm	Confirm Volume Creation Review the selected configuration. This process could take a while depending on the number and size of the disks. You can continue using other applications during this time.	Proposed Configuration New Array Volume_0000
	Back Create Volume Cancel	More help on this page

7. Wait until the process is completed, then click **OK** when prompted.

Volume Creation Complete	×
The volume was created successfully.	
• You still need to partition your new volume using Windows Disk Management* before addir any data.	ıg
More help OK	

You still need to partition your new volume using Windows Disk Management before adding any data.

The RAID set is displayed in the **Volumes** list and you can change the settings in **Volume Properties**.



# 5.3.2 Changing a Volume Type

To change the volume type in Volume Properties:

- 1. Click the SATA array items you want to change in Volumes field.
- 2. From the Volume Properties field, select Type: RAID 1 Change type.

logy enterprise			intel)
r system is functioning normally	<i>l</i> .		
v Volume	Volumes SAS_Array_0000	Volume Properties (*) Name: Volume, 0000 Beame Status: Normal Type: RAD1 Change type Stee 4,460 Mb Increase tase Stee 4,460 Mb Increase tase System volume: No <u>Dateds volume</u> Write-back carbin Disabled Chable (*) Instaland: No Unitalize (*) Verification details <u>Verify</u> Parky errors 0 Blocks with media errors 0 Physical sector size: 512 Bytes	

- 3. You can change the Name, Select the new volume type, and Select additional disks to include in the new volume if needed.
- Select the Data stripe size for the RAID array (for RAID 0, 10 and 5 only), and click OK. The available stripe size values range from 4 KB to 128 KB. The following are typical values: RAID 0: 128KB RAID 10: 64KB

RAID 10: 64KE RAID 5: 64KB

Change Volume Type	×
Name: Volume_0000	
Select the new volume type:	
Optimized disk performance (RAID 0)     Efficient data hosting and protection (RAID 5)	
The new volume will automatically include the disks that are part of the existing volume.	
Select additional disks to include in the new volume: 💯	
SAS disk on Controller 1, Phy 4 SAS disk on Controller 1, Phy 6	
Data stripe size: 64 KB 💌 🦻	
WARNING: Completing this action will immediately start the volume migration process. Any data on the disks to be added to the volume will be permanently lost and should be backed up before continuing. Volume data will be preserved. Performing a driver upgrade or downgrade while a volume migration is in progress may make the volume inaccessible due to driver incompatibility.	3
More help OK Cancel	-

We recommend a lower stripe size for server systems, and a higher stripe size for multimedia computer systems used mainly for audio and video editing.

10

### 5.3.3 Deleting a volume



Be cautious when deleting a volume. You will lose all data on the hard disk drives. Before you proceed, ensure that you back up all your important data from your hard drives.

To delete a volume:

1. From the utility main menu, select the volume (ex. Volume\_0000) in **Volumes** field you want to delete.

logy enterprise			_ 8 ×
			(intel)
r system is functioning norma	illy.		
t Volume	Volumes SAS_Array_0000	Volume Properties Name: Volume, 0000 <u>Bename</u> Status: Normal Type: RAID 1 <u>Change type</u> Size: 446 MB <u>Increase size</u> System volume: No <u>Delete volume</u> Write: tack cache: Disabled <u>Chable</u> <u>W</u> Initialized: No <u>Installer</u> Verification details <u>Verifi</u> Parly errors: 0 Blocks with media errors: 0 Physical sector size: 512 Bytes Logical sector size: 512 Bytes	

2. Select **Delete volume** in **Volume Properties** field. The following screen appears.



3. Click **Yes** to delete the volume and return to the utility main menu, or click **No** to return to the main menu.

# 5.3.4 Preferences

#### **System Preferences**

Allow you to set to show the notification area icon and show system information, warning, or errors here.

Intel® Ra	pid Storage Technolo	agy enterprise	_ @ ×
💥 Home	Preferences		(intel)
System E-mail		System Preferences           Ibor the notification area icon           Ibor the following notification:           Ibor see information           Iborage system information           Iborage system information           Iborage system information           Iborage system momention           Iborage system momention <td< th=""><th>vices helps on this page</th></td<>	vices helps on this page
			viore new on this page

#### **E-Mail Preferences**

Allow you to set to sent e-mail of the following events:

- Storage system information
- Storage system warnings
- Storage system errors

Encal       E-mail Preferences         E-mail       Hothy on tay e mail of the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors:         Image: system with the following vectors:       Image: system with the following vectors: </th <th>🔁 Intel® Rapid Storage Techno</th> <th>logy enterprise</th> <th>_ @ ×</th>	🔁 Intel® Rapid Storage Techno	logy enterprise	_ @ ×
E-mail       Notify me by e-mail of the following events:         Storage system saming:       Storage system saming:         Bit       Storage system saming:         Recipient e-mail address 1*       Recipient e-mail address 2:			intel
*Required fields           Apply Charges         Discard Charges		Notify me by email of the following events:         Storage system warnings         Path         Path         Recipient e-mail address 1:         Recipient e-mail address 1:         "Nequired fields	More help on this page




# 6

# **Driver Installation**

This chapter provides instructions for installing the necessary drivers for different system components.

# 6.1 Running the Support DVD

The support DVD that is bundled with your motherboard contains drivers, management applications, and utilities that you can install to maximize the features of your motherboard.



The contents of the support DVD are subject to change at any time without notice. Visit the ASUS website (www.asus.com) for the latest updates on software and utilities.

The main screen of the Support DVD contains the following tabs:

- 1. Drivers Shows the available device drivers that the system detects.
- 2. Utilities Displays the software applications and utilities that the motherboard supports.
- 3. Manual Provides the link to the user guide(s).




You need an internet browser installed in your OS to view the User Guide.

 Contact - Displays the ASUS contact information, e-mail addresses, and useful links if you need more information or technical support for your motherboard.

Appendix

# Z13PH-D16 block diagram



# Notices

# **Federal Communications Commission Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

# Compliance Statement of Innovation, Science and Economic Development Canada (ISED)

This device complies with Innovation, Science and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-003(A)/NMB-003(A)

#### Déclaration de conformité de Innovation, Sciences et Développement économique Canada (ISED)

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-003(A)/NMB-003(A)

#### Japan statement notice

This product cannot be directly connected to the Internet (including public wireless LAN) of a telecom carrier (mobile network companies, landline network companies, Internet providers, etc.). When connecting this product to the Internet, be sure to connect it through a router or switch.

# Japan JATE

本製品は電気通信事業者(移動通信会社、固定通信会社、インターネットプロバイダ等)の 通信回線(公衆無線LANを含む)に直接接続することができません。本製品をインターネットに接続する場合は、必ずルーター等を経由し接続してください。

#### Australia statement notice

From 1 January 2012 updated warranties apply to all ASUS products, consistent with the Australian Consumer Law. For the latest product warranty details please visit <u>https://www.asus.com/support/</u>. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you require assistance please call ASUS Customer Service 1300 2787 88 or visit us at <a href="https://www.asus.com/support/">https://www.asus.com/support/</a>.



DO NOT throw the motherboard in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

DO NOT throw the mercury-containing button cell battery in municipal waste. This symbol of the crossed out wheeled bin indicates that the battery should not be placed in municipal waste.

## Declaration of compliance for product environmental regulation

ASUS follows the green design concept to design and manufacture our products, and makes sure that each stage of the product life cycle of ASUS product is in line with global environmental regulations. In addition, ASUS disclose the relevant information based on regulation requirements.

Please refer to <u>http://csr.asus.com/Compliance.htm</u> for information disclosure based on regulation requirements ASUS is complied with:

#### EU REACH and Article 33

Complying with the REACH (Registration, Evaluation, Authorization, and Restriction of Chemicals) regulatory framework, we publish the chemical substances in our products at ASUS REACH website at <a href="http://csr.asus.com/english/REACH.htm">http://csr.asus.com/english/REACH.htm</a>.

#### EU RoHS

This product complies with the EU RoHS Directive. For more details, see <a href="http://csr.asus.com/english/article.aspx?id=35">http://csr.asus.com/english/article.aspx?id=35</a>

#### Japan JIS-C-0950 Material Declarations

Information on Japan RoHS (JIS-C-0950) chemical disclosures is available on <a href="http://csr.asus.com/english/article.aspx?id=19">http://csr.asus.com/english/article.aspx?id=19</a>

#### India RoHS

This product complies with the "India E-Waste (Management) Rules, 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls (PBBs) and polybrominated diphenyl ethers (PBDEs) in concentrations exceeding 0.1% by weight in homogenous materials and 0.01% by weight in homogenous materials for cadmium, except for the exemptions listed in Schedule II of the Rule.

#### Vietnam RoHS

ASUS products sold in Vietnam, on or after September 23, 2011, meet the requirements of the Vietnam Circular 30/2011/TT-BCT.

Các sản phẩm ASUS bán tại Việt Nam, vào ngày 23 tháng 9 năm2011 trở về sau, đều phải đáp ứng các yêu cầu của Thông tư 30/2011/TT-BCT của Việt Nam.

#### **Türkiye RoHS**

AEEE Yönetmeliğine Uygundur

#### **ASUS Recycling/Takeback Services**

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials. Please go to <a href="http://csr.asus.com/english/Takeback.htm">http://csr.asus.com/english/Takeback.htm</a> for detailed recycling information in different regions.

#### **Ecodesign Directive**

European Union announced a framework for the setting of ecodesign requirements for energy-related products (2009/125/EC). Specific Implementing Measures are aimed at improving environmental performance of specific products or across multiple product types. ASUS provides product information on the CSR website. The further information could be found at <a href="https://csr.asus.com/english/article.aspx?id=1555">https://csr.asus.com/english/article.aspx?id=1555</a>.

#### **Safety Precautions**

Accessories that came with this product have been designed and verified for the use in connection with this product. Never use accessories for other products to prevent the risk of electric shock or fire.

# 安全上のご注意

付属品は当該専用品です。他の機器には使用しないでください。機器の破損もしくは、火災 や感電の原因となることがあります。

# Service and Support

Visit our multi-language website at https://www.asus.com/support/



