

Pro Pad Manual

Features

Thank you for buying the Pro pad.

- **Windows 98/98se/ME/2000/XP compatible**
- **Compatible with Direct-X**
- **USB Port only**
- **Digital and Analog mode control**
- **Digital mode : 2-Axis, 10-Buttons**
- **Analog mode : 4-Axis, 12-Buttons and POV**
- **Vibration Feed Back (need driver)**
- **Dual motor vibration**
- **TURBO and CLEAR function**
- **MACRO function.**

The button layout:

The Pro pad supports digital and analog mode. In digital mode have 2 axis and 10 buttons, but analog mode have 4 axis, 12 buttons and POV. With additional buttons Turbo and Clear designed for buttons 1-8. Moreover, 5,6,11,12 button with Macro function which could make you to set up your own hot keys.

Installation

1. In Windows 98/98se/ME/2000/XP
2. Attach the **USB port** connector of the Pro pad to USB port of the computer.
3. USB have **Plug and Play** function, but Pro pad need driver to setup the Vibration Feed Back function.
If you don't install the driver that you still could use the game pad, but you won't have the Vibration Feed Back function.
Note: Windows 98/98se needs original Windows 98/98se program, just follow the on-screen instructions.
4. Install the driver, you just only need to execute the " setup.exe " program and follow the on-screen instructions, it's easy to setup.
Note: Be sure your operation system have the Direct-X 7.0a or more (win 98/98se have not inner this program), if not please download the file from Microsoft website.
5. Check the Pro pad double click the **Game Controller** Icon in the Windows 98/98se/ME/2000/XP **Control Panel**.
6. Now choose " Properties " and than " Calibrate ".
7. Once in the calibration utility, follow the on-screen instructions.
8. After gaming device has been calibrated, choose " TEST " to verify the gaming device has been properly.
If the Pro pad is not calibrated properly, calibrated again.
9. If the Pro pad is calibrated properly select " **Apply** " and then " **OK** " before exiting.

MACRO FUNCTION

Only the 5,6,11,12 key can, for example, be assigned step sequence combinations to make it easier to use when playing.

1. Press the MACRO key and the MACRO LED lights green.
2. Press the button which you wish to assign a step sequence. The LED flashes.
3. Enter the step sequence and press the MACRO button again. The green LED light goes out.

Example : Press on “MACRO” and then button “5”. Enter the step sequence “1,2,down button and press “MACRO” again. If you now press the “5” button when playing, the MACRO step sequence is carried out.

Note: 1. There can be up to 15 steps in a sequence.

2. Only one of TURBO or MACRO function could be setting on one button. Macro function will be the first mode to be set up if turbo function is also setting at the same time.

Erasing MACRO function

If you want to erase any MACRO function you have entered, proceed as follows:

1. Press “MACRO” until the LED lights green.
2. Press the button for which you wish to erase the MACRO function.
3. Press the “ MACRO” button again. The MACRO function I snow erased.

Increase the speed of MACRO function

Two different speed mode could be set up:

1. Fasten motion
2. Slow motion:

Troubleshooting

In Windows 98/98se/ME/2000/XP the gamepad control panel tells me that the Twin Shock is not connected properly.

- Make sure that the Pro pad is properly connected to the USB port of the computer.
- Make sure that no other drivers are installed. Remote any other drivers listed under **Game Controllers** on the general screen.
- Make sure that your USB is functioning properly.
- Do not move the direction pad to center the crosshairs manually. Just press the fire button, even if crosshairs are in a corner.