

Motherboard

PRIME Z490-A

Quick start guide

دليل التشغيل السريع

Кратко упътване за бърз старт

Stručná příručka

Quick Start-vejledning

Snelstartgids

Lühijuhend

راهنمای شروع سریع

Guide de démarrage rapide

Pikakäynnistysopas

Schnellstarthilfe

Οδηγός γρήγορης έναρξης

Beüzemelési útmutató

Guida Rapida

Panduan Ringkas

クイックスタートガイド

Жылдам іске косу нұсқаулығы

빠른 시작 설명서

Greitos darbo pradžios vadovas

Ísa pamäciba

Hurtigstartsvejledning

Guia de consulta rápida

Instrukcja szybkiej instalacji

Краткое руководство

Ghid de pornire rapidă

Guía de inicio rápida

Vodič za brzo korišćenje

Stručný návod na spuštění

Snabbstartsguide

قۇمۇكىرىمدىن ئۆياڭىزىرىتى

Hızlı Başlatma Kilavuzu

Hööög daän khôoui ñoäng nhanh

vodič za brzi početak rada

Стисле керівництво для початку експлуатації

Step 1

Install the CPU

(CPU) قم بثبيت وحدة المعالجة المركزية

Инсталирайте процесора

Instalace procesoru

Installer CPU'en

De CPU installeren

Paigaldage CPU

CPU را نصب کنید

Installer le CPU

Asenna suoritin

Installieren der CPU

Εγκατάσταση της CPU

Helyezze be a CPU-t

Installare la CPU

Pasang CPU

CPUを取り付ける

CPU орнатыңыз

CPU را نصب کنید

CPU 설치

Sumontuokite centrini procesori

Uzstādīet centrálo procesoru

Installe sentralprosessoren (CPU)

Instale a CPU

Instalacija procesora

Установка процессора

Instalați CPU-ul

Instalar la CPU

Instalirajte CPU





Inštalácia centrálneho procesora

Installera CPU

安装 CPU

Instalação de processador

Инсталуйте процесор



Step 2

Install the CPU fan

ثبت مروحة وحدة المعالجة المركزية

Инсталирайте вентилатора на процесора

Instalace ventilátoru procesoru

Installer CPU-blæseren

De CPU-ventilator installeren

Paigaldage CPU ventilaator

پنکه CPU را نصب کنید

Installer le ventilateur de CPU

Asenna suorittimen tuuletin

Installieren des CPU-Lüfters

Εγκατάσταση του αεριστήρα της CPU

Szerelje be a CPU ventillátort

Installare la ventola della CPU

Pasang kipas CPU

CPUクーラーを取り付ける

CPU жедедтішін орнатыңыз

CPU 팬 설치

Sumontuokite centrino procesoriaus ventiliatoriū

Uzstādīet centrāla procesora ventilatoru

Installer CPU-viften

Instale a ventoinha de CPU

Instalacija wentylatora procesora

Установка вентилятора

Instalați ventilatorul CPU-ului

Instalar el ventilador de la CPU

Instalirajte CPU ventilator

Inštalácia ventilátora centrálneho procesora

Installera CPU-fläkten



তিছিঁপঢ়লন CPU

CPU fanını takın


Lắp quạt CPU

Instalacija ventilatora procesora

Инсталуйте вентилятор процесора



Motherboard Layout



Step 3

Install memory modules

ثبت وحدات الذاكرة

Инсталирайте модули памет

Instalace paměťových modulů

Installer hukommelsesmodulerne

Geheugenmodules installeren

Paigaldage mälumoodulid

مادول های حافظه را نصب کنید

Installer les modules mémoire

Asenna muistikomponentit

Installieren der Speichermodule

Εγκατάσταση των στοιχείων μνήμης

Helyezze be a memória modulokat

Installare i moduli di memoria

Pasang modul memori

メモリーモジュールを取り付ける

Жад модульдерін орнатыңыз

Step 4

Install storage devices

메모리 모듈 설치

Sumontuokite atminties modulius

Uzstādīet atmiņas moduļus

Installer minnemoduler

Instale módulos de memoria

Instalacija modułów pamięci

Установка модулей памяти

Instalați module de memorie

Instalar los módulos de memoria

Instalirajte module memorije

Inštalácia pamäťových modulov

Installera minnesmoduler


তিছিঁপঢ়লন পার্ক মডুল

Bellek modüllerini takın

Lắp các thanh nhớ

Instalacija memoriskih modula

Інсталуйте модулі пам'яті



Step 4

M.2 devices

ثبت أجهزة التخزين

Инсталиране на устройства за съхранение

Instalování paměťových zařízení

Montere lagringseheter

Instalar dispositivos de almacenamiento

Instalacija urzadzení pamieci

Установите накопители

Instalarea dispozitivelor de stocare

Instalar dispositivos de almacenamiento

Instalirajte uređaje za skladištenje

Ištalácia pamäťových zariadení

Installaera lagringseheter


গার্ডিট আপলবেন করা শক্তি

Depolama aygitlarınızı takma

lắp đặt các thiết bị lưu trữ

Instalirajte uređaje za pohranjivanje

Сақтау құрылғыларын орнаты



Australia statement notice

From 1 January 2012 updated warranties apply to all ASUS products, consistent with the Australian Consumer Law. For the latest product warranty details please visit <http://www.asus.com/support/>. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you require assistance please call ASUS Customer Service 1300 2787 88 or visit us at <http://www.asus.com/support/>

India E-waste (Management) Rule 2016


This product complies with the "India E-Waste (Management) Rules, 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls (PBBS) and polybrominated diphenyl ethers (PBDEs) in concentrations exceeding 0.1% by weight in homogenous materials and 0.01 % by weight in homogenous materials for cadmium, except for the exemptions listed in Schedule II of the Rule.

Regional notice for Turkey

AEEE Yönetmeligiine Uygundur.


Step 5

Install expansion card(s)
 تثبيت بطاقة (بطاقات) التوسيع
 Инсталайрайте допълнителна карта (допълнителни карти)
 Instalace přidavné karty (karet)
 Installer udvidelseskortene
 Uitbreidingskaart(en) installeren
 Paigaldage laienduskaart(-kaardid)
 کارت های گسترش را نصب کنید
 Installer une carte d'extension
 Asenna laajennuskortti/kortit
 Installieren der Erweiterungskarte(n)
 Εγκατάσταση καρτών επέκτασης
 Helyezze be a bővítőkártyát(ka)t
 Installare le schede di espansione
 Pasang kartu ekspansi
 拡張カードを取り付ける
 Кеңеңтү картас(лар)ын орнатыңыз
 확장 카드 설치
 Sumontuokite išplėtimo plokštę (-es)
 Uzstādīt izvērses karti(-es)
 Installer utvidelseskort
 Instale placas de expansão
 Instalacja kart(y) rozszerzenia
 Установка карт расширения
 Instalați cardul/cardurile de extensie
 Instalar tarjetas de expansión
 Instalirajte ekspanzionu/e karticu/e
 Inštalácia rozširujúcich kart
 Installera expansionskort
 گیگابایت لارغا شفعتلىكىرىنىڭ كارت
 Genişletme kartlarını takın
 Lắp (các) thẻ mở rộng
 Instalacija kartica za proširenje
 Інсталюйте плати розширення




Step 6

Install system panel connectors
 تثبيت وحدات توصيل لوحة النظم
 Инсталайрайте конекторите на системния панел
 Instalace konektorů panelu systému
 Installer systempanelets tilslutninger
 Aansluitingen op het systeempaneel installeren
 Paigaldage süsteemi paneeli konnektorid
 رابط های صفحه سیستم را نصب کنید
 Installer les connecteurs système
 Asenna järjestelmäpaneelin liittimet
 Installieren des Systemtafelanschlusses
 Εγκατάσταση συνδέσμων πάνελ συστήματος
 Szerelje be a rendszерpanel csatlakozóit
 Installare i connettori del pannello del sistema
 Pasang konektor panel sistem
 システムパネルコネクターを取り付ける
 Жұмыс тақтасының қосқыштарын орнатыңыз
 시스템 패널 커넥터 설치
 Sumontuokite sistemas plokštés jungtis
 Uzstādīt sistēmas paneļa savienotājus
 Installer kontakter for systempanelet
 Instale os conectores do painel do sistema
 Instalacja złączy panela systemu
 Установка соединений системной панели
 Instalați conectorii pentru placă de bază
 Instalar conectores del panel del sistema
 Instalirajte sistemske priključke
 Inštalácia konektorov ovládacieho panela
 Installera systempanelkontakter
 گیگابایت لارغا شفعتلىكىرىنىڭ كارت
 Sistem paneli konnektörlerini takın
 Lắp các đầu nối hệ thống ra ngoài
 Instalacija konektora ploče sustava
 Інсталюйте розніми системної панелі



Step 7


Install ATX power connectors
 تثبيت توصيلات الطاقة ATX
 Инсталайрайте ATX конекторите за захранване
 Instalace konektorů napájení ATX
 Installer ATX-strømtilslutningerne
 ATX-voedingsaansluitingen installeren
 Paigaldage ATX-i toitekonnektorid
 رابط های برق ATX را نصب کنید
 Installer les connecteurs d'alimentation ATX
 Asenna ATX-virtaaliittimet
 Installieren des ATX-Stromanschlusses
 Εγκατάσταση συνδέσμων τροφοδοσίας ATX
 Csatlakoztassa az ATX tápcsatlakozókat
 Installare i connettori di alimentazione ATX
 Pasang konektor daya ATX
 電源ケーブルを接続する
 ATX электр қуат қосқыштарын орнатыңыз
 ATX 전원 커넥터 설치
 Sumontuokite ATX maitinimo jungtis
 Uzstādīt ATX strāvas savienotājus
 Installer kontakter for ATX-strøm
 Instale os conectores de alimentação ATX
 Instalacja złączy zasilacza ATX
 Установка ATX разъема
 Instalați pinii conectori ATX
 Instalar conectores de alimentación ATX
 Instalirajte ATX električne priključke
 Inštalácia napájacích konektorov ATX
 Installera ATX strömkontakter
 گیگابایت لارغا شفعتلىكىرىنىڭ كارت
 ATX güç konnektörlerini takın
 Lắp các đầu nối nguồn ATX
 Instalacija konektora ATX napajanja
 Інсталюйте розніми живлення ATX



Step 8

Connect input/output devices
 توصيل أجهزة الدخول/الخرج
 Свързване на I/O устройства
 Připojení vstupních/výstupních zařízení
 Tilslut input-/outputudstyr
 I/O-apparaten aansluiten
 Ühdage sisend-/väljundseadmed
 دستگاه های ورودی/خروجی را متصل نمایید
 Connecter les périphériques d'entrée/sortie
 Liitä tulo-/lähtölaitteita
 Eingabe-/Ausgabe-Geräte verbinden
 Σύνδεση συσκευών εισόδου/εξόδου
 Bemeneti/kimeneti eszközök csatlakoztatása
 Collegate i dispositivi di input/output
 Sambungan perangkat input/output
 入出力デバイスに接続する
 Kırıç/шығыс құрылғыларын қосы

입력/출력 장치 연결
 Prijunkite įvesties / išvesties įrenginius
 Pievienot ievades/izvades ierīces
 Koble til inngang/utgangsenheter.
 Ligar dispositivos de entrada/saída
 Podłączzenie urządzeń wejścia/wyjścia
 Подключите устройства ввода/вывода
 Conectare dispozitive de intrare/ieșire
 Conectar dispositivos de entrada y salida
 Povežite ulazne/izlazne uređaje
 Připojenie vstupných/výstupných zariadení
 Anslut ingående/utgående enheter
 چۈنمدىقلىكىنىڭ ئۆئىتۈرۈشۈرۈشىلەرنىڭ
 Giriş/çıkış aygıtlarına bağlan
 Kết nối các thiết bị đầu vào/đầu ra
 Spajanje ulaznih/izlaznih uređaja
 Під'єднайте пристрой вводу/виводу



Step 9

Power on the system and install operating system and drivers
 تشغيل الجهاز وتثبيت نظام وبرامج التشغيل
 Включете системата и инсталайрайте операционната система и драйверите
 Zapnúť napájení systému a instalace operačného systému a ovladačů
 Tænd for systemet, og installer operativsystemet og de tilhørende drivere
 Het systeem inschakelen en het besturingssysteem en de stuurprogramma's installeren
 Lülitage süsteemi toide sisse ning installige operatsioonisüsteem ja draiverid
 سیستم را روشن کرده و درایورها و سیستم را نصب کنید
 Allumer le système et installer le système d'exploitation et les pilotes
 Käynnistä järjestelmä ja asenna käyttöjärjestelmä ja ohjaimet
 Einschalten des Systems und installieren des Betriebssystems und der Treiber
 Ενεργοποιήστε το σύστημα και εγκαταστήστε το λειτουργικό σύστημα και τα προγράμματα οδήγησης
 Kapcsolja be a rendszert és telepítse az operációs rendszert és illesztőprogramokat
 Accendere il sistema e installare il sistema operativo e i driver
 Hidupkan sistem, lalu instal sistem operasi dan driver
 システムを起動しOSとドライバーをインストールする
 Жұмыс тақтасындағы жеке операциялық жүйені жөнө драйверлерді орнатыңыз
 시스템 전원 켜기 및 운영체제와 드라이버 설치
 Împingeți sistemul și instalați sistemul de operare și driverele
 Slá på systemet og installer operativsystem og drivere
 Ligue o sistema e instale o sistema operativo e os controladores
 Włącz zasilanie i zainstaluj system operacyjny oraz sterowniki
 Включение системы и установка операционной системы и драйверов
 Porniți sistemul și instalați sistemul de operare și driverele
 Proporcionar alimentación al sistema e instalar el sistema operativo y los controladores
 Uključite sistem i instalirajte operativni sistem i drivrutiner
 Zapnutie systému a inštalácia operačného systému a ovládačov
 Slá på systemet och installera operativsystem och drivrutiner
 گیگابایت لارغا شفعتلىكىرىنىڭ كارت
 Bật nguồn hệ thống và cài đặt hệ điều hành cũng như các driver
 Uključivanje sustava i instaliranje operativnih sustava i upravljačkih programa
 Увімкніть живлення системи та інсталюйте операційну систему та драйвери

