ASUS GX900 Gaming Mouse

User Manual

E5887
First Edition (V1)
July 2010

Contact Information

ASUSTeK COMPUTER INC.

Address	15 Li-Te Road, Peitou, Taipei, Taiwan 11259
Telephone	+886-2-2894-3447
Fax	+886-2-2890-7798
E-mail	info@asus.com.tw
Web site	www.asus.com.tw

Technical Support

Telephone	+86-21-38429911
Online support	support.asus.com

ASUS COMPUTER INTERNATIONAL (America)

Address	800 Corporate Way, Fremont, CA 94539, USA
Telephone	+1-510-739-3777
Fax	+1-510-608-4555
Web site	usa.asus.com

Technical Support

Telephone	+1-812-282-2787
Support fax	+1-812-284-0883
Online support	support.asus.com

ASUS COMPUTER GmbH (Germany and Austria)

Address	Harkort Str. 21-23, D-40880 Ratingen, Germany
Fax	+49-2102-959911
Web site	www.asus.de
Online contact	www.asus.de/sales

Technical Support

Telephone (Component)	+49-1805-010923*
Telephone (System/Notebook/Eee/LCD)	+49-1805-010920*
Support Fax	+49-2102-9599-11
Online support	support.asus.com

* EUR 0.14/minute from a German fixed landline; EUR 0.42/minute from a mobile phone.

Contents

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

Safety Certifications

- CE Marking
- China RoHS EFUP Labeling - 10 Years
- C-Tick Mark
- BSMI Certification

Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.

REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at http://csr.asus.com/english/REACH.htm.

DO NOT throw the mouse in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

Package Contents

Check your ASUS GX900 Gaming Mouse package for the following items:

- **ASUS GX900 Gaming Mouse**
- **User Manual**
- **Support CD**

If any of the above items is damaged or missing, contact your retailer immediately.

Specifications Summary

Model Name	GX900
Connectivity Technology	Wired
Tracking	Laser
OS Support	Windows® XP / Windows® Vista / Windows® 7
Dimensions (mm)	Mouse: 122(L) x 82(W) x 43(H)
Cable Length	1.8m with cable sleeve
Weight	Mouse: 150g (adjustable)
Buttons / Switches	1 x Left button / Right button / Scroll wheel 2 x Side buttons 1 x DPI button 1 x Profile Switch button
Resolution	100 ~ 4000 dpi (adjustable) Default: 1200dpi (Level 1), 4000dpi (Level 2)
Interface	Gold plated USB

Specifications are subject to change without prior notice.

Knowing your ASUS GX900 Gaming Mouse

Your ASUS GX900 Gaming Mouse comes with a left button, a right button, a scroll wheel, two side buttons, a DPI button, and a specially designed Profile Switch button.

1	Left button
2	Right button
3	Scroll wheel
4	Push/Pull DPI switch
5	Profile switch button / Profile indicator*
6	LED DPI indicator**
7	GX900 logo
8	IE Forward button
9	IE Backward button
10	Mouse feet
11	Mouse feet and Twin-Eye Laser sensor
12	Weight base (5 x 4.5g blocks)***

* **Profile switch LED indications**

LED colors	Indications
Do not light up.	Normal Profile
Green	Profile 1
Red	Profile 2
Orange	Profile 3

** **DPI switch LED indications**

Number of lit LEDs	Indications
2	DPI Level 1
4	DPI Level 2

*** You can adjust the mouse weight through adding or removing some of the weight blocks.

Connecting your ASUS GX900 Gaming Mouse

Connect your ASUS GX900 Gaming
Mouse to your computer's USB port.

Launching the Program

The bundled support CD includes a specially designed program which allows you to set up your GX900 to avail all its features. Place the support CD into the optical drive and follow the onscreen instructions to launch the program.

> If Autorun is NOT enabled in your computer, browse the contents of the support CD to locate the **GX900.exe** file. Double-click the **GX900.exe** file to launch the program.

Setting your ASUS GX900 Gaming Mouse

Locate the **GX900.exe** file, and double-click it to launch the program.

If the screen below appears, plug your ASUS GX900 Gaming Mouse into your computer's USB port. The program will automatically detect the mouse and continue to the main menu.

No Mouse Detected   ✕

No mouse detected!

Try Again   Quit

Main menu

Items	Descriptions
1.	Click the each tap to display the selected profile menu.
2.	Displays the profile icon which is configurable in Profile 1~3 menus.
3.	Click to reset the DPI configuration to the last settings you have saved.
4.	Drag the slider to adjust the DPI value for each level.*
5.	Click to reset the button settings to the last settings you have saved.
6.	Click to display the indications of different Profile indicator colors.
7.	Click to load a profile you have saved to your mouse.
8.	Click to save the current profile settings to your hard disk drive.
9.	Click to reset all the mouse settings to the factory defaults.
10.	Click to save the settings you have made.
11.	Click to save the settings you have made and exit the program.

* Each profile provides two DPI levels. Two DPI switch LEDs light up indicating that you are using Level 1, and four light up indicating that you are using Level 2. See page 7 for details.

9

Profile 1 menu

Items	Descriptions
1.	Click to open the Edit menu which allows you to change the profile name and profile icon.
2.	Enter the profile name you want to use.
3.	Click to locate the image file you want to use as the profile icon.
4.	Select a function for each button / action from the drop down list. * Refer to the table below for more details.

| Items	Descriptions
L-Button	Makes the button behave like the left mouse button.
R-Button	Makes the button behave like the right mouse button.
M-Button	Makes the button behave like the middle mouse button.
IE Backward	Makes the button behave like the IE Backward button. When selected, press the button to go to the previous page you viewed.
IE Forward	Makes the button behave like the IE Forward button. When selected, press the button to go to the next page you viewed.

continued on the next page

Items	Descriptions
Keyboard	When selected, press the button to perform a keystroke or keystroke sequence.
Macro	When selected, press the button to run a command or series of commands which you can edit though the Edit Macro menu. See page 12 for more details.
Script #1~6	When selected, press the button to run a script which you can edit through the Edit Script menu. See page 13 for more details.
DPI[+]	When selected, press the button to increase the DPI value.
DPI[-]	When selected, press the button to decrease the DPI value.
DPI Level 1/2	When selected, press the button to use the DPI Level 1/2.
Profile Switch	Makes the button behave like the profile switch button.
Normal Profile	When selected, press the button to use the normal profile.
User Profile 1/2/3	When selected, press the button to use the customized profile 1/2/3 .
Wheel [left] / [right]	When selected, press the button to scroll leftward / rightward as a tilt wheel does. NOTE: This function only work in the Microsoft® Office applications under the Windows® 7 / Vista operating systems.
Rapid Fire [mouse]	When selected, press the button to do a rapid fire in a click-to-attack game, which is the same as you triple click the left mouse button.
Rapid Fire [key]	When selected, press the button to do a rapid fire in a game using the Spacebar to attack, which is the same as you press the Spacebar thrice.
Web Browser	When selected, press the button to launch your default web browser.
E-mail	When selected, press the button to launch your default email application.
Media Player	When selected, press the button to launch your default media player.
Play/Pause	When selected, these buttons become playback control buttons in an active media player.
Stop	
Next Track	
Prev Track	
Volume UP / Down	When selected, press the button to increase / decrease the system volume.
Mute	When selected, press the button to turn the volume's mute mode on/off.
Calculator	When selected, press the button to launch the Calculator application.
My Computer	When selected, press the button to open My Computer window.
Disabled	Select this item to deactivate the button.

Edit Macro menu

Items	Descriptions
Edit Macro	Click to open the Edit Macro menu.
Timing	Check this item to record the time between pressing down and releasing a button. (Default: 12ms)
Insert	When checked, the new instruction will be inserted before the selected instruction. Otherwise, any new instruction will be given the first priority.
Start	Click to start recording the keystrokes and/or mouse actions.
Stop	Click to stop recording the keystrokes and/or mouse actions.
Clear	Click to clear all the saved instructions.
Move up/down	Click to move up/down the selected instruction.
Instruction cycle time	When Timing is unchecked, all the actions' delay time will be the value you chose from the drop down list.
Loop	Sets the macro to run at a click and stop when you click again.
Fire	Sets the macro to run once at one click.
Keeping fire	Sets the macro to run when you hold down the button and stop when you release the button.
Export	Click to save the current macro to your hard disk drive.
Import	Click to load a macro from your hard disk drive.

Edit Script menu

Edit Script ✕

Mouse Input Area

Start
Stop

☐ Timing ☐ Insert

NO.	Instruction	Delay

Clear
Delete
Move up
Move down

0/256

Instruction cycle time 24ms ▼   Fire ▼

Export   Import   OK   Cancel

Profile 1 ✏

BUTTON SETTIN

Script #1 ▼

Edit Script

IE Forward ▼

IE Backward ▼

Export   Import

Items	Descriptions
Edit Script	Click to open the Edit Script menu.
Timing	Check this item to record the time between pressing down and releasing a button. (Default: 12ms)
Insert	When checked, the new instruction will be inserted before the selected instruction. Otherwise, any new instruction will be given the first priority.
Start	Click to start recording the keyboard and/or mouse actions.
Stop	Click to stop recording the keyboard and/or mouse actions.
Clear	Click to clear all the saved instructions.
Move up/down	Click to move up/down the selected instruction.
Instruction cycle time	When Timing is unchecked, all the actions' delay time will be the value you chose from the drop down list.
Loop	Sets the script to run at a click and stop when you click again.
Fire	Sets the script to run once at one click.
Keeping fire	Sets the script to run when you hold down the button and stop when you release the button.
Export	Click to save the current script to your hard disk drive.
Import	Click to load a script from your hard disk drive.