Fingerprint Driver Update Instructions


Step1: Open the **Settings app**.



CONFIDENTIAL AND PROPRIETARY INFORMATION

Fingerprint Driver Update Instructions


Step2: Click on the **Accounts icon**.



CONFIDENTIAL AND PROPRIETARY INFORMATION

Fingerprint Driver Update Instructions

Step3: Click on **Sign-in options** on the left side, and click on **Remove** for Fingerprint under **Windows Hello** on the right side.




CONFIDENTIAL AND PROPRIETARY INFORMATION

Fingerprint Driver Update Instructions

Step4: Click "**Fingerprint_WBF_USB_CC_Focal_D_V3.03.4901.2857_34100.exe**" and then follow the instructions.



Note: Select Install



CONFIDENTIAL AND PROPRIETARY INFORMATION

Fingerprint Driver Update Instructions

- Do not operate the unit or disconnect the power cable during driver update.
- If the driver update is interrupted, there is a possibility that the unit will malfunction.

CONFIDENTIAL AND PROPRIETARY INFORMATION