

# Padfone™ mini Station

4.3◀▶7

Quick Start Guide



E8431  
First Edition  
Model: T00CP

Copyright © 2013 ASUSTeK COMPUTER INC.

All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Thank you for purchasing an ASUS product!

Before you start, read all the safety information and operating instructions in the **User Manual** bundled with your PadFone mini 4.3 to prevent injury or damage to your device.

---

**NOTE:** This bundled Quick Start Guide is for reference only and is subject to change without prior notice. For the latest updates and additional information, please visit **[www.asus.com](http://www.asus.com)**.

---

## PadFone mini Station overview



- ① Touch screen display
- ② Micro USB connector
- ③ Power key
- ④ Volume key



5 PadFone mini 4.3

6 Speaker

## Charging your PadFone mini Station

Fully charge your PadFone mini Station before connecting the PadFone mini 4.3.

### To charge your PadFone mini Station:

1. Connect the USB connector into the power adapter's USB port.
2. Connect the PadFone mini 4.3 cable to your PadFone mini Station.
3. Plug the power adapter into a wall socket.



---

### NOTES:

- Use only the power adapter that came with your device. Using a different power adapter may damage your device.
  - Using the bundled power adapter and cable to connect your PadFone mini 4.3 to a power outlet is the best way to charge your PadFone mini Station.
  - The input voltage range between the wall outlet and this adapter is AC 100V - 240V. The output voltage of the micro USB cable is DC 5.2V, 1.35A.
-

## Inserting your PadFone mini 4.3 into the PadFone mini Station

---

**CAUTION:** We do not recommend adding a protective film or cover to your PadFone mini 4.3 as it can result in difficulty when inserting/removing the PadFone mini 4.3 to/from the PadFone mini Station.

---


---

**NOTE:** Always keep the PadFone mini Station bay clean to prevent dust or dirt from scratching or damaging your PadFone mini 4.3.

---

### To insert your PadFone mini 4.3 into your PadFone mini Station:

1. Align your PadFone mini 4.3 into the PadFone mini 4.3 bay sliding track.



2. Insert your PadFone mini 4.3 all the way into the bay until it is securely connected to the PadFone mini Station. Your PadFone mini 4.3 briefly vibrates when the connection is secured.





After successfully inserting your PadFone mini 4.3 into the PadFone mini Station, Android automatically adjusts the screen and apps to work on a tablet environment.

If an app was designed for a smaller screen size, a zoom control will appear beside the clock.

---

**NOTE:** The following screen is for reference only and may appear differently on your device.

---



## Removing your PadFone mini 4.3 from the PadFone mini Station

Gently slide the PadFone mini 4.3 out from the PadFone mini Station.



## Safety information

### PadFone mini Station care

- Do not leave your PadFone mini Station exposed to strong sunlight or excessive heat for a prolonged period. This may damage it.
- Do not handle your PadFone mini Station with wet hands or expose it to moisture or liquids of any kind. Continuous changes from a cold to a warm environment may lead to condensation inside your PadFone mini Station device, resulting in corrosion and possible damage.
- When traveling, avoid packing your PadFone mini Station in a suitcase. Cramming the device into a suitcase may crack the LCD display. Remember to switch off your wireless connection during air travel.
- Use your PadFone mini Station in an environment with ambient temperatures between -10 °C (14 °F) and 35 °C (95 °F).

---

**IMPORTANT!** To provide electrical insulation and maintain electrical safety, a coating is applied to insulate the ASUS PadFone mini Station body except on the sides where the I/O ports are located.

---

## The battery

- Avoid charging in extremely high or low temperature. The battery performs optimally in an ambient temperature of +5 °C to +35 °C.
- Do not remove and immerse the battery in water or any other liquid.
- Never try to open the battery as it contains substances that might be harmful if swallowed or allowed to come into contact with unprotected skin.
- Do not remove and short-circuit the battery, as it may overheat and cause a fire. Keep it away from jewellery and other metal objects.
- Do not remove and dispose of the battery in fire. It could explode and release harmful substances into the environment.
- Do not remove and dispose of the battery with your regular household waste. Take it to a hazardous material collection point.
- Do not touch the battery terminals.

---

### **CAUTION:**

- Risk of explosion if battery is replaced by an incorrect type.
  - Dispose of used batteries according to the instructions.
-

## Prevention of Hearing Loss

Warning statement requirement under EN 60950-1:A12.



**WARNING:** To prevent possible hearing damage, do not listen at high volume levels for long periods.

C €0560

**NOTE:** For France, headphones/earphones for this device are compliant with the sound pressure level requirement laid down in the applicable EN 50332-1: 2000 and/or EN50332-2: 2003 standard as required by French Article L.5232-1.



A pleine puissance, l'écoute prolongée du baladeur peut endommager l'oreille de l'utilisateur.



