


更新NVM步驟如下:


1. 滑鼠右鍵以系統管理員的身分執行 install.bat



2. 第一次按任意鍵以繼續



3. 第二次按任意鍵以繼續



4. 更新NVM成功

```
系統管理員: C:\Windows\System32\WindowsPowerShell\v1.0\powershell.exe
Flash inventory finished.
[00:003:00:00]: Intel(R) Ethernet Controller (2) I225-V
Vendor      : 8086
Device     : 15F3
Subvendor  : 1043
Subdevice  : 87D2
Revision   : 2
LAN MAC    : 00A0C9000000
Alt MAC    : FFFFFFFF
SAN MAC    : 000000000000
ETrackId   : 80000150
SerialNumber : 00A0C9FFF000000
NVM Version : 1.69(1.45)
PBA        : G23456-000
VPD status : Not set
VPD size   : 0
NVM update : No config file entry
checksum   : Invalid
.
....Updating....

Intel(R) Ethernet NVM Update Tool
NVMUpdate version 1.35.28.1
Copyright (C) 2013 - 2020 Intel Corporation.

Config file read.
Inventory
[00:003:00:00]: Intel(R) Ethernet Controller (2) I225-V
Flash inventory started.
Shadow RAM inventory started.
Shadow RAM inventory finished.
Warning: Probably incorrect image - LoamBit is set and Pointer to OROM is VALID!
Flash inventory finished.

Update
[00:003:00:00]: Intel(R) Ethernet Controller (2) I225-V
Flash update started.
===== [100%] =====
NVM verification started.
Shadow RAM verification started.
===== [100%] =====
Shadow RAM verification finished.
Flash verification started.
===== [100%] =====
Flash verification finished.
NVM verification finished.
Flash update successful.

Update security revisions
[00:003:00:00]: Intel(R) Ethernet Controller (2) I225-V
Skipping update minimum security revisions.
Checking update availability for next tool run.
規則導引式模式: \FXVL_15F3_ASUS.bin 無效。
位於 線路:1 字元:1
+ (gc config_i225.txt) -replace '\FXVL_15F3_ASUS.bin','NVM_VERSION' | ...
+ ~~~~~
+ CategoryInfo          : InvalidOperation: (\FXVL_15F3_ASUS.bin:String) [], RuntimeException
+ FullyQualifiedErrorId : InvalidRegularExpression
```

5. 將系統斷電移除電源線，並重新啟動系統