

ASUS Instant Fun

User's Guide

Contents

Chapter 1	ASUS Instant Fun	1
1.1	Introduction	1
1.2	How to run Instant Fun.....	1
1.3	Function introduction for Instant Fun	4


Chapter 1 ASUS Instant Fun

1.1 Introduction


Make it easier to enjoy home entertainment. Only one touch, DVD/ Photo/ Video/ Music is quickly ready on your demand based on WINDOWS Instant Fun.

1.2 How to run Instant Fun

1. Install ATK Media firstly



2. Install Instant Fun secondly



3. Press Instant Key button on system(Whenever system power on or shut down)



1.3 Function introduction for Instant Fun

1. Select photo option it will launch Windows Picture and Fax Viewer



2. Select Music option and it will launch Windows Media player



3. Select Video option and it will launch Windows Media player



4. Select DVD option it will launch ASUS DVD Player



5. Select DV option and it will launch Lifeframe utility



6. Select Make Disc option it will launch Nero





Tip: Instant Fun instant key on top right side



1. Photo
2. Music
3. Video
4. DVD
5. DV
6. Make Disc
7. Exit