


# UX425JA 、 UX425IA 、 UX425EA Update Audio Dongle FW


**Please do not unplug the device when updating FW.**

1. Inert the Asus audio dongle with headset or microphone or headphone.
2. Please download the ESS FW on Asus website, then compressed the file.
3. After decompression is complete, enter to bottom-layer folder and click ESS\_SuiteFW.




4. After running the program, it will pop up an window, and confirm whether FW is update correct or not.


```
12/23/2020 8:21:28 AM: Connecting...
12/23/2020 8:21:28 AM: Device: VID (0x0495) PID (0x3001) | MODE: SYNC
12/23/2020 8:21:28 AM: Chip Version: Production Chip
12/23/2020 8:21:28 AM: Previous Version: 1.6.10
12/23/2020 8:21:28 AM: Current Version: 1.6.10
12/23/2020 8:21:28 AM: Uploading Firmware...
12/23/2020 8:21:28 AM: Progress: 0%
```



5. After update FW finished, it will pop up an success FW update message.



**PS:** If unplug the device when FW is updating, it will pop up an message and ask re-update again, just click OK.



When you execute it again,you will find that PID is incorrect.It will pop up an message to ask whether FW need to update? Click Yes.

```
12/23/2020 8:32:28 AM: Connecting...
12/23/2020 8:32:28 AM: Device: VID (0x0495) PID (0x3001) | MODE: SYNC
12/23/2020 8:32:28 AM: Chip Version: Production Chip
12/23/2020 8:32:28 AM: Previous Version: 1.6.12
12/23/2020 8:32:28 AM: Current Version: 1.6.12
12/23/2020 8:32:28 AM: Uploading Firmware...
12/23/2020 8:32:28 AM: Progress: 0%
```



If you run the program without Dongle, it will pop up an message which show device is not connected, please try again.

Just click OK.

```
12/23/2020 8:35:38 AM: Connecting...
12/23/2020 8:35:40 AM: Failed to connect! No USB device found
12/23/2020 8:35:40 AM: Failed to connect
12/23/2020 8:35:40 AM: Please check C:\Users\liang\Documents\Customers\Asus\Zenbook\UX-Dongle\FW\2020\ESS_SuiteFW_1.
10\ESS_SuiteFW\AppData\Results.txt for more information.
```

