












## Service Part List

The illustrations below show the components of RS700A-E11-RS4U & RS700A-E11-RS12U.




(Illustration model may not be the same, for more detailed information, please refer to the SN)

| Component  | Description                      | Part No.        |
|--|----------------------------------|-----------------|
| <b>KMPP-D32</b><br>            | Motherboard                      | 90SB0940-M0XBN0 |
| <b>BP12LE12G-25-R1P-A</b><br> | HDD Backplane(For RS12U)         | 90SC0CH0-M0XBN0 |
| <b>BP4LE12G-35-R1M-A</b><br>  | HDD Backplane(For RS4U)          | 90SC0HJ0-M0XBN0 |
| <b>FPB-12BAY-R1P-A</b><br>    | Front Panel Board<br>(For RS12U) | 90SC0D70-M0XBN0 |
| <b>FPB-R20D</b><br>           | Front Panel Board<br>(For RS4U)  | 90SC03Z0-M0XBN2 |




| Component  | Description       | Part No.               |
|--|-------------------|------------------------|
| <p><b>RE8LE16R-R1P-A</b></p>    | <p>Riser Card</p> | <p>90SCOBNO-MOXBNO</p> |
| <p><b>RG16LX2G8R-R1P-A</b></p>  | <p>Riser Card</p> | <p>90SCOCFO-MOXBNO</p> |
| <p><b>RG16L-OCP-R2P-B</b></p>  | <p>OCP Card</p>   | <p>90SCODDO-MOXBNO</p> |

| Component   | Description             | Part No.       |
|---|-------------------------|----------------|
| <b>INTERNAL SAS HD CABLE, L=85CM</b>  |                         |                |
|    | Internal SAS HD Cable   | 14011-00480500 |
| <b>SMBUS CABLE 2*5P TO 2*5P L:750</b>   |                         |                |
|   | SMBUS Cable             | 14011-02380600 |
| <b>NCSI 2X8 PIN TO 2X8 PIN L:150</b>  |                         |                |
|  | NCSI Cable              | 14011-04600000 |
| <b>NCSI CABLE 1*18 TO 1*18 L:200MM</b>  |                         |                |
|  | NCSI Cable              | 14011-04710000 |
| <b>SLSAS R/A TO SLSAS V/T L:670</b>   |                         |                |
|  | SlimSAS Cable           | 14022-00103900 |
| <b>FPB CABLE 2*10 TO 2*5+2*7<br/>L:230//ASAP/L67WH807-DT-R</b>                      |                         |                |
|  | Front Panel Board Cable | 14011-00122600 |





**Cables for RS700A-E11-RS12U**

| Component   | Description       | Part No.       |
|---|-------------------|----------------|
| <b>FPB CABLE 2*10 TO 2*5+2*7 L:230</b>  |                   |                |
|  | Front Panel Cable | 14011-00121000 |
| <b>PWR BP 4P/M TO 4P/M L:300MM</b>  |                   |                |
|  | Power Cable       | 14017-00040700 |
| <b>PWR BP 8P/M TO 8P/M L:280</b>  |                   |                |
|  | Power Cable       | 14017-00560800 |

**Cables for RS700A-E11-RS12U**

| Component   | Description   | Part No.       |
|---|---------------|----------------|
| <b>SLSAS V/T-R TO SLSAS V/T L:600</b>   |               |                |
|    | SlimSAS Cable | 14022-00103700 |
| <b>SLSAS R/A TO SLSAS V/T L:770</b>   |               |                |
|   | SlimSAS Cable | 14022-00103800 |
| <b>SLSAS V/T-R TO HD V/T L:510</b>  |               |                |
|  | SlimSAS Cable | 14022-00104000 |

**Cables for RS700A-E11-RS4U**

| Component  | Description              | Part No.       |
|--|--------------------------|----------------|
| <b>VGA CABLE 2*8 TO 2*8 L:1000MM</b><br>                | VGA Cable                | 14011-00110400 |
| <b>SIDEBAND CABLE 8P,16P TO 10P,14P<br/>L=600MM</b><br> | Sideband Cable           | 14011-05170500 |
| <b>POWER CABLE 8P TO 8P L:250MM</b><br>               | Power Cable              | 14017-00033000 |
| <b>SLSAS INT TO USB 3.0 L=700MM</b><br>               | SlimSAS to USB 3.0 Cable | 14022-00170100 |