













## Service Part List

The illustrations below show the components of the RS720-E9-RS24 series.

(Illustration model may not be the same, for more detailed information, please refer to the SN)

Component	Description	Part No.
<b>Z11PP-D24</b>		
	Motherboard	M: 90SB05N0-MOXXN1 S: 90SB05N0-MOXXBX0 90SB05N0-MOXXBX1 90SB05N0-MOXXN0
<b>RE16RX3-R21L</b>		
	Riser card	M: 90SC08G0-MOXXN0 S: 90SC08G0-MOXBNO
<b>RE16LX2-R21L</b>		
	Riser Card	M: 90SC08F0-MOXXN0 S: 90SC08F0-MOXBNO
<b>RE16RX3-R21L</b>		
	Riser Card	M: 90SC08G0-MOXXN0 S: 90SC08G0-MOXBNO
<b>RE16L-R21L</b>		
	Riser Card	M: 90SC08H0-MOXXN0 S: 90SC08H0-MOXBNO

Component	Description	Part No.
<b>PCIE-NVME4-OCULINK</b> 	OCULINK Card <b>(Only for RS720-E9-RS24-U)</b>	M: 90SC0930-MOXXN0 S: 90SC0930-MOXBNO
<b>CB12LE8G-25-R2P</b> 	PCIe switch board <b>(Only for RS720-E9-RS24-U)</b>	M: 90SC0A10-MOXXN0 S: 90SC0A10-MOXBNO
<b>BP24LE12G-25-R2P</b> 	SATA/SAS/NVMe backplane <b>(Only for RS720-E9-RS24-U)</b>	M: 90SC0AK0-MOXXN0 S: 90SC0AK0-MOXBNO
<b>CBEX12G-E4-25-R20E</b> 	Expander board <b>(Only for RS720-E9-RS24-E)</b>	M: 90SC06T0-M00000 S: 90SC06T0-MOXBNO
<b>BP24LX12G-25-R20E</b> 	SATA/SAS backplane <b>(Only for RS720-E9-RS24-E)</b>	M: 90SC06S0-M1XXN0 S: 90SC06S0-M1XBNO
<b>PSU CRPS 1200W PLATINUM</b> 	Power Supply <b>(Only for RS720-E9-RS24-E)</b>	M: 0A100-00271100 S: 0A100-00270900
<b>PSU CRPS 1600W PLATINUM</b> 	Power Supply <b>(Only for RS720-E9-RS24-U)</b>	0A100-00250800

**POWER CABLE 8P TO 8P,600MM**


Power cable for HDD backplane  
**(Only for RS720-E9-RS24-E)**

14017-00030100

**OCU/R/P TO OCU/V/P L:850MM**


OCU Link cable for NVMe drive  
**(Only for RS720-E9-RS24-U)**

14011-02261800

**INTERNAL SAS HD CABLE, L=15CM**


SAS HD CABLE  
**(Only for RS720-E9-RS24-U)**

14011-00481200

**INTERNAL SAS HD CABLE, L=85CM**


SAS HD CABLE  
**(Only for RS720-E9-RS24-E)**

M: 14011-00480500

S: 14011-00480400

**SMBUS 2\*5P TO 10P L:600MM**


SMBUS Cable  
**(Only for RS720-E9-RS24-U)**

14011-02380000

**PWR\_BP\_8P/M\_TO\_8P/M\_TO\_4P/M400**


Power cable for HDD backplane  
**(Only for RS720-E9-RS24-U)**

14017-00260600

**PWR\_BP\_8P/M\_TO\_8P/M\_TO\_4P/M590**


Power cable for HDD backplane  
**(Only for RS720-E9-RS24-U)**

14017-00260500

**USB CABLE 2\*4 TO 2\*5,L=850MM**


Front USB cable

14G000509430

**FPB CAB2\*8/1\*10+1\*6+2\*10 950MM**


Front Panel cable

M: 14001-00800500

S: 14003-00110100

**AUX\_PANEL2 CABLE 2\*10 TO 2\*4 L**


Front LAN LED cable

14011-02680000

**W.H CABLE 4P TO 4P, L:150MM**


System Fan

14G030011552

**POWER 8P TO 8P, L:250MM**


Power cable for HDD backplane

14001-00190400

**RS520-E9 8038 FAN\_1.4A**


System fan

13070-01360000

**USB-R20A**


Front Panel USB board

M: 90-C1SDZ0-00P0T

S: 90-C1SDZ0-00XBN00T

**FPB-R20F**


Front Panel board

M: 90SC0630-M0XXN0

S: 90SC0630-M0XBN1