




Service Part List

The illustrations below show the components of the TS300-E10-PS4.

(Illustration model may not be the same, for more detailed information, please refer to the SN)

Component	Description	Part No.
P11C-E/4L 	Motherboard	M: 90SB06P0-MOXBX0 S: 90SB06P0-MOXBNO 90SB06P0-MOXXNO
PSU ATX 500W ERP2014,G APFC 	PSU	0A100-00141300
DVD S-MULTI DL 16X/8X/8X6X/5X 	Optical drive	M: 17600-00030700 S: 17600-00050400
ESC2000 REAR FAN	System rear fan	13G074186010


LGA1156 COOLER 1366 BOX


CPU heatsink

13G074157020

FPB-TRS8A


Front Panel USB module

M: 90SC00N0-M00000

S: 90SC00N0-M0XBN1

90SC00N0-M0XBN0

R1 A P11C-C IO SHIELD


IO Shield

13SF00G0M07011

BP4LX12G-35-T50D


HDD Backplane

M: 90SC0750-M00000

S: 90SC0750-M0XBN0

R21A 3-5 HDD MODULE ASSY


HDD Tray

M: 13GS1I0AM054-1

S: 13GS1I0AM063-1

SATA cable for optical drive

SATA CABLE 7P 90-180,L:500mm

14G000100101


INTERNAL SAS HD CABLE,L=60CM


Mini SAS HD cable for HDD
Backplane

14011-00480800

COM1 CABLE 9P,L:260MM(BRACKET)


COM Port cable

M: 14001-00400100

S: 14G00002009H

USB3.0 180 TO 90-R L=900MM


USB 3.0 Cable for front panel USB 3.0 14002-00200100

WIRE CABLE USB 10P TO 10P


USB 2.0 Cable for front panel USB 2.0 14G143083000