


Fast. Easy. Setup!



1 Prepare your Modem


Connect your modem to the router with the network cable provided.



Power on the modem. Plug modem to the power outlet and power on.


Power on your cable/DSL modem.

Check your cable/DSL modem LED lights to ensure the connection is active.




2 Power on your Router

Plug in the power adapter and press the power button at the back of your router.




Check the WAN and 2.4G / 5G LED lights to ensure the hardware connection is ready (see the picture above).




Connect your PC to the router via Wi-Fi or using an additional network cable (not included).

3 Login and Connect



Open a web browser. You will be redirected to the ASUS Setup Wizard. If not, navigate to <http://router.asus.com>



Set up the router login information. Assign unique login name and password for your router to prevent unauthorized access.

Security		
Record your login information here.		
Router	Login Name	
	Password	
2.4 GHz	Network Name(SSID)	
	Password	
5 GHz	Network Name(SSID)	
	Password	

1 If you are using DSL for internet, you will need your username/password from your Internet service provider (ISP) to properly configure your router.

Rápido. Sencillo. ¡Configurado!



1 Preparar el módem


Conecte el módem al router con el cable de red proporcionado.



Encienda el módem. Enchufe el módem a la toma de corriente eléctrica y enciéndalo.


Encienda su módem de cable o DSL.

Compruebe las luces de los LED del módem de cable o DLS para asegurarse de que la conexión está activa.




2 Encienda el router

Enchufe el adaptador de alimentación y presione el botón de alimentación situado en la parte posterior del router.



Compruebe las luces de los LED WAN y 2,4G / 5G para asegurarse de que la conexión de hardware está preparada (consulte la imagen anterior).




Conectar su PC al router a través de WiFi o utilizando un cable de red adicional (no incluido).

3 Iniciar sesión y conectar



Abra un explorador Web. Será redirigido al Asistente para configuración de ASUS. Si no es así, navegue a <http://router.asus.com>.



Configure la información de inicio de sesión del router. Asigne un nombre de inicio de sesión único y una contraseña para el router con el fin de evitar accesos no autorizados.

Seguridad

Grabe aquí información de inicio de sesión.

Router	Nombre de inicio de sesión	
	Contraseña	
2.4 GHz	Nombre de red (SSID)	
	Contraseña	
5 GHz	Nombre de red (SSID)	
	Contraseña	

1 Si utiliza DSL para Internet, necesitará el nombre de usuario y la contraseña de su proveedor de servicio de Internet (ISP) para configurar adecuadamente el router.