


Fast. Easy. Setup!




1 Prepare your Modem

Connect your modem to the router with the network cable provided.




Power on the modem. Plug modem to the power outlet and power on.

Check the LED lights of the modem to ensure the connection is active.




2 Power on your Router

Plug in the power adapter and press the power button at the back of your router.



Check the WAN and 2.4G / 5G LED lights to ensure the hardware connection is ready (see the picture above).




Connect your PC to the router via Wi-Fi or using an additional network cable (not included).

3 Login and Connect



Open a web browser. You will be redirected to the ASUS Setup Wizard. If not, navigate to <http://router.asus.com>



Set up the router login information. Assign unique login name and password for your router to prevent unauthorized access.

| Security | | |
|-------------------------------------|--------------------|--|
| Record your login information here. | | |
| Router | Login Name | |
| | Password | |
| 2.4 GHz | Network Name(SSID) | |
| | Password | |
| 5 GHz | Network Name(SSID) | |
| | Password | |


1 If you are using DSL for internet, you will need your username/password from your Internet service provider (ISP) to properly configure your router.

Rapide. Facile. Configurez !




1 Préparer votre modem

Raccordez votre modem au routeur à l'aide du câble réseau fourni.





Allumez le modem. Branchez le modem à une prise électrique puis allumez-le.




Vérifiez les voyants lumineux de votre modem pour vous assurer que la connexion est établie.

2 Allumer votre routeur

Branchez l'adaptateur secteur et appuyez sur le bouton d'alimentation situé à l'arrière de votre routeur.



Vérifiez les voyants de réseau étendu (WAN) et les voyants de bandes 2,4 GHz et 5 GHz pour vous assurer que la connexion matérielle est prête (voir l'image ci-dessus).




Connectez votre ordinateur au routeur en Wi-Fi ou à l'aide d'un câble réseau supplémentaire (non fourni).

3 Vous connecter



Ouvrez un navigateur internet. Vous serez automatiquement redirigé vers l'assistant de configuration ASUS. Dans le cas contraire, rendez-vous sur <http://router.asus.com>



Configurez les informations de connexion de votre routeur. Définissez un nom de connexion et un mot de passe afin d'éviter les accès non autorisés au routeur.

Sécurité

Notez vos informations de connexion ici.

| | | |
|---------|-------------------|--|
| Routeur | Nom de connexion | |
| | Mot de passe | |
| 2,4 GHz | Nom réseau (SSID) | |
| | Mot de passe | |
| 5 GHz | Nom réseau (SSID) | |
| | Mot de passe | |

1 Si vous utilisez le DSL pour accéder à Internet, vous aurez besoin du nom d'utilisateur et du mot de passe fournis par votre fournisseur d'accès internet (FAI) pour configurer votre routeur.