DVD Playback over DH/DVS/DDL/Multiple Analog Speakers

Windows XP

Dolby Headphone (Virtualized 5.1 surround sounds over stereo headphone)

1. Open PowerDVD➔Configuration➔Audio
2. Select 6 speaker in Speaker Environment
3. Select No Effect in Output Mode
4. Press OK



5. Open Xonar Audio Center
6. Select Headphone in Analog Out
7. Check “Dolby Headphone”

Dolby Virtual Speaker (Virtualized 5.1 surround sounds over stereo speakers)

1. Open PowerDVD➔Configuration➔Audio
2. Select 6 Speaker in Speaker Environment
3. Select No Effect in Output Mode
4. Press OK



5. Open Xonar Audio Center
6. Select 2 Speakers in Analog Out

7. Check “Dolby Virtual Speaker”

DVD playback by SPDIF (Dolby Digital/DTS digital audio pass-through)

1. Open PowerDVD➔Configuration➔Audio
2. Select Use SPDIF in Speaker Environment
3. Press OK



4. Open Xonar Audio Center
5. Enable “SPDIF Out”

DVD playback by SPDIF (Add Sound effects w/ DDL encoding)

1. Open PowerDVD➔Configuration➔Audio
2. Select 6 speaker in Speaker Environment
3. Select No Effect in Output Mode
4. Press OK



5. Open Xonar Audio Center
6. Enable “SPDIF Out”
7. Select Dolby Digital Live in SPDIF Out

8. In this mode, you are able to adjust the DVD sound volume, your multi-speaker placement and surround soundfield virtually by 7.1 Virtual Speaker Shifter. You can also add environmental reverbs or EQ effect into the movie surround sounds. In a word, you can optimize the movies' sounds even over Dolby Digital output to your home theater.

Windows Vista

Dolby Headphone (Virtualized 5.1 surround sounds over stereo headphone)

1. Open PowerDVD➔Configuration➔Audio
2. Select 6 speaker in Speaker Environment
3. Select No Effect in Output Mode
4. Press OK



5. Open Xonar Audio Center
6. Select 6 Channels in Audio Channel
7. Select Headphone in Analog Out
8. Check “Dolby Headphone”

Dolby Virtual Speaker (Virtualized 5.1 surround sounds over stereo speakers)

1. Open PowerDVD➔Configuration➔Audio
2. Select 6 Speaker in Speaker Environment

3. Select No Effect in Output Mode
4. Press OK



5. Open Xonar Audio Center
6. Select 6 Channels in Audio Channel
7. Select 2 Speakers in Analog Out
8. Check “Dolby Virtual Speaker”

DVD playback by SPDIF (Dolby Digital/DTS digital audio pass-through)

1. Open PowerDVD➔Configuration➔Audio
2. Select Use SPDIF in Speaker Environment
3. Press OK



4. Open Xonar Audio Center
5. Enable “SPDIF Out”

DVD playback by SPDIF (Add Sound effects w/ DDL encoding)

1. Open PowerDVD➔Configuration➔Audio
2. Select 6 speaker in Speaker Environment

3. Select No Effect in Output Mode
4. Press OK



5. Open Xonar Audio Center
6. Select 6 Channels in Audio Channel
7. Enable “SPDIF Out”
8. Select Dolby Digital Live in SPDIF Out
9. In this mode, you are able to adjust the DVD sound volume, your multi-speaker placement and surround soundfield virtually by 7.1 Virtual Speaker Shifter. You can also add environmental reverbs or EQ effect into the movie surround sounds. In a word, you can optimize the movies’ sounds even over Dolby Digital output to your home theater.

DOLBY
dts
Connect
MENU
Audio Channel
6 Channels
Sample Rate
PCM 96 KHz
Analog Out
SPDIF Out
Dolby Digital Live
Reset
Sub
7.1 Virtual Speaker Shifter
Min
Max
SVN
Mute
HF
DSP Mode
Main
Mixer
Effect
KARAOKE
FlexBass
AEC