# 8. ISP Instruction

**Before Upgrade scaler fw and EDID, the following message must be noted first:**

1. After use USB disk to upgrade scaler FW, please keep use USB disk to update, but don't use ISP TOOL to update scaler FW.
2. If use ISP TOOL to upgrade scaler FW, please clean up the entire flash data, HDCP key will all lose, so after update FW, need update EDID.

## Upgrade Scaler FW with USB

1. Prepare a USB disk (The file system of USB disk must be FAT16 or FAT 32).
2. Copy the file from your computer to the USB disk root directory, and Change the software file name to "ASUS_PA279CV.bin".then remove it from computer's USB port.
3. Insert the U disk to Upstream USB port (below picture number9) of MNT.

4. Give the monitor HDMI or DP source.
5. AC OFF.
7. Enter Factory Menu to select "USB Update", the MNT will update FW till appears update pass.

The way to open the factory menu.

Press "Input select" Key and then insert the power cable, when the screen lights, release the key and press "MENU" again to open the menu with "F"

6. Do Reset in user menu after FW update

   Restart the monitor, select ALL reset ----YES