


PL-N12 Kit 300Mbps AV500 Wi-Fi PowerLine Extender


Quick Start Guide

Applicable to PL-N12 and its multiple-pack kits.
This QSG uses PL-E41 powerline adapter to work with PL-N12 powerline extender.

PL-N12 Kit includes:

- PL-N12 Wireless-N300 Wi-Fi PowerLine
- PL-E41 Homeplug AV 500Mbps PowerLine Adapter





Wi-Fi Clone (optional)

Use your router's wireless network name and password to configure your PL-N12 settings.

- 1. Place your PL-N12 next to your router, and turn both devices on.
- Press the WPS button on your router.



3. Press the Clone button on your PL-N12.




 Your PL-N12 and your router now have the same wireless network name and password.

NOTE: If Wi-Fi Clone succeeds, move your PL-N12 to your preferred location. If it fails, follow the steps in **PL-N12 Wireless Settings**.



To connect devices to your PL-N12 Wi-Fi powerline, refer to the Wi-Fi information sticker for the default network name (SSID) and password.



Model No. PL-N12

	<u>.</u>
0	To customize your PL-N12 network name (SSID) and password, refer to the section PL-N12 Wirele Settings .

Your Configuration				
Customized Wireless Network Name				
Customized Wireless Password				

Pair button (optional)

Pairing devices via the Pair button


Use the Pair button to create a secure powerline network, and add up to 16 powerline devices to this network.

Creating a secure powerline network

1. Press the Pair/Reset button on your 2.




Press the Pair button on your PL-N12. I I Wait until the powerline LED lights I I up, indicating that a secure powerline network has been created.




Joining a secure powerline network

1. Press the Pair button on a powerline device in the powerline network.




Press the Pair button on another extender. Wait until the powerline LED lights up, indicating that pairing is successful.



PL-N12 Wireless Settings (optional)

1. Set up your PL-N12 via wired or wireless connection. For details, refer to the section **Plug-n-Play** on the previous page.




- 2. Go to http://ap.asus.com
- 3. Use **admin** as both the username and password.




- 4. Go to **Wireless** > **General** and set the SSID (network name) and password.
- 5. When done, click **Apply**.

LEDs and buttons



PL-N12 Extender



-	LED	STATUS	DESCRIPTION
ტ	Power	On/Off	Your PL-N12 is on/off. When switched on, the power LED turns from red to green in about one minute, indicating that it is ready to use.
		Blinking	Blinking every second: Pairing is in progress.
企	Powerline	On	The device is connected to one or more powerline devices.
		Off	The device is not connected to any powerline devices.
		Blinking	In Power-Saving mode, the powerline LED blinks every 15 seconds.
	Ethernet	On/Off	A device is connected or not connected to the Ethernet port.
•••		Blinking	The powerline adapter is transferring data via the Ethernet port.
	Wi-Fi	Blinking rapidly	Your PL-N12 is cloning the parent AP's SSID and password.
ি		Blinking every five seconds	Your PL-N12 is resetting to the factory default settings.

BUTTON	DESCRIPTION		
Clone	Press and hold the button for about one second to start cloning the parent AP's SSID and password.		
Pair	Press and hold the button for about one second to start the pairing process.		
Reset	Press and hold the button for about five seconds to restore the PL-N12 to the factory default settings.		

Frequently Asked Questions (FAQs)

Q1: How do I reset my PL-N12?

With your PL-N12 switched on, use a pin to press and hold the Reset button until the Wi-Fi LED starts blinking. When the power LED turns green and the Wi-Fi LED is on, the reset process is completed.

Q2: My devices cannot connect to the Internet.

- Check your Internet connection.
- Ensure that the powerline LED lights up on all your powerline devices in the network. If they do not, try pairing the devices again.
- Ensure that all your devices are in the same network.
- Ensure that all the extenders and adapters are in the same electrical circuit.

Q3: My successfully-paired PL-N12 does not work after I moved it to a new location.

- Ensure that all the extenders and adapters are in the same electrical circuit.
- Try to pair your extender with your adapter again. For details, see Pairing devices via the Pair button.
- Check for any possible interferences that may be too close to your extenders or adapters such as air conditioners, washing machines, and other electrical appliances.
- Ensure that all your devices are in the same network.

